

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Noise](#) /

> [Noise ColorFit Icon 2 Smartwatch User Manual](#)

Noise ColorFit Icon 2

Noise ColorFit Icon 2 Smartwatch

USER MANUAL

1. Introduction

This manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your Noise ColorFit Icon 2 Smartwatch. Please read this manual thoroughly before using your device to ensure proper function and longevity.



Image: Front view of the Noise ColorFit Icon 2 Smartwatch, displaying its rectangular screen and strap.

2. What's in the Box

Verify that all the following items are present in your product packaging:

- Noise ColorFit Icon 2 Smartwatch

- Magnetic Charger
- User Manual (this document)
- Warranty Card

3. Setup

3.1 Charging the Smartwatch

Before initial use, fully charge your smartwatch. Connect the magnetic charger to the charging points on the back of the smartwatch and plug the USB end into a compatible power adapter (not included) or a computer's USB port. The watch display will indicate charging status.

3.2 Powering On/Off

- **To Power On:** Press and hold the side button until the Noise logo appears.
- **To Power Off:** Navigate to the settings menu on the smartwatch, select "Power Off," and confirm. Alternatively, press and hold the side button and select "Power Off" from the options.

3.3 Pairing with Your Smartphone

1. Download the official NoiseFit application from your smartphone's app store.
2. Ensure Bluetooth is enabled on your smartphone.
3. Open the NoiseFit app and follow the on-screen instructions to create an account or log in.
4. Select "Add Device" or a similar option within the app and choose "ColorFit Icon 2" from the list of available devices.
5. Confirm the pairing request on both your smartphone and the smartwatch.
6. Your smartwatch is compatible with devices running iOS 8 & + or Android 4.4 & +.

4. Operating Instructions

4.1 Basic Navigation

- **Swipe Up/Down:** Scroll through menus and notifications.
- **Swipe Left/Right:** Access quick widgets or different screens.
- **Tap:** Select an item or confirm an action.
- **Side Button:** Press to return to the home screen or wake the device.

4.2 Key Features

The Noise ColorFit Icon 2 Smartwatch offers various features accessible through its interface and the connected NoiseFit app. These include:

- Activity Tracking (steps, distance, calories)
- Heart Rate Monitoring
- Sleep Tracking
- Notification Alerts (calls, messages, app notifications)
- Music Control
- Weather Information

For detailed instructions on specific features, refer to the NoiseFit application's help section.

5. Maintenance

5.1 Cleaning

Regularly clean your smartwatch and strap to prevent skin irritation and maintain device performance. Use a soft, lint-free cloth. If necessary, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive materials, or strong detergents.

5.2 Charging Best Practices

- Use only the provided magnetic charger.
- Avoid exposing the charging contacts to water or sweat. Ensure they are dry before charging.
- Do not leave the smartwatch charging for extended periods after it is fully charged.

5.3 Storage

When not in use for an extended period, store the smartwatch in a cool, dry place away from direct sunlight and extreme temperatures. Ensure it has a partial charge to prevent battery degradation.

6. Troubleshooting

Problem	Possible Solution
Smartwatch does not power on.	Ensure the device is fully charged. Connect to the magnetic charger and wait a few minutes before attempting to power on again.
Cannot pair with smartphone.	<ul style="list-style-type: none">• Ensure Bluetooth is enabled on your phone.• Make sure the smartwatch is within range of your phone.• Restart both the smartwatch and your phone.• Check if the NoiseFit app is updated to the latest version.• Forget the device from your phone's Bluetooth settings and try pairing again.
Inaccurate activity tracking.	Ensure the smartwatch is worn snugly on your wrist, about one finger's width above your wrist bone. Calibrate the device through the NoiseFit app if available.
Notifications not received.	<ul style="list-style-type: none">• Check notification settings in the NoiseFit app.• Ensure the app has necessary permissions on your phone.• Verify that the smartwatch is connected via Bluetooth.

If you encounter issues not listed here, please refer to the support section of the NoiseFit application or contact customer support.

7. Specifications

Feature	Detail
Brand	Noise
Model Series	ColorFit Icon 2

Feature	Detail
Item Model Number	wrb-sw-colorfiticon2-std-blu_blu
Product Dimensions	4.7 x 3.9 x 1.2 cm
Item Weight	45 g
Connectivity Type	Bluetooth
Wireless Type	Bluetooth
Operating System Compatibility	iOS 8 & + or Android 4.4 & +
Included Components	Smartwatch, Magnetic Charger, User Manual, Warranty Card
GPS	No GPS
Shape	Rectangular

8. Warranty and Support

Your Noise ColorFit Icon 2 Smartwatch comes with a **1-year assured warranty** from Noise, covering manufacturing defects from the date of purchase. Please retain your purchase receipt and warranty card for any warranty claims.

For technical support, warranty claims, or further assistance, please contact Noise customer service.

Manufacturer and Importer details:

Nexxbase Marketing Pvt. Ltd.

Khasra No-146/25/2/1, Jail Road Badshahpur,

Gurugram Haryana-122101, India

Phone: 8882-132-132

You can also visit the official Noise website for more information and support resources.