



[Manuals.plus](#) /

› [LDAILY](#) /

› LDAILY A-Frame Swing Stand Instruction Manual

LDAILY NP10525-1YE

LDAILY A-Frame Swing Stand Instruction Manual

Model: NP10525-1YE

1. INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your LDAILY A-Frame Swing Stand. This heavy-duty steel swing frame is designed for both indoor and outdoor use, supporting a variety of swings for children and adults. Please read these instructions thoroughly before assembly and retain this manual for future reference.

2. SAFETY INFORMATION

Your safety is paramount. Adhere to all warnings and instructions to prevent injury.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 660 lbs (300 kg). This stand is designed to support two swings simultaneously.
- **Age Recommendation:** Suitable for users aged 3 years and older. Adult supervision is recommended for children.
- **Stable Installation:** Ensure the swing stand is assembled on a level surface. For outdoor use, utilize the provided ground stakes to secure the frame firmly to the ground to prevent wobbling or tipping. For indoor use, ensure anti-slip foot pads are properly installed.
- **Regular Inspection:** Before each use, inspect all components, including frame connections, carabiners, and ground stakes, for wear, damage, or looseness. Tighten any loose connections immediately.
- **Swing Compatibility:** Ensure any attached swings are compatible with the stand's hanging mechanisms and do not exceed the stand's dimensions or weight limits. Swings are not included with this stand.
- **Clearance:** Maintain adequate clear space around the swing stand to prevent collisions.
- **Material Integrity:** The frame is constructed from heavy-duty steel with a rustproof surface. However, prolonged exposure to extreme weather conditions may affect its integrity.

Heavy-Duty Swing Frame



Image: The swing stand in use, highlighting its ASTM certification, sturdy triangular construction, durable design, and 660 lbs weight capacity.

3. PACKAGE CONTENTS

Please verify that all parts are present before beginning assembly.

- 1 x Swing Frame Stand (consisting of various steel tubes)
- 4 x Carabiners
- 4 x Ground Stakes
- 4 x Foot Pads
- 1 x Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Assembly requires two adults. Follow these steps carefully.

1. **Unpack Components:** Lay out all parts on a clean, flat surface. Refer to the parts list to ensure everything is accounted for.
2. **Assemble A-Frame Legs:** Connect the steel tubes to form the two A-frame structures. Ensure all connections are secure and aligned. The inner tube joints are reinforced for stability.
3. **Attach Top Beam:** Connect the assembled A-frames to the main horizontal top beam. Ensure the beam is centered and securely fastened to both A-frames.
4. **Install Cross Bars:** Attach the reinforced cross bars between the A-frame legs to enhance structural rigidity.
5. **Secure Connections:** Double-check all bolts, nuts, and connections to ensure they are tightened securely.
6. **Attach Foot Pads (Indoor Use):** If using indoors, slide the anti-slip foot pads onto the bottom of each leg to protect floors and increase stability.
7. **Install Ground Stakes (Outdoor Use):** For outdoor installation, position the swing stand on a level patch of ground. Drive the ground stakes through the designated holes at the base of each leg into the soil until firm. This prevents movement during use.
8. **Attach Carabiners:** Secure the provided carabiners to the hanging points on the top beam. These will be used to attach your swings.

Wide Range of Usage

Available for a multiple kinds of swings



Saucer Tree Swing



Belt Swing



Yoga Swing



Note: Swings are not included

Image: Close-up details of the swing stand's construction, including the A-frame design, smooth surfaces, carabiners, reinforced cross bars, and tightened connections.

Stand with Higher Stability



Image: Illustration of the stand's stability features: reinforced inner tube joint, anti-slip footpads for indoor use, and ground nails for outdoor use.

5. OPERATING INSTRUCTIONS

The LDAILY A-Frame Swing Stand is designed for versatile use with various swing types.

- **Attaching Swings:** Use the provided carabiners to attach your desired swings (e.g., swing seat, saucer tree swing, aerial yoga hammock, platform swing, hanging chair tent swing). Ensure the carabiners are securely closed after attachment.
- **Dual Hanging Options:** The stand offers two ways to connect swings: directly via the carabiners or by using a lanyard (not included) with the carabiners.
- **Weight Distribution:** When using two swings, ensure the weight is distributed evenly and does not exceed the total 660 lbs capacity.
- **Supervision:** Always supervise children during play.

Dual Hanging Ways

Choose the hanging ways as you like



Image: Demonstrates the two methods for attaching swings: using the carabiners directly or with a lanyard.



Image: The swing stand in use with a child enjoying a saucer swing.

6. MAINTENANCE

Regular maintenance ensures the longevity and safety of your swing stand.

- **Cleaning:** Wipe down the steel frame with a damp cloth and mild soap as needed. Avoid abrasive cleaners.
- **Rust Prevention:** Although the frame has a rustproof surface, inspect for any signs of rust, especially in areas where the coating might be scratched. Touch up with rust-inhibiting paint if necessary.
- **Hardware Check:** Periodically check all nuts, bolts, and connections for tightness. Re-tighten as required to maintain structural integrity.
- **Ground Stakes:** For outdoor use, ensure ground stakes remain firmly embedded. Re-secure if they become loose due to soil conditions.
- **Storage:** During prolonged periods of non-use or harsh weather, consider disassembling and storing the swing stand indoors to extend its lifespan.

7. TROUBLESHOOTING

If you encounter issues with your swing stand, refer to the following common solutions.

Problem	Possible Cause	Solution
Swing stand feels unstable or wobbles.	Uneven ground; loose connections; ground stakes not fully secured (outdoor); foot pads missing/damaged (indoor).	Ensure installation on a level surface. Check and tighten all bolts and nuts. For outdoor use, re-drive ground stakes firmly. For indoor use, verify foot pads are correctly installed.
Connectors (carabiners) show wear or damage.	Normal wear and tear; excessive load; improper use.	Inspect carabiners regularly. Replace any worn or damaged carabiners immediately with suitable heavy-duty replacements. Ensure total weight does not exceed 660 lbs.
Frame appears to bend or deform under load.	Exceeding weight capacity; improper assembly; structural fatigue.	Immediately cease use. Verify that the total weight on the stand does not exceed 660 lbs. Re-check assembly for any incorrect connections. If deformation persists, discontinue use and contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	LDAILY
Model Number	NP10525-1YE
Material	Alloy Steel
Finish Type	Powder Coated
Overall Dimension (L x W x H)	98" x 73" x 71.5" (249 cm x 185 cm x 181.6 cm)
Top Length	86.5" (220 cm)
Net Weight	46 lbs (20.9 kg)
Weight Capacity	660 lbs (300 kg)
Color	Blue + Yellow
Certifications	ASTM Certified



Suitable Age: 3+ Years Old




Image: Detailed dimensions of the swing stand and its maximum weight capacity.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact LDAILY customer service through the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

