

ACAGET ACAGET-0110

ACAGET Wireless Earbuds User Manual

Model: ACAGET-0110

Brand: ACAGET

INTRODUCTION

Thank you for choosing ACAGET Wireless Earbuds. These lightweight, touch-controlled Bluetooth 5.1 earphones are designed to provide a comfortable and immersive audio experience. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure optimal performance.

WHAT'S IN THE BOX

- Wireless Earbuds (Left and Right)
- Charging Box
- USB Charging Cable
- Storage Case
- User Manual

PRODUCT OVERVIEW

The ACAGET Wireless Earbuds feature a compact and ergonomic design for comfortable wear. The accompanying charging case provides extended battery life and convenient portability.



Image: ACAGET Wireless Earbuds, charging case, and included carrying case.

Each earbud weighs only 4.3g, and the pocket-sized charging case is designed for minimal bulk, making them ideal for on-the-go use.

SMALL & COMPACT DESIGN



Image: Diagram illustrating the small and compact design of the earbuds and charging box, highlighting their light weight.

Equipped with advanced Bluetooth 5.1 technology, these earbuds ensure a stable and fast connection. They are compatible with a wide range of Bluetooth-enabled devices, including various iPhone, iPad, Samsung Galaxy, Google Pixel, and OnePlus models.



WIDE COMPATIBILITY

Compatible with most Bluetooth mobile phones and other devices
that support the Bluetooth headset

Image: Earbuds and charging case next to various smartphones, illustrating wide compatibility.

SETUP

Charging the Earbuds and Case

Before first use, fully charge the charging case and earbuds. Connect the provided USB charging cable to the USB-C port on the charging case and a power source. The indicator light on the case will show charging status and turn off when fully charged (approximately 1.5 hours for the case).

LONG BATTERY LIFE

Bluetooth earbuds get 4-5 hour's playtime from a single charge (only 1.5hrs charge time) and 25 extra hours in the mini portable charging case



Image: Earbuds in their charging case, with a graphic indicating up to 30 hours of total playtime.

The earbuds provide 4-5 hours of playtime on a single charge, and the portable charging case can recharge them approximately 5 times, extending total playtime up to 30 hours.

Video: This video demonstrates the charging process of the ACAGET Wireless Earbuds and their charging case, highlighting the long battery life.

One-Step Pairing

To pair the earbuds with your device:

1. Take both earbuds out of the charging case. They will automatically enter pairing mode.
2. On your smartphone or Bluetooth-enabled device, open the Bluetooth settings.
3. Select "BT-A1" from the list of available devices to complete the pairing process.

ONE-STEP PAIRING

Pick up 2 Earbuds from Charging Box
Connect Bluetooth “BT-A1”



Image: A smartphone screen showing "BT-A1" in the Bluetooth device list, with earbuds next to the charging case, illustrating the one-step pairing process.

Once paired, the earbuds will automatically connect to your device when taken out of the case for future use.

OPERATING THE EARBUDS

Smart Touch Controls

The ACAGET Wireless Earbuds feature intuitive touch controls on each earbud for easy management of calls, music, and voice assistant functions.

SMART TOUCH CONTROL



Image: A person wearing an earbud, with a diagram showing various touch control gestures and their corresponding functions.

Video: This video demonstrates the various smart touch control functions of the ACAGET Wireless Earbuds, including music playback, call management, and voice assistant activation.

Touch Control Functions

Action	Gesture	Function
Music Play/Pause	Single tap (Left or Right earbud)	Plays or pauses current audio.
Next Track	Double tap (Left earbud)	Skips to the next song.
Previous Track	Double tap (Right earbud)	Skips to the previous song.
Volume Up	Triple tap (Right earbud)	Increases volume.
Volume Down	Triple tap (Left earbud)	Decreases volume.
Answer/End Call	Single tap (Left or Right earbud)	Answers an incoming call or ends an active call.

Action	Gesture	Function
Reject Call	Long touch for 2 seconds (Left or Right earbud)	Rejects an incoming call.
Wake Up Voice Assistant (Siri)	Long touch for 2 seconds (Left or Right earbud)	Activates your device's voice assistant.

MAINTENANCE

To ensure the longevity and optimal performance of your ACAGET Wireless Earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds, especially the charging contacts, with a dry, soft cloth. Avoid using abrasive materials or harsh chemicals.
- **Water Resistance:** The earbuds are IPX4 water-resistant, protecting them from sweat and light rain. They are *not* designed for swimming or bathing. Avoid submerging them in water.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Temperature:** Avoid exposing the earbuds to extreme temperatures (hot or cold) or direct sunlight for extended periods.

TROUBLESHOOTING

If you encounter issues with your earbuds, refer to the following common solutions:

- **Earbuds not pairing:** Ensure both earbuds are out of the case and fully charged. Turn off and on your device's Bluetooth, then try pairing again. If issues persist, try resetting the earbuds (refer to manufacturer's website for specific reset instructions if not in manual).
- **No sound from one earbud:** Place both earbuds back into the charging case, close the lid, wait a few seconds, then take them out again. This often re-syncs them.
- **Charging issues:** Check that the charging cable is securely connected to both the case and the power source. Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.
- **Poor sound quality:** Ensure the earbuds are properly seated in your ears. Check your device's volume settings. Move closer to your connected device to avoid interference.
- **Touch controls unresponsive:** Ensure your fingers are clean and dry. Try restarting the earbuds by placing them back in the case and taking them out again.

For further assistance, please contact ACAGET customer support.

SPECIFICATIONS

Feature	Detail
Model Name	ACAGET-0110
Connectivity Technology	Wireless (Bluetooth 5.1)
Earbud Weight	4.3g (each)
Earbud Battery Life	4-5 hours (single charge)




Feature	Detail
Total Playtime (with case)	Up to 30 hours
Charging Case Battery Capacity	300 Milliamp Hours
Charging Time (Case)	1.5 hours
Water Resistance Level	IPX4 (Sweat and rain resistant)
Control Type	Touch Control
Bluetooth Range	10 Meters
Audio Driver Size	13 Millimeters
Frequency Response	20 Hz - 20,000 Hz
Impedance	32 Ohm
Product Dimensions	1.96 x 1.53 x 0.97 inches




WARRANTY AND SUPPORT

ACAGET US provides a 6-month worry-free new replacement service for these wireless earphones. If you encounter any problems with your product, please contact ACAGET directly for support. Do not hesitate to reach out even beyond the standard return window.

For more information or assistance, please visit the official ACAGET website or contact their customer service team.

Related Documents - ACAGET-0110

	<p>Bose L1 Pro8 Portable Line Array System: Technical Data and Specifications</p> <p>Detailed technical specifications, features, connections, dimensions, and performance data for the Bose L1 Pro8 portable line array system, designed for musicians and DJs.</p>
	<p>Rollease Acmeda S45 Automate 0.5Nm 20mm Roller Shade System Quick Reference Guide</p> <p>A comprehensive quick reference guide for the Rollease Acmeda S45 Automate 0.5Nm 20mm motorized roller shade system, detailing its features, technical specifications, system components, control options, and installation considerations.</p>
	<p>Bose Professional Veritas 2160BH Smart Mixer Amplifier Technical Data and Specifications</p> <p>Detailed technical specifications, features, applications, and hardware details for the Bose Professional Veritas 2160BH smart mixer amplifier. Learn about its premium amplification, DSP, connectivity options, and suitability for commercial audio installations.</p>

 The image shows the cover of the 'E3 Facility Status Display (FSD) Quick Start Guide'. It features a blue header with the title and a small image of the FSD device. Below the header, there is a table of contents and a list of features.	<p>Copeland E3-Facility Status Display (FSD) Quick Start Guide</p> <p>A quick start guide for the Copeland E3-Facility Status Display (FSD), detailing its features, specifications, mounting instructions, network setup, wiring, and software configuration for monitoring facility status and alarms.</p>
 The image shows the cover of the 'Hyper Toys 1:10 Scale Amphibious RC Truck Instruction Manual'. It features a black and white image of the RC truck and a table of contents.	<p>Hyper Toys 1:10 Scale Amphibious RC Truck Instruction Manual</p> <p>Comprehensive instruction manual for the Hyper Toys 1:10 Scale Amphibious RC Truck (Model HYP-SAM-0110). Learn about battery use, operation, maintenance, troubleshooting, and safety guidelines.</p>
 The image shows the cover of the 'Bose Professional Veritas 2160BH Smart Mixer Amplifier Technical Data Sheet'. It features a black and white image of the amplifier and a table of contents.	<p>Bose Professional Veritas 2160BH Smart Mixer Amplifier Technical Data Sheet</p> <p>Detailed technical specifications, features, and applications for the Bose Professional Veritas 2160BH smart mixer amplifier. Learn about its power output, connectivity options including Bluetooth, DSP capabilities, hardware details, electrical specifications, and dimensions.</p>