

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [CULTSPORT](#) /

› Cultsport C2 4HP Peak DC-Motorised Treadmill User Manual

## CULTSPORT C2

# Cultsport C2 4HP Peak DC-Motorised Treadmill User Manual

Model: C2 | Brand: CULTSPORT

## 1. INTRODUCTION

Welcome to the Cultsport C2 4HP Peak DC-Motorised Treadmill user manual. This guide provides essential information for the safe and effective operation, assembly, and maintenance of your new treadmill. Please read this manual thoroughly before initial use to ensure optimal performance and longevity of your equipment.



Image: Cultsport C2 Treadmill, showcasing its design and presence.

## 2. KEY FEATURES

The Cultsport C2 Treadmill is designed with advanced features to enhance your home workout experience:

- **Powerful Motor:** Equipped with a 4HP Peak DC motor, providing smooth and consistent performance.
- **Adjustable Speed:** Speed range from 0.8 km/h to 16 km/h, suitable for walking, jogging, and running.
- **Auto Incline:** Features 15 levels of automatic inclination for varied workout intensity.
- **High Weight Capacity:** Supports a maximum user weight of 120 kg (recommended weight support 100 kg).
- **Spacious Running Belt:** Belt dimensions of 1260mm x 450mm for comfortable strides.
- **LCD Display:** Clear display showing time, speed, distance, and calories burned.
- **Heart-Rate Monitoring:** Integrated sensors for tracking your heart rate during workouts.
- **Anti-Skid Surface:** Ensures safety and stability during use.

- **Hydraulic Folding System:** For easy and convenient storage.
- **Portable Design:** Equipped with wheels for effortless movement and storage.

## KEY FEATURES &

## Specifications



Motor Power  
4 HP Peak



Max Weight Support  
120 KG



Manual  
Lubrication



Speed  
1-16 km/h



Auto Inclination  
Level 15



Image: Visual representation of the treadmill's key features including motor power, max weight support, manual lubrication, speed, and auto inclination.

# PRODUCT Highlights



Image: Highlights of the treadmill including LCD display, heart-rate monitoring, anti-skid running surface, and wheels for easy storage.

## 3. SAFETY INFORMATION

Your safety is paramount. Please adhere to the following guidelines:

- Always consult with a healthcare professional before starting any new exercise program.
- Ensure the treadmill is placed on a flat, stable surface with adequate clearance around it.
- Keep children and pets away from the treadmill during operation.
- Use the safety key at all times. Attach it to your clothing before starting your workout.
- Do not operate the treadmill if it is damaged or malfunctioning.
- Wear appropriate athletic footwear during use.
- **Power Connection:** It is advised to buy and install a voltage stabilizer with the treadmill to protect the motor from power fluctuations and ensure its long life. Additionally, connect the product to a power point with adequate earthing

to ensure discharge of extra current.

- Do not exceed the maximum user weight of 120 kg.



Image: Close-up of the anti-skid running surface, highlighting a key safety feature.

## 4. ASSEMBLY & SETUP

The Cultsport C2 Treadmill requires assembly. A tool kit and user manual are included to assist you. Please follow the instructions provided in the separate assembly guide for detailed steps.

### 4.1 Unpacking and Placement

- Carefully remove all components from the packaging.
- Place the treadmill in a designated area, ensuring sufficient space for operation and safety. Refer to the dimensions below for planning.

## 4.2 Assembly Steps (General)

- Attach the uprights and console according to the assembly guide.
- Secure all bolts and nuts firmly.
- Connect any necessary electrical cables as instructed.
- Ensure the safety key mechanism is correctly installed and functional.



Image: Diagram showing the assembled dimensions of the Cultsport C2 Treadmill (167cm length, 72cm width, 132cm height).

## 5. OPERATING INSTRUCTIONS

Familiarize yourself with the control panel and functions before starting your workout.

### 5.1 Starting the Treadmill

1. Plug the power cord into a grounded electrical outlet.
2. Attach the safety key to the console and clip the other end to your clothing.
3. Step onto the treadmill belt, placing your feet on the side rails.
4. Press the 'START' button on the console. The belt will begin to move at a low speed.

### 5.2 Adjusting Speed and Incline

- **Speed Adjustment:** Use the 'Smart Knob' to easily increase or decrease the speed. Rotate clockwise to increase,

counter-clockwise to decrease. Quick speed buttons may also be available on the console.

- **Incline Adjustment:** Use the 'INCLINE UP' and 'INCLINE DOWN' buttons to adjust the incline level. The treadmill features 15 levels of auto inclination.



Image: The 'Smart Knob' control, illustrating its function for one-dial speed adjustments.

### 5.3 Monitoring Your Workout

- The LCD display will show your workout metrics: Time, Speed, Distance, and Calories Burned.
- Grip the heart rate sensors on the handlebars to monitor your pulse.

### 5.4 Stopping the Treadmill

- Press the 'STOP' button to gradually slow down and stop the treadmill.
- Alternatively, pulling the safety key will immediately stop the treadmill for emergency situations.



Image: A user actively running on the Cultsport C2 Treadmill, demonstrating its use.

## 6. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your treadmill.

### 6.1 Lubrication

- The Cultsport C2 Treadmill requires manual lubrication. Refer to the separate maintenance guide for detailed instructions on how and when to lubricate the running deck.
- Use only approved silicone lubricant.

### 6.2 Cleaning

- Wipe down the console and exterior surfaces with a damp cloth after each use.
- Do not use abrasive cleaners or solvents.

- Periodically vacuum underneath the treadmill to prevent dust buildup.

### 6.3 Belt Adjustment

- If the running belt feels loose or slips, it may need adjustment. Consult the maintenance guide for instructions on how to tension and center the belt.

### 6.4 Storage

- The treadmill features a hydraulic folding system for convenient storage. Lift the running deck until it locks into the upright position.
- Utilize the built-in wheels to easily move the folded treadmill for storage.



Image: A user demonstrating the hydraulic folding system, showing how the treadmill can be easily folded for storage.




Image: Close-up view of the wheels located at the base of the treadmill, designed for easy portability and storage.

## 7. TROUBLESHOOTING

If you encounter issues with your Cultsport C2 Treadmill, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Treadmill does not start	Power cord not plugged in; Safety key not in place; Circuit breaker tripped.	Ensure power cord is securely plugged in; Insert safety key fully; Check household circuit breaker.
Running belt slips or hesitates	Belt too loose; Belt needs lubrication.	Adjust belt tension as per maintenance guide; Lubricate the running deck.
Unusual noises during operation	Loose components; Motor issues; Belt friction.	Check all assembly bolts for tightness; Lubricate belt; If noise persists, contact customer support.

Problem	Possible Cause	Solution
Display not working	Loose cable connection; Console malfunction.	Check all console cable connections; If issue persists, contact customer support.

If the problem persists after attempting these solutions, please contact Cultsport customer support.

## 8. PRODUCT SPECIFICATIONS

Detailed technical specifications for the Cultsport C2 Treadmill:

Specification	Value
Brand	CULTSPORT
Model Name	smartrun c2
Colour	Black
Product Dimensions (LxWxH)	1.67D x 0.72W x 1.32H Meters (1670 x 720 x 1320 MM)
Item Weight	60 Kilograms
Material	Stainless Steel (Frame: Alloy Steel)
Maximum Speed	16 Kilometers per Hour
Maximum Horsepower	4 Horsepower (Peak)
Maximum Incline Percentage	15 Levels (Auto Incline)
Maximum Weight Recommendation	120 Kilograms
Running Belt Dimensions (LxW)	1260 x 450 MM
Display Type	LCD
Metrics Measured	Distance, Calories Burned, Time, Speed
Power Source	Corded Electric
Assembly Required	Yes
Included Components	1 Treadmill, Tool Kit, User Manual, Warranty Card
Country of Origin	India

## 9. WARRANTY & SUPPORT

Cultsport is committed to providing excellent customer service and product support.

### 9.1 Warranty Information

- Your Cultsport C2 Treadmill comes with a **1-year manufacturer warranty** on the product. Please refer to the included Warranty Card for full terms and conditions.

### 9.2 Customer Support

- For installation support, technical assistance, or any other queries, please contact Cultsport's active post-sales and customer support.
- **Working hours:** Monday to Saturday from 9 AM to 6 PM.
- Please register your installation after delivery. Service schedule may vary by location.
- Contact details can be found on your Warranty Card or the official Cultsport website.