



[Manuals.plus](#) /

> [METEESER](#) /

> METEESER 10 Inch Android Car Stereo Double Din Instruction Manual

METEESER B0B879LDJ5

METEESER 10 Inch Android Car Stereo Double Din Instruction Manual

Model: B0B879LDJ5

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, maintenance, and troubleshooting of your METEESER 10 Inch Android Car Stereo Double Din. This unit features a 10-inch touch screen, wireless CarPlay and Android Auto compatibility, GPS navigation, WiFi, Hi-Fi sound, FM/RDS radio, and supports a backup camera. Please read this manual thoroughly before use to ensure proper functionality and safety.



Image 2.1: Diagram illustrating the product dimensions and a comprehensive list of included accessories such as power cables, video cables, rear camera, microphone, USB cables, GPS antenna, and mounting brackets.

- Main Head Unit (10-inch display)
- Power Harness
- Mounting Brackets
- GPS Antenna
- CAM-IN Cable (for backup camera)
- RCA Cable
- External Microphone
- USB Cables (x2)
- AHD Backup Camera
- User Manual

2.2 Wiring Diagram

Refer to the wiring diagram below for proper connection of the head unit to your vehicle's electrical system and accessories. Incorrect wiring can cause damage to the unit or vehicle.



Image 2.2: Detailed wiring diagram showing connections for power, USB, GPS, backup camera, WiFi antenna, Bluetooth antenna, microphone, and various audio/video inputs/outputs (AUX, Subwoofer, Video Out).

2.3 Wireless CarPlay/Android Auto Connection

To connect your smartphone wirelessly via CarPlay or Android Auto:

1. Ensure your phone's Bluetooth is enabled.
2. On the car stereo, navigate to the 'Zlink' application.
3. Follow the on-screen prompts to pair your phone via Bluetooth.
4. Once paired, the system will automatically initiate CarPlay or Android Auto.



Image 2.3: Visual guide demonstrating the steps to connect a smartphone for wireless CarPlay or Android Auto functionality, starting with Bluetooth activation and using the Zlink app.

3. OPERATING INSTRUCTIONS

3.1 Touchscreen Interface

The unit features a responsive 10-inch HD touchscreen. Navigate through menus and applications by tapping, swiping, and dragging. Physical buttons on the left side provide quick access to common functions like Reset, Power, Menu, Back, Volume Up, and Volume Down.



Image 3.1: The 10-inch HD touchscreen in operation, highlighting its clarity and responsiveness. Also shown is the RCA video output feature, allowing content to be displayed on external screens.

3.2 Wireless CarPlay and Android Auto

Once connected, CarPlay and Android Auto provide a safe way to use your smartphone's features on the car stereo display. Access navigation, music, calls, and messages via the touch screen or voice commands (Siri/Google Assistant).



Image 3.2: Display of the CarPlay and Android Auto interfaces on the car stereo, demonstrating integration with Siri voice control for hands-free operation.

3.3 GPS Navigation

The unit supports both online and offline navigation. Utilize the built-in offline navigation app (HereWeGo) or connect to WiFi/hotspot to use online map applications.



Image 3.3: The GPS navigation system displaying a route, with satellite imagery in the background, indicating real-time positioning and guidance.

3.4 WiFi Connectivity

Connect the stereo to a WiFi network or mobile hotspot to access online features, browse the internet, stream videos, download apps, and use online navigation.



Image 3.4: The car stereo connected to WiFi, showing various online applications like YouTube, social media, and web browsing, demonstrating its internet capabilities.

3.5 Audio Features (Hi-Fi, EQ, Subwoofer)

Experience high-fidelity sound with adjustable EQ settings (Custom, Classical, Jazz, Rock, Pop) and subwoofer output for enhanced bass. The system is designed for clear and powerful audio.



Image 3.5: The car stereo's audio interface showing Hi-Fi settings, a graphic equalizer with preset options, and an illustration of subwoofer integration for enhanced sound quality.

3.6 Bluetooth

Connect your phone via Bluetooth for hands-free calling and wireless audio streaming. This feature ensures safer driving by allowing you to manage calls and music without handling your device.



Image 3.6: A composite image showing the car stereo's Bluetooth capabilities, including hands-free calling and wireless audio streaming, with a phone displaying a call screen.

3.7 FM/RDS Radio

Tune into your favorite FM radio stations. The RDS (Radio Data System) feature displays station information, song titles, and other relevant data where available.

HiFi / EQ / Subwoofer



Image 3.7: The FM RDS Radio interface on the car stereo, showing frequency tuning and preset station options.

3.8 Rear View Camera

The included AHD backup camera provides a clear reverse image on the stereo display, assisting with parking and maneuvering. The display automatically switches to the camera feed when the vehicle is in reverse.



Image 3.8: The car stereo displaying the feed from the HD rear view camera, showing parking guidelines, alongside an image of the compact camera unit.

3.9 Steering Wheel Control (SWC)

If your vehicle supports it, you can connect the stereo to your car's steering wheel controls. This allows you to manage volume, tracks, and other functions directly from your steering wheel for convenience and safety.



Image 3.9: The car stereo's settings menu for Steering Wheel Control (SWC), showing how to map vehicle steering wheel buttons to stereo functions.

4. MAINTENANCE

4.1 Cleaning the Unit

To clean the touchscreen and unit exterior, use a soft, dry, lint-free cloth. For stubborn smudges, lightly dampen the cloth with water or a screen-safe cleaner. Avoid abrasive materials or harsh chemicals, as these can damage the screen and finish.

4.2 Software Updates

Periodically check the manufacturer's website or contact customer support for available software updates. Updates can improve performance, add new features, or resolve known issues. Follow the provided instructions carefully when performing any software update.

5. TROUBLESHOOTING

If you encounter issues with your car stereo, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not power on.	Incorrect wiring, blown fuse, power supply issue.	Check power connections, inspect vehicle fuses, ensure proper grounding.
No sound or distorted audio.	Speaker wiring issues, incorrect audio settings, volume too low.	Verify speaker connections, adjust volume and EQ settings, check balance/fader.
Touchscreen unresponsive or slow.	Software glitch, excessive background apps, system overload.	Perform a soft reset (press the reset button), close unused applications, clear cache if possible.

Problem	Possible Cause	Solution
Wireless CarPlay/Android Auto not connecting.	Bluetooth not enabled, incorrect pairing steps, phone compatibility.	Ensure Bluetooth is on, re-pair the device via the 'Zlink' app, check phone's OS version.
GPS signal weak or inaccurate.	GPS antenna obstruction, poor satellite reception.	Ensure GPS antenna is correctly installed and has a clear view of the sky.
USB ports not charging devices.	Insufficient power output, cable issue, device incompatibility.	USB ports are primarily for data transfer. Charging capabilities may be limited for some devices. Use a dedicated car charger for optimal charging.

6. SPECIFICATIONS

Key technical specifications for the METEESER 10 Inch Android Car Stereo:

- **Brand:** METEESER
- **Model:** B0B879LDJ5
- **Screen Size:** 10 Inches
- **Resolution:** 1024 x 600
- **Operating System:** Android (Version 9.1 indicated in some visuals)
- **Processor:** 4 Core
- **RAM:** 2 GB
- **Internal Storage (ROM):** 32 GB
- **Control Method:** Touchscreen
- **Product Dimensions (L x W x H):** 5.71" x 1.77" x 9.45" (145mm x 45mm x 240mm approx.)
- **Vehicle Service Type:** Car
- **Connectivity:** Wireless CarPlay, Android Auto, Bluetooth, WiFi, GPS
- **Radio:** FM/RDS
- **Audio Output:** Hi-Fi, Subwoofer output
- **Input/Output:** USB (x2), RCA Video Output, Rear Camera Input, External Mic Input

7. WARRANTY AND SUPPORT

7.1 Warranty Information

For specific warranty terms and conditions, please refer to the warranty card included with your product or contact the seller directly. Keep your purchase receipt as proof of purchase for any warranty claims.

7.2 Customer Support

If you require further assistance, have questions, or encounter issues not covered in this manual, please contact METEESER customer support through the retailer where you purchased the product or visit the official METEESER store page for contact information.

METEESER Store: [Visit Store](#)

© 2024 METEESER. All rights reserved.