

VEVOR 450W 0.6HP Inflatable Blower

VEVOR 450W 0.6HP Inflatable Air Blower Instruction Manual

Model: 450W 0.6HP Inflatable Blower

1. INTRODUCTION

Thank you for choosing the VEVOR 450W 0.6HP Inflatable Air Blower. This powerful and portable air blower is designed to quickly inflate various inflatable items such as bounce houses, water slides, obstacle courses, and paint booths. Please read this manual carefully before operation to ensure safe and efficient use of the product.

2. SAFETY INSTRUCTIONS

Always prioritize safety when operating electrical equipment. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the power supply matches the blower's requirements (110V-120V AC/60Hz). Do not operate with a damaged cord or plug.
- **Water Exposure:** The switch has a transparent hood for protection against water splashes, but avoid submerging the blower or operating it in heavy rain.
- **Ventilation:** Keep the air intake and outlet clear of obstructions to prevent overheating.
- **Children and Pets:** Keep children and pets away from the blower during operation. The blower features plastic meshes over vents to prevent accidental contact with moving parts.
- **Stable Placement:** Always place the blower on a stable, level surface. Use the provided ground nails to secure it if necessary, especially outdoors.
- **Storage:** Store the blower in a dry, secure location when not in use.

SECURE PROTECTION DESIGN

Ensure security for long time running




Image: The VEVOR air blower features a protective switch with a transparent cover and two plastic meshes over the vents for enhanced safety.

3. PRODUCT OVERVIEW

The VEVOR 450W 0.6HP Inflatable Air Blower is a compact and powerful device designed for various inflatable applications. It features a durable PP plastic casing and a robust motor for efficient inflation.

Components:

- Air Blower Unit
- Power Cord (6.6 ft long)
- Ground Nails (for securing the unit)



Image: The VEVOR air blower is ideal for inflating various items indoors and outdoors.



Image: The blower features an easy-grip handle for convenient carrying and transportation.

4. SPECIFICATIONS

Feature	Specification
Power	450W
Horsepower	0.6 HP
Input Voltage	110V-120V AC/60Hz
Air Volume	450 m³/h
Outlet Diameter	4.1 in / 10.5 cm
Net Weight	7.7 lbs / 3.5 kg
Product Dimensions (L x W x H)	13.8 x 8.5 x 14.6 in / 35 x 21.5 x 37 cm
Noise Level	60dB
Material	PP Plastic

PRODUCT SPECIFICATIONS:

VEVOR®

Net Weight: 7.7 lbs / 3.5 kg

Product Size: 13.8 x 8.5 x 14.6 in / 35 x 21.5 x 37 cm



Image: Key dimensions of the VEVOR air blower.

5. SETUP

Setting up your VEVOR air blower is a simple three-step process:

1. **Step 1: Position the Blower.** Place the air blower on a flat, stable surface near the inflatable item. For outdoor use, secure the blower to the ground using the provided ground nails through the designated holes in the base.
2. **Step 2: Connect the Inflatable.** Link the inflation tube of your inflatable item to the air blower's outlet. Ensure a tight and secure connection to prevent air leakage.
3. **Step 3: Power On.** Plug the power cord into a suitable electrical outlet. Press the power switch to the 'ON' position to begin inflation.



Image: Easy operation steps for the VEVOR air blower.

6. OPERATING INSTRUCTIONS

Once set up, operating the VEVOR air blower is straightforward:

- **Continuous Operation:** The blower is designed for continuous operation to keep your inflatable fully inflated.
- **Monitoring:** Periodically check the inflatable for proper inflation and ensure the blower's air intake and outlet remain unobstructed.
- **Noise Level:** The blower operates at approximately 60dB, which is a moderate noise level. Consider placement to minimize disturbance.
- **Power Off:** To deflate the item, simply switch the power button to the 'OFF' position and unplug the unit.

7. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your air blower:

- **Cleaning:** Keep the exterior of the blower clean. Wipe with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Air Vents:** Regularly inspect and clean the air intake and outlet vents to remove any dust, debris, or obstructions that could hinder airflow.
- **Power Cord:** Check the power cord for any signs of damage (fraying, cuts). If damaged, discontinue use and replace it immediately.
- **Storage:** When not in use, store the blower in a cool, dry place, away from direct sunlight and extreme temperatures.

8. TROUBLESHOOTING

If you encounter issues with your VEVOR air blower, refer to the following common troubleshooting steps:

- **Blower Not Starting:**
 - Ensure the power cord is securely plugged into a working outlet.
 - Check if the power switch is in the 'ON' position.
 - Verify that the electrical outlet is functional by plugging in another device.
- **Low Airflow:**
 - Check for any obstructions in the air intake or outlet vents.
 - Ensure the connection between the blower and the inflatable is tight and free of leaks.
 - Confirm the inflatable item is not too large for the blower's capacity.
- **Unusual Noise or Vibration:**
 - Turn off the blower immediately.
 - Inspect for any foreign objects inside the blower or obstructing the impeller.
 - If the issue persists, contact customer support.

9. WARRANTY

This VEVOR Inflatable Air Blower comes with a **2-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects and malfunctions under normal use conditions. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper maintenance.

10. SUPPORT

For technical assistance, warranty claims, or any questions regarding your VEVOR Inflatable Air Blower, please contact VEVOR Customer Service. Refer to the contact information provided on the product packaging or the official VEVOR website.

Online Support: Visit the official VEVOR website for FAQs, troubleshooting guides, and contact options.

Email Support: Available for detailed inquiries and technical assistance.