

## LENRUE A38S

# LENRUE Computer Speakers Instruction Manual

Model: **A38S** | Brand: **LENRUE**

## INTRODUCTION

Thank you for choosing LENRUE Computer Speakers. These USB/USB-C powered speakers are designed to provide clear stereo sound for your desktop, laptop, iMac, or MacBook. Featuring convenient plug-and-play functionality, a headphone output jack, and touch-controlled atmospheric lighting, they enhance your audio experience for gaming, music, movies, and more.



Image: Front view of LENRUE Computer Speakers with colorful LED lighting.

## WHAT'S INCLUDED

---

- 1 × Computer Speakers
- 1 × Type C Adapter
- 1 × Manual

## SETUP INSTRUCTIONS

---

### 1. Power and Audio Connection:

Connect the USB cable from the speakers to an available USB port on your computer, laptop, or monitor for power. If your device only has USB-C ports, use the included USB-C to USB adapter.



Image: Connecting the speakers using the USB-C to USB adapter.



Plug the 3.5mm audio jack into your device's headphone or audio output port. The speakers are plug-and-play, requiring no additional drivers.



Image: Speakers connected to a laptop, demonstrating the simple plug-and-play setup.

## 2. **Speaker Placement:**


Place the speakers on either side of your monitor or laptop. The 37-inch cable between the desktop speakers allows for flexible positioning to achieve optimal stereo sound.

## OPERATING INSTRUCTIONS

### 1. **Volume Control:**

The speakers feature a rotary knob for easy volume adjustment. Rotate the knob clockwise to increase volume and counter-clockwise to decrease it. This knob also serves as the power on/off switch.

Windows (Vista / 7 / 8 / 10), Mac OS, Chrome OS, Linux, UNIX



## NO NEED ANY DRIVER

Match with most systems, just plug and listen you want



Image: Speakers positioned for stereo sound, showing the rotary volume control knob.

### 2. Atmospheric Lighting:

The speakers are equipped with touch-controlled cyclic lights. Simply touch the designated button on the speaker to turn the lights on or off, adding to your setup's ambiance.

# Touch Breathing Light



Touch turn on/off



Image: Speakers demonstrating the touch-controlled breathing light feature.

Your browser does not support the video tag.

Video: Demonstration of the touch-controlled lights on the computer speakers.

### 3. Headphone Output Jack:

A 3.5mm headphone jack is integrated into the speakers, allowing you to connect your headphones for private listening without disturbing others. This jack is designed to be noiseless for a clear audio experience.



# Headphone Jack



Image: Close-up of the headphone jack on the speaker, with headphones connected.

## MAINTENANCE

- Keep the speakers clean by wiping them with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- Do not expose the speakers to extreme temperatures, humidity, or direct sunlight.
- Ensure proper ventilation around the speakers to prevent overheating.
- Avoid dropping or subjecting the speakers to strong impacts.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No sound from speakers	Incorrect audio connection. Volume too low or muted. Speakers not powered. Incorrect audio output selected on device.	Ensure 3.5mm audio jack is fully inserted into the correct port. Turn the rotary volume knob clockwise to increase volume. Check device's master volume. Verify USB power cable is securely connected to a working USB port. Check your computer's sound settings to ensure the speakers are selected as the default output device.
LED lights not working	Lights are turned off. Power issue.	Touch the light control button on the speaker to cycle through modes or turn on. Ensure speakers are receiving power via USB.
Static or distorted sound	Volume too high. Interference from other devices. Loose connection.	Reduce the volume on both the speakers and your device. Move speakers away from other electronic devices that may cause interference. Ensure all cables are securely connected.
Only one speaker working	Cable issue between speakers. Device audio settings.	Check the cable connecting the two speakers for damage or loose connections. Verify your device's audio balance settings are centered.

## SPECIFICATIONS

Feature	Detail
Brand	LENRUE
Model Name	1059
Item Model Number	A38S
Speaker Type	Surround Sound (2.0 Channel Configuration)
Connectivity Technology	Auxiliary, USB
Power Source	Corded Electric (USB Plug, DC 5V, 2A Max)
Audio Output Mode	Stereo
Speaker Maximum Output Power	10 Watts
Control Method	Touch (for lights), Knob (for volume)
Special Features	USB & AUX, USB C Adapter, Headphone Jack, Touch Lights
Compatible Devices	Desktop, Laptop, Tablet, PC (Windows, Mac OS, Chrome OS, Linux, UNIX)
Product Dimensions	1"D x 1"W x 1"H

Feature	Detail
Item Weight	1.37 pounds (21.86 Ounces)
Material	Plastic

## WARRANTY AND SUPPORT

For any product inquiries, technical support, or warranty claims, please contact LENRUE customer service through the platform where you purchased the product. Please refer to your purchase receipt for specific warranty details.

You can also visit the official LENRUE store on Amazon for more information and support:[LENRUE Amazon Store](#)