

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Etekcity](#) /
- › [Etekcity Food Kitchen Scale EKS-C193-KUS Instruction Manual](#)

## Etekcity EKS-C193-KUS

# Etekcity Food Kitchen Scale EKS-C193-KUS Instruction Manual

### IMPORTANT SAFEGUARDS

---

To ensure safe and optimal use of your Etekcity Food Kitchen Scale, please read and follow all instructions carefully. Keep this manual for future reference.

- Do not use this scale for commercial purposes. It is intended for household use only.
- Place the scale on a hard, flat surface to ensure accurate readings. Avoid soft surfaces like carpets.
- Do not immerse the scale in water or any other liquid. If liquid spills on the scale, wipe it immediately with a soft, damp cloth.
- Avoid exposing the scale to extreme temperatures, direct sunlight, or high humidity.
- Handle the scale with care. Do not drop it or subject it to strong impacts, as this may damage the internal components.
- Do not mix new and used batteries. Replace all batteries at the same time.
- Keep the scale out of reach of children.

### PACKAGE CONTENTS

---

- 1 x Digital Kitchen Scale
- 1 x Quick Start Guide
- 2 x AAA batteries

### SPECIFICATIONS

---

Feature	Detail
Max. Weight	176 oz / 5000 g / 11 lbs
Min. Weight	2g
Units	g / oz / lb:oz / ml (Milk & Water) / fl'oz (Milk & Water)

Increments	1 g
Auto-off	3 Minutes
Power	2 x AAA Batteries (included)
Dimensions	7.2 x 5.7 x 0.7 inches
Material	Plastic
Display Type	LCD with Backlit Display

## PRODUCT OVERVIEW

The Etekcitcity Food Kitchen Scale EKS-C193-KUS is designed for precise measurements in various kitchen tasks, from baking to meal prep. Its compact and sleek design makes it easy to store and clean.

### Reliable Accuracy

No matter what you're making, easily measure items from 2–5,000 grams in 1-gram increments.



**Figure 1:** The Etekcitcity Food Kitchen Scale showing a precise measurement of 64 grams for sliced avocado, highlighting its reliable accuracy for various ingredients.

## SETUP

1. **Battery Installation:** Open the battery compartment on the underside of the scale. Insert the 2 AAA batteries, ensuring correct polarity (+/-). Close the compartment securely.
2. **Placement:** Place the scale on a hard, flat, and stable surface. Uneven surfaces can affect accuracy.

## OPERATING INSTRUCTIONS

---

### 1. Power On/Off

- Press the **Z/T ON/OFF** button to turn the scale on. The display will show '0' when ready.
- To turn off, press and hold the **Z/T ON/OFF** button for a few seconds. The scale also features an automatic shut-off after 3 minutes of inactivity to conserve battery life.

### 2. Unit Conversion

The scale supports multiple units for versatile measuring:

- Grams (g)
- Ounces (oz)
- Pounds:Ounces (lb:oz)
- Milliliters (ml) for Milk & Water
- Fluid Ounces (fl'oz) for Milk & Water

To switch between units, press the **UNIT** button repeatedly until your desired unit is displayed.

## 5 Measuring Units

Weigh any ingredient, including water and milk, with 5 convenient units.



**Figure 2:** The scale's display showing 8.15 fluid ounces of milk, illustrating the ease of switching between 5 convenient measurement units.

### 3. Tare Function

The Tare function allows you to subtract the weight of a container or previous ingredients, enabling you to measure multiple items in the same bowl accurately.

1. Place an empty container on the scale.
2. Press the **Z/T ON/OFF** button. The display will reset to '0'.
3. Add your first ingredient to the container. The scale will display its weight.
4. To add another ingredient, press the **Z/T ON/OFF** button again to reset the display to '0', then add the next ingredient. Repeat as needed.

# Tare Function




Figure 3: Step-by-step visual guide on using the Tare function to accurately weigh ingredients in a container.

## 4. Weighing Items

Simply place the item directly onto the scale's platform. The weight will be displayed in the currently selected unit. For items requiring a container, use the Tare function as described above.

## Nice & Bright

Easily read your results on the backlit LCD display.



**Figure 4:** The bright backlit LCD display clearly shows the weight of blueberries, ensuring easy readability in any lighting condition.

### 5. Product Demonstration Video

**Video 1:** An official product demonstration video showcasing the key features and operation of the Etekcity Food Kitchen Scale.

## MAINTENANCE

---

### 1. Cleaning


The scale features a slick surface that is easy to clean. Wipe the scale with a soft, damp cloth. Do not use abrasive cleaners or immerse the scale in water.

### 2. Storage

With its compact dimensions (7.2 x 5.7 x 0.7 inches), the scale can be easily stored on your countertop, in a drawer, or hung on a hook.

## Store It Anywhere

The slim design makes it easy to store the scale on your countertop or in a drawer.



**Figure 5:** The slim design of the Etekcity Food Kitchen Scale allows for convenient storage in various kitchen spaces, such as on a countertop or inside a drawer.

## TROUBLESHOOTING

---

- **Inaccurate Readings:** Ensure the scale is on a hard, flat surface. Avoid placing it near electronic devices that may cause interference. Recalibrate if necessary (refer to quick start guide for specific steps).
- **"Lo" Display:** This indicates low battery. Replace both AAA batteries with new ones.
- **"Err" Display:** This indicates an overload. Remove items from the scale immediately to prevent damage. The maximum weight capacity is 11 lbs / 5000 g.
- **Display Not Turning On:** Check battery installation and ensure batteries are not depleted.

## WARRANTY AND SUPPORT

---

Etekcity provides a 1-year warranty for this product. For any questions, concerns, or support needs, please contact Etekcity customer service. Refer to the Quick Start Guide for contact information or visit the official Etekcity website.

**Etecity Customer Support:** [Visit the Etecity Store on Amazon](#)