

## ANALOI SG5

# ANALOI SG5 Kids Alarm Clock User Manual

Model: SG5

## 1. PRODUCT OVERVIEW

The ANALOI SG5 Kids Alarm Clock is designed to assist children in developing healthy sleep habits through visual cues, soothing sounds, and customizable lighting. This device combines an alarm clock, night light, and sound machine into one child-friendly unit.

## 2. PACKAGE CONTENTS

- 1 x ANALOI SG5 Kids Alarm Clock
- 1 x USB Type-C Charging Cable
- 1 x User Manual

## 3. PRODUCT DIAGRAM



Figure 1: Rear view of the alarm clock with labeled control buttons.



Figure 2: Front view of the alarm clock showing the digital display and ambient light.



Figure 3: Overview of key features including dual alarms, snooze, sleep trainer, ambient light, soothing sounds, timer, memory battery, and safe material.



Figure 4: Product dimensions and power specifications.

## 4. SETUP INSTRUCTIONS

### 4.1 Initial Charging

Before first use, fully charge the alarm clock using the provided USB Type-C cable. Connect the cable to the Type-C port on the back of the device and plug the other end into a compatible 5V/1A USB power adapter (not included). The battery indicator on the display will show charging status.

### 4.2 Power On/Off

To power on the device, long press the **Power** button (usually indicated by a circle with a vertical line) on the back panel. Long press again to power off.

### 4.3 Setting Time

1. Short press the **Time** button (clock icon) on the back panel. The hour digits will flash.
2. Use the **+** and **-** buttons to adjust the hour.
3. Short press **Time** again to switch to minute adjustment. Use **+** and **-** to set minutes.
4. Short press **Time** one more time to confirm and exit time setting.



## 5. OPERATING INSTRUCTIONS

### 5.1 Setting Alarms (Alarm 1 & Alarm 2)

The clock supports two independent alarms.

1. **To set Alarm 1:** Long press the **Alarm 1** button (bell icon with '1'). The hour digits for Alarm 1 will flash.
2. Use **+** and **-** to adjust the hour.
3. Short press **Alarm 1** again to switch to minute adjustment. Use **+** and **-** to set minutes.
4. Short press **Alarm 1** to confirm. The alarm icon will appear on the display, indicating it's active.
5. **To set Alarm 2:** Follow the same steps using the **Alarm 2** button (bell icon with '2').
6. **To turn an alarm On/Off:** Short press the corresponding **Alarm 1** or **Alarm 2** button. The alarm icon will appear or disappear from the display.




Figure 5: Setting Alarm 1, Alarm 2, and the Timer function.

### 5.2 Sleep Training Function (Ok to Wake / Go to Bed)

This feature uses visual light cues to help children understand when it's appropriate to wake up or go to sleep.

1. **Setting Sun Time (Wake-up):** Long press the **Sun/Moon** button (sun and moon icon). The sun icon will flash. Use **+** and **-** to set the desired wake-up hour (e.g., 06:00 - 18:59).
2. **Setting Moon Time (Bedtime):** Short press **Sun/Moon** again. The moon icon will flash. Use **+** and **-** to set the desired bedtime hour (e.g., 19:00 - 05:59).
3. Short press **Sun/Moon** to confirm.

When the set wake-up time arrives, the clock will display a flashing sun icon and illuminate with a green light, signaling it's okay to get out of bed. At bedtime, a flashing moon icon and a red light will appear, indicating it's time to go to sleep.



Figure 6: Visual cues for sleep training, showing green light for wake-up and red light for bedtime.

### 5.3 Night Light Function

The clock features 5 lighting modes and adjustable brightness.

1. **To turn on/off and cycle through light modes:** Short press the **Light** button (light bulb icon) on the back panel. Each press cycles through different colors (Cyan-Blue, Warm White, White, Color Loop, Blue-Pink) and breathing light modes.
2. **To adjust brightness:** Use the **+** and **-** buttons when a light mode is active to increase or decrease brightness (0% to 100%).



## 5.4 Sound Machine Function

The clock offers 7 soothing sounds to aid sleep.

1. **To play/pause and cycle through sounds:** Short press the **Sound** button (music note icon) on the back panel. Each press cycles through the 7 available sounds (Bird, Piano1, Cricket, Piano2, Music Box, Wave, Piano3).
2. **To adjust volume:** Use the **+** and **-** buttons when a sound is playing to increase or decrease the volume.



Figure 8: Selection of 7 soothing sounds and volume adjustment.

## 5.5 Snooze Function

When an alarm sounds, short press the **Snooze** button (Zz icon on top). The alarm will temporarily silence for 9 minutes, and the Zz icon will flash on the display. This can be repeated up to 3 times.





Figure 9: Activating the snooze function by pressing the top button.

## 5.6 Timer Function

The clock includes a timer function for various activities.

1. Long press the **Timer** button (hourglass icon) on the back panel.
2. Use **+** and **-** to set the desired countdown duration (e.g., 15, 30, or 60 minutes).
3. Short press **Timer** to start the countdown. The timer icon will appear on the display.
4. To cancel the timer, long press the **Timer** button again.

## 6. MAINTENANCE

### 6.1 Cleaning

Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.

### 6.2 Battery Care

The device has a built-in memory battery to retain settings during power outages or when unplugged. For optimal battery life, avoid fully discharging the battery frequently. Recharge when the low battery indicator appears.

## 7. TROUBLESHOOTING

- **Clock not turning on:** Ensure the device is fully charged. Connect to a power source using the USB Type-C cable.
- **Alarm not sounding:** Verify that the alarm is enabled (alarm icon visible on display) and the volume is not set to zero. Check that the alarm time is correctly set.
- **Sleep training lights not changing:** Confirm that the Sun Time and Moon Time are correctly configured. Ensure the clock is powered on.
- **Display is too dim/bright:** Adjust the brightness using the+ and - buttons when a light mode is active.

## 8. SPECIFICATIONS

Brand	ANALOI
Model Number	SG5
Display Type	Digital
Special Features	Alarm, Mood Light, Noise Machine, Timer, Sleep Training
Product Dimensions	4.72"W x 4.92"H
Power Source	Corded Electric (USB Type-C)
Material	Plastic
Item Weight	9.9 ounces (0.62 Pounds)
Batteries	1 Lithium Polymer battery required (built-in)

## 9. WARRANTY & SUPPORT

The ANALOI SG5 Kids Alarm Clock comes with a 24-month warranty from the date of purchase. For warranty claims, technical support, or any product-related inquiries, please contact ANALOI customer service through the retailer's platform or the official ANALOI website. Please retain your proof of purchase for warranty validation.

## 10. PRODUCT VIDEO DEMONSTRATION

Your browser does not support the video tag.

*Video 1: Official product overview of the ANALOI Kids Alarm Clock, demonstrating its features and functionality.*

