

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VEVOR](#) /

› [VEVOR 5.3 Gallon 1.6 Peak HP 4-in-1 Wet/Dry Shop Vacuum Instruction Manual](#)

VEVOR 5.3 Gallon Wet Dry Vac

VEVOR 5.3 Gallon 1.6 Peak HP 4-in-1 Wet/Dry Shop Vacuum Instruction Manual

Model: 5.3 Gallon Wet Dry Vac | Brand: VEVOR

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, setup, and maintenance of your VEVOR 5.3 Gallon 1.6 Peak HP 4-in-1 Wet/Dry Shop Vacuum. This versatile appliance is designed for dry vacuuming, wet vacuuming, blowing, and spray cleaning, making it suitable for various cleaning tasks in homes, workshops, and vehicles. Please read this manual thoroughly before initial use and retain it for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, or injury. Read all instructions before using this vacuum cleaner.

- **Electrical Safety:** Always connect to a properly grounded outlet. Do not modify the plug. Do not use with a damaged cord or plug. Keep the power cord away from heated surfaces.
- **General Operation:** Do not leave the appliance unattended when plugged in. Unplug from outlet when not in use and before servicing. Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- **Liquid Handling:** Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present. Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- **Filter Usage:** Always ensure the correct filter is installed for the task (HEPA filter for dry, sponge filter for wet) to prevent damage to the motor and ensure effective cleaning.
- **Maintenance:** Perform maintenance only when the vacuum is unplugged. Ensure all latches are securely fastened before operation.

PACKAGE CONTENTS

Carefully unpack the box and ensure all items are present and in good condition. If any items are missing or damaged, contact VEVOR customer service.



Image: The VEVOR 4-in-1 Wet/Dry Shop Vacuum shown with its main unit, hose, extension wand, floor brush, and various attachments including crevice tool, round brush, spray brush, carpet brush, and duckbill brush.

- Main Vacuum Unit (5.3 Gallon Tank)
- Hose (5 ft)
- Extension Wand
- Floor Brush
- Crevice Tool
- Round Brush
- Spray Brush
- Carpet Brush
- Duckbill Brush
- HEPA Filter
- Sponge Filter

- Detergent Tank (1.1 Gallon)
- Power Cord (14.8 ft)
- User Manual

SETUP

Follow these steps to assemble your VEVOR Wet/Dry Shop Vacuum before first use.

PORTABLE FOR OPERATION

Don't waste time on the way of back and forth



Image: A detailed diagram illustrating the various components and features of the VEVOR shop vacuum, including its carry handle, power switch, cord wrap, blower port, latches, vacuum port, swivel wheels, power cord, hose, and control button.

1. **Attach Wheels:** Invert the main unit and securely attach the 360° swivel wheels to the base. Ensure they click into place or are fastened according to the specific model's design.
2. **Connect Hose:** Insert the larger end of the hose into the vacuum port on the front of the main unit. Twist to secure it firmly.

3. Install Filters:

- For **Dry Vacuuming**: Ensure the HEPA filter is properly installed over the motor cage inside the tank.
- For **Wet Vacuuming**: Remove the HEPA filter and install the sponge filter over the motor cage.

4. **Attach Detergent Tank (for Spray Function)**: If using the spray function, fill the removable 1.1-gallon detergent tank with appropriate cleaning solution and attach it to the designated port on the side of the main unit. Connect the small clear tube from the detergent tank to the spray nozzle connection point on the vacuum.

5. **Connect Attachments**: Attach the desired extension wand and cleaning brush (e.g., floor brush, carpet brush, crevice tool) to the end of the hose.

6. **Power Connection**: Unwind the 14.8 ft power cord and plug it into a grounded electrical outlet.

OPERATING INSTRUCTIONS

Your VEVOR Wet/Dry Shop Vacuum offers four distinct cleaning modes.



Image: A visual representation of the vacuum's four modes: dry cleaning for debris, wet cleaning for liquids, blowing for leaves, and

spraying for deep cleaning, accompanied by images of the spray brush, carpet brush, duckbill brush, round brush, and floor brush.

General Operation

- Ensure the vacuum is properly assembled and plugged in.
- Turn the ON/OFF switch located on the top of the unit to the 'ON' position to start the motor.
- To stop operation, turn the switch to the 'OFF' position.

1. Dry Vacuuming

Use this mode for picking up dry debris, dust, and dirt.

1. Ensure the HEPA filter is installed.
2. Attach the appropriate dry cleaning brush (e.g., floor brush, round brush) to the hose.
3. Turn on the vacuum and move the attachment over the area to be cleaned.

2. Wet Vacuuming

Use this mode for picking up liquids and wet messes.

1. Remove the HEPA filter and install the sponge filter.
2. Attach a suitable wet pickup tool (e.g., squeegee attachment on the floor brush).
3. Turn on the vacuum and move the attachment over the liquid. The tank has a maximum fill line; do not overfill.

3. Blower Function

The vacuum can be used to blow away debris from hard-to-reach areas.

1. Disconnect the hose from the vacuum port.
2. Insert the hose into the blower port located on the top of the unit.
3. Turn on the vacuum to activate the blower.

4. Spray Function

This mode allows for applying cleaning solution and then vacuuming it up for deep cleaning.

1. Ensure the sponge filter is installed.
2. Fill the detergent tank with the appropriate cleaning solution.
3. Attach the spray brush or carpet brush to the hose.
4. Turn on the vacuum. Press the touch button on the handle to activate the spray function, applying solution to the surface.
5. Release the button and move the brush over the wet area to vacuum up the dirty solution.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your vacuum.

DUAL-LAYER FILTRATION

Large capacity tank for one-shot cleaning without repeat pouring



Image: An illustration highlighting the vacuum's dual-layer filtration system, featuring both a HEPA filter for dry debris and a sponge filter for wet applications. It also shows the large 5.3-gallon dust tank and the separate 1.1-gallon detergent tank.

Emptying the Tank

1. Unplug the vacuum from the power outlet.
2. Release the latches on the sides of the main unit and carefully lift off the motor head.
3. For dry debris, empty the dust tank into a waste receptacle. For wet waste, pour the liquid into a drain.
4. Clean the inside of the tank with water and mild detergent if necessary, then dry thoroughly before reassembly.

Filter Cleaning and Replacement

- **HEPA Filter:** For dry use, tap off loose dirt. If heavily soiled, rinse under running water and allow to air dry completely (24-48 hours) before reinstallation. Replace if damaged or if suction significantly decreases after cleaning.
- **Sponge Filter:** For wet use, rinse thoroughly with water and allow to air dry completely before storing or reusing.

Detergent Tank

- After using the spray function, empty any remaining cleaning solution from the 1.1-gallon detergent tank.
- Rinse the tank and spray nozzle thoroughly with clean water to prevent clogging.

Hose and Attachments

- Inspect the hose and attachments regularly for blockages or damage. Clear any obstructions.
- Wipe down attachments with a damp cloth.

TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on	No power supply; ON/OFF switch in 'OFF' position; Damaged power cord.	Check power outlet; Ensure switch is 'ON'; Inspect cord for damage, contact service if damaged.
Loss of suction	Tank is full; Filter is clogged; Hose or attachment is blocked; Improperly sealed lid.	Empty tank; Clean or replace filter; Clear blockages; Ensure lid latches are secure.
Water leaking from unit	Tank is overfilled during wet vacuuming; Lid not properly sealed; Damaged tank or hose.	Do not exceed max fill line; Ensure lid latches are secure; Inspect for damage, contact service if needed.
Spray function not working	Detergent tank empty; Spray nozzle clogged; Detergent tube disconnected.	Refill detergent tank; Clean spray nozzle; Reconnect detergent tube securely.
Blower function weak	Hose not securely connected to blower port; Obstruction in hose.	Ensure hose is firmly in blower port; Clear any blockages in hose.

SPECIFICATIONS

Detailed technical specifications for the VEVOR 5.3 Gallon Wet Dry Vac.

PRODUCT SPECIFICATIONS: **VEVOR**®

Item Weight: 15.4 lbs / 7 kg

Product Size: 16.1 × 14.2 × 20.5in / 41 × 36 × 52cm



Image: A diagram illustrating the physical dimensions of the VEVOR shop vacuum, including its height (20.5 inches / 52 cm), width (14.2 inches / 36 cm), and length (16.1 inches / 41 cm). The extension wand length (19.7-31.5 inches / 50-80 cm) is also shown, along with icons suggesting its use for sofas, cars, and floors.

Feature	Specification
Brand	VEVOR
Model Number	5.3 Gallon Wet Dry Vac
Capacity (Dust Tank)	5.3 Gallons
Capacity (Detergent Tank)	1.1 Gallons
Motor Horsepower	1.6 Peak HP
Wattage	1200 Watts
Amperage	10.9 Amps
Suction Power	>17 kPa

Feature	Specification
Water Flow (Spray Mode)	Max. 800 L/min
Noise Level	68.0 Decibels
Hose Length	5 Feet
Power Cord Length	14.8 Feet
Product Dimensions	16.1 x 14.2 x 20.5 inches
Filter Type	HEPA, Sponge
Special Features	Portable, Waterproof, Wet/Dry/Blow/Spray, Wheels
Power Source	Corded Electric

WARRANTY AND SUPPORT

VEVOR products are designed for durability and performance. For warranty information, please refer to the warranty card included with your purchase or visit the official VEVOR website. If you encounter any issues or require technical assistance, please contact VEVOR customer support through their official channels. Have your model number and purchase date ready when contacting support.