



Manuals.plus /

- › Better Homes & Gardens /
- › Better Homes & Gardens Dual Power Portable Circulator Fan User Manual

## Better Homes & Gardens BHS136111442001

# Better Homes & Gardens Dual Power Portable Circulator Fan User Manual

Model: BHS136111442001

## 1. INTRODUCTION

---

Thank you for purchasing the Better Homes & Gardens Dual Power Portable Circulator Fan, Model BHS136111442001. This manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your new fan. Please read this manual thoroughly before using the product and retain it for future reference.

This portable fan is designed to provide efficient airflow and cooling in various settings, including homes, offices, and outdoor environments. Its compact and lightweight design ensures convenient portability.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this fan.
- Use this fan only as described in this manual. Other uses not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- To reduce the risk of fire or electric shock, do not expose this fan to water or rain.
- Never insert fingers or any other objects through the grille when the fan is in operation.
- Unplug the fan from the power source when moving it from one location to another, and before cleaning.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- Always place the fan on a stable, flat surface to prevent it from tipping over.
- This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric

shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

### 3. PRODUCT FEATURES

---

- **Powerful Performance:** Enjoy a refreshing breeze anywhere with this portable fan. Its powerful motor ensures constant airflow and effective cooling thanks to its 3 speeds.
- **Convenient Portability:** Designed to be compact and lightweight, this fan is perfect to take with you anywhere. Ideal for use at home, office or outdoor activities.
- **Adjustable Speed Control:** Adjust the fan speed according to your needs. From a gentle breeze to more intense cooling, you can adapt it to different climates and personal preferences.
- **Quiet Operation:** Enjoy a quiet environment while cooling off. This fan operates quietly, preventing hearing discomfort while providing refreshing relief.
- **Durable & Safe Construction:** Made with high-quality materials, this fan is designed for a long service life. In addition, it features a safety grid that protects your fingers and offers additional peace of mind during use.

### 4. SETUP

---

1. **Unpacking:** Carefully remove the fan from its packaging. Retain the packaging for storage or if the product needs to be returned.
2. **Placement:** Place the fan on a firm, level surface. Ensure there is adequate space around the fan for proper air circulation. Avoid placing it near curtains or other objects that could obstruct the airflow or get caught in the fan blades.
3. **Power Connection:**

This fan supports dual power: corded electric and batteries. For corded operation, insert the power adapter into the DC input port on the back of the fan, then plug the adapter into a standard electrical outlet. Ensure the voltage matches the fan's requirements.



Figure 4.1: Power input port on the back of the fan. The image shows a black power cord connected to the circular DC input port, with "9V DC IN" text visible nearby, indicating the power specification.

For battery operation, ensure compatible batteries (not included) are correctly installed in the designated battery compartment (if applicable, based on product design, as "Batteries" is listed as a power source). Refer to the battery compartment markings for correct polarity.

## 5. OPERATING INSTRUCTIONS

---

The fan features intuitive controls for ease of use.



Figure 5.1: Front view of the fan, showing the grille, central logo, and control panel with power and speed indicator lights at the top right.

1. **Power On/Off:** Press the power button (usually marked with a symbol) located on the control panel to turn the fan on or off.
2. **Adjusting Fan Speed:** This fan offers 3 speed settings. Each press of the power button will cycle through the speeds (Low, Medium, High) and then off. Indicator lights on the control panel will illuminate to show the current speed setting.
3. **Portability:** The fan is designed with a convenient handle for easy carrying.



Figure 5.2: A hand gripping the integrated handle on the top edge of the fan, demonstrating its portability.

## 6. MAINTENANCE

---

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your fan.

1. **Before Cleaning:** Always unplug the fan from the power outlet before cleaning or performing any maintenance.
2. **Cleaning the Exterior:** Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents, as these may damage the finish.
3. **Cleaning the Grille and Blades:** Use a vacuum cleaner with a brush attachment or a soft, dry cloth to gently remove dust and debris from the front and rear grilles and the fan blades. Do not attempt to disassemble the fan to clean the blades directly unless specified by the manufacturer.
4. **Storage:** When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

## 7. TROUBLESHOOTING

---

If your fan is not operating correctly, please refer to the following troubleshooting guide before contacting customer support.

Problem	Possible Cause	Solution
Fan does not turn on.	<ul style="list-style-type: none"> <li>◦ Not plugged in.</li> <li>◦ No power at outlet.</li> <li>◦ Batteries are depleted or incorrectly installed.</li> </ul>	<ul style="list-style-type: none"> <li>◦ Ensure the power cord is securely plugged into a working outlet.</li> <li>◦ Check the circuit breaker or try another outlet.</li> <li>◦ Replace batteries or ensure they are inserted with correct polarity.</li> </ul>
Weak airflow.	<ul style="list-style-type: none"> <li>◦ Fan speed set too low.</li> <li>◦ Grille is obstructed or dirty.</li> </ul>	<ul style="list-style-type: none"> <li>◦ Increase the fan speed setting.</li> <li>◦ Clean the front and rear grilles to remove dust and debris.</li> </ul>
Unusual noise.	<ul style="list-style-type: none"> <li>◦ Fan not on a level surface.</li> <li>◦ Debris caught in blades.</li> </ul>	<ul style="list-style-type: none"> <li>◦ Place the fan on a stable, level surface.</li> <li>◦ Unplug the fan and carefully check for any obstructions in the blades or grille.</li> </ul>

## 8. SPECIFICATIONS

Feature	Detail
<b>Model Number</b>	BHS136111442001
<b>Brand</b>	Better Homes & Gardens (Product is Amazon Renewed)
<b>Power Source</b>	Corded Electric, And Batteries
<b>Fan Speeds</b>	3 Speeds
<b>Control Method</b>	App (Note: Product description emphasizes intuitive physical controls. Please verify if app control is available or if this is a generic specification.)
<b>Item Weight</b>	1.1 pounds
<b>Package Dimensions</b>	19.69 x 11.81 x 3.54 inches
<b>Recommended Uses</b>	Cooling (for Office, Travel)
<b>ASIN</b>	B0BDBCZBLR
<b>UPC</b>	195925381010

## 9. WARRANTY AND SUPPORT

As this product is listed as "Renewed" by Amazon Renewed, specific warranty details may vary from a new product. Please refer to the Amazon Renewed program terms and conditions for information regarding the warranty and return policy applicable to your purchase.

For further assistance, troubleshooting not covered in this manual, or to inquire about service, please contact Amazon Renewed customer support or the original manufacturer if applicable.

You can typically find contact information on your purchase receipt or on the Amazon Renewed product page.

