



[Manuals.plus](#) /

> [Olakids](#) /

> OLAKIDS 7-in-1 Outdoor A-Frame Heavy Duty Metal Swing Set Instruction Manual, Model BH032

Olakids BH032

OLAKIDS 7-in-1 Outdoor A-Frame Heavy Duty Metal Swing Set Instruction Manual

Model: BH032

1. SAFETY INFORMATION

Read and understand all instructions before assembly and use of the swing set. Failure to follow these instructions may result in serious injury.

- **Adult Supervision Required:** Always ensure children are supervised by a responsible adult while using the swing set.
- **Age and Weight Limits:** This swing set is suitable for children aged 3 years and older. The total weight capacity is 660 lbs. Each individual swing has a weight capacity of 110 lbs. Do not exceed these limits.
- **Proper Installation:** Ensure the swing set is assembled correctly and all components are securely fastened. Use the provided ground stakes to anchor the A-frame structure firmly to the ground to prevent tipping.
- **Clearance Area:** Maintain a safe clearance area around the swing set, free from obstacles such as fences, trees, or other structures.
- **Regular Inspection:** Periodically check all nuts, bolts, ropes, and connections for tightness and wear. Replace any worn or damaged parts immediately.
- **One User Per Activity:** Unless specifically designed for multiple users (e.g., glider), ensure only one child uses each swing, slide, or trapeze ring at a time.
- **Material Compliance:** This product complies with US CPSIA and ASTM requirements, made from safe materials free from BPA, PVC, Phthalates, Lead, Latex, and Formaldehyde.



Image: Detail of a locking nut for enhanced safety and an indication of 110 lbs individual swing weight capacity.

UPGRADED STABILITY



Image: Illustration of ground nails used to fix the swing set for upgraded stability.

2. PACKAGE CONTENTS

The OLAKIDS 7-in-1 Swing Set arrives in two separate packages. Verify all components are present before beginning assembly. Refer to the detailed parts list in the official installation manual (PDF) for specific quantities and identification.

- A-Frame Metal Structure Components
- Slide
- 2 Swings
- Glider
- Trapeze Rings
- Monkey Bar Section
- Basketball Hoop and Net
- All necessary hardware (nuts, bolts, washers)

- 4 Ground Stakes
- Basic Assembly Tools (wrenches, etc.)

3. SETUP AND ASSEMBLY

Assembly of the OLAKIDS 7-in-1 Swing Set requires careful attention to detail. It is recommended to have at least two adults for assembly. The process involves connecting various metal tubes and securing them with hardware.

3.1 Preparation

- Unpack all components and lay them out in an organized manner.
- Identify all parts against the parts list in the official manual.
- Choose a level, clear area in your backyard for installation, ensuring adequate clearance around the swing set.

3.2 Assembly Steps

For detailed, step-by-step assembly instructions, please refer to the official Installation Manual (PDF) provided with your product or available online. The manual contains diagrams and specific guidance for each connection.

General Assembly Tips:

- Follow the sequence of steps precisely as outlined in the manual.
- Ensure all inner pipe joints are reinforced and locking nuts are tightened to increase safety and stability.
- While hand tools are provided, using a power drill with appropriate attachments can expedite the tightening of screws and bolts, ensuring a more secure fit.
- Once the main structure is assembled, securely install the four ground stakes into the ground to anchor the swing set.

Stable A-shaped Frame



Image: Illustration of the stable A-shaped frame design, highlighting key structural reinforcement points.

4. OPERATING INSTRUCTIONS

The OLAKIDS 7-in-1 Swing Set offers multiple activities for children. Ensure safe and appropriate use of each component.

4.1 Swings (Disc Swing and Belt Swings)

- Sit centered on the swing seat.
- Hold firmly onto the ropes or chains.
- Swing in a forward and backward motion, avoiding excessive sideways swinging or twisting.
- Do not stand on the swing seats.

4.2 Slide

- Climb the ladder facing the steps.

- Sit down at the top of the slide, feet first.
- Slide down one person at a time.
- Ensure the landing area is clear before sliding.

4.3 Glider

- Two children can use the glider simultaneously, facing each other.
- Sit securely on the seats and hold onto the handles.
- Push off the ground with feet to initiate movement.

4.4 Trapeze Rings

- Grasp the rings firmly with both hands.
- Use for hanging or swinging motions.
- Ensure hands are dry to maintain grip.

4.5 Monkey Bar

- Use a hand-over-hand motion to traverse the bars.
- Maintain a firm grip on the bars.

4.6 Basketball Hoop

- Use for shooting practice with a lightweight basketball.
- Do not hang from the basketball hoop or net.



Image: Children engaging with the multiple activities offered by the swing set.

5. MAINTENANCE

Regular maintenance ensures the longevity and safety of your OLAKIDS swing set.

- **Structural Check:** Annually, inspect the entire metal frame for any signs of rust, cracks, or damage. The frame is made of weather-resistant steel tubes with a powder-coated paint finish, designed to be rustproof and anti-corrosion.
- **Hardware Check:** Monthly, check all nuts, bolts, and screws for tightness. Tighten any loose fasteners to prevent instability.
- **Component Inspection:** Regularly inspect all swings, ropes, chains, glider seats, trapeze rings, and the slide for wear, fraying, or damage. Replace any components that show signs of significant wear or damage.
- **Cleaning:** Clean the swing set periodically with mild soap and water. Avoid harsh chemicals that could damage the finish or materials.
- **Ground Anchors:** Ensure ground stakes remain firmly in place. Re-secure if they become loose.

- **Winter Storage:** In areas with harsh winters, consider disassembling and storing certain components (like swings and slide) indoors to prolong their lifespan.



Image: Details of the swing seat construction, highlighting durable materials and adjustable ropes for maintenance reference.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your swing set.

Problem	Possible Cause	Solution
Swing set feels unstable or wobbly.	Loose connections; ground stakes not fully secured; uneven ground.	Tighten all nuts and bolts. Ensure ground stakes are fully inserted and secure. Relocate to a more level surface if necessary.
Squeaking noises during use.	Friction at pivot points or connections.	Apply a silicone-based lubricant to moving parts and connection points.

Problem	Possible Cause	Solution
Component (e.g., swing, slide) appears damaged.	Wear and tear; accidental damage.	Discontinue use of the damaged component immediately. Contact Olakids customer support for replacement parts.

If you encounter issues not listed here or require further assistance, please contact Olakids customer support.

7. SPECIFICATIONS

- **Brand:** Olakids
- **Model Number:** BH032
- **Product Dimensions (L x W x H):** 173.5" x 69.5" x 88.5"
- **Frame Material:** Alloy Steel, Metal
- **Finish Type:** Powder Coated
- **Item Weight:** 96 pounds
- **Total Weight Capacity:** 660 lbs
- **Individual Swing Weight Capacity:** 110 lbs
- **Recommended Age:** 3+ years
- **Assembly Required:** Yes



Image: Detailed dimensions and total weight capacity of the swing set.

8. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or to purchase replacement parts, please contact Olakids customer service directly. Refer to your purchase documentation or the Olakids official website for contact details. When contacting support, please have your product model number (BH032) and purchase date available.