

Sekonda 30085

Sekonda 30085 Men's Dive Watch User Manual

Model: 30085

1. INTRODUCTION

Thank you for choosing the Sekonda 30085 Men's Dive Watch. This manual provides essential information for the proper setup, operation, maintenance, and care of your new timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

2. PRODUCT OVERVIEW

The Sekonda 30085 is a robust men's dive watch featuring a durable stainless steel case and bracelet. It is equipped with a reliable Japanese movement and offers a water resistance of up to 200 meters. Key features include a date display window, luminous hands and markers for visibility in low light, and a secure, adjustable double-lock clasp.






Figure 2.1: Front view of the Sekonda 30085 Dive Watch, showcasing the orange dial, luminous markers, and stainless steel bracelet.

Key Features:

- **Japanese Movement:** Ensures accurate timekeeping.
- **200m Water Resistance:** Suitable for professional marine activity and serious surface water sports, but not scuba diving.
- **Stainless Steel Case and Bracelet:** Provides durability and a classic aesthetic.
- **Date Display Window:** Conveniently located on the dial.
- **Luminous Hands and Markers:** Enhances readability in dark conditions.
- **Adjustable Bracelet with Double-Lock Clasp:** Offers a secure and comfortable fit.
- **Non-Rotating Bezel:** A fixed bezel for aesthetic purposes.

3. SETUP

3.1 Setting the Time

1. Pull the crown (located on the right side of the watch case) out to the second click position.
2. Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the desired time.
3. Once the time is set, push the crown back in to the normal position. The second hand will begin to move.

3.2 Setting the Date

1. Pull the crown out to the first click position.
2. Rotate the crown clockwise to adjust the date. Avoid setting the date between 9:00 PM and 3:00 AM, as this may interfere with the automatic date change mechanism.
3. Once the date is set, push the crown back in to the normal position.



Figure 3.1: Close-up view of the watch dial and crown, illustrating the crown's position for time and date adjustments.

3.3 Adjusting the Bracelet

The stainless steel bracelet is fully adjustable. For a comfortable fit, links may need to be added or removed. This procedure typically requires specialized tools and is best performed by a professional jeweler or watch repair service. The double-lock clasp allows for micro-adjustments to achieve the perfect fit.





Figure 3.2: The double-lock clasp in an open position, showing the mechanism for securing the watch on the wrist.





Figure 3.3: The double-lock clasp in a closed position, demonstrating the secure fastening of the bracelet.

4. OPERATING INSTRUCTIONS

4.1 Water Resistance

Your Sekonda 30085 watch is water resistant up to 200 meters (20 ATM). This rating means the watch is suitable for professional marine activity and serious surface water sports. It is generally not suitable for scuba diving. Always ensure the crown is fully pushed in before exposing the watch to water. Do not operate the crown while the watch is wet or submerged.

4.2 General Wear and Care

- Avoid exposing your watch to extreme temperatures or sudden temperature changes.
- Keep the watch away from strong magnetic fields, as these can affect timekeeping accuracy.
- Avoid direct contact with solvents, detergents, perfumes, and cosmetic products, which can damage the bracelet, case, or gaskets.
- If the watch is exposed to saltwater, rinse it thoroughly with fresh water and dry it with a soft cloth.

5. MAINTENANCE

5.1 Cleaning

Regularly clean your watch with a soft, dry cloth. For the stainless steel bracelet and case, a slightly damp cloth can be used, followed by immediate drying. Do not use harsh chemicals or abrasive materials.

5.2 Battery Replacement

The watch is powered by a quartz movement and requires a battery. When the battery runs low, the second hand may start to jump in two-second intervals (End-of-Life indicator). Battery replacement should be performed by a qualified watch technician to ensure the water resistance seal is maintained.

5.3 Water Resistance Checks

It is recommended to have the water resistance of your watch checked periodically, especially if it is frequently exposed to water or if the case has been opened for battery replacement or service. Gaskets can degrade over time, affecting the watch's water resistance.

6. TROUBLESHOOTING

6.1 Watch Not Running

- **Check the Crown:** Ensure the crown is fully pushed in to the normal operating position.
- **Battery:** The battery may be depleted. Refer to Section 5.2 for battery replacement information.

6.2 Date Not Changing

- **Time Setting:** Ensure the time is set correctly, especially the AM/PM cycle. The date typically changes around midnight.
- **Manual Adjustment:** If the date is stuck, try manually advancing it using the crown (refer to Section 3.2).

If you experience persistent issues not covered here, please contact Sekonda customer support or a certified watch repair center.

7. SPECIFICATIONS

Feature	Specification
Model Number	30085
Brand	Sekonda
Movement	Japanese Quartz
Water Resistance	200 meters (20 ATM)
Case Material	Stainless Steel
Bracelet Material	Stainless Steel
Clasp Type	Double-Lock Safety Clasp
Date Display	Yes
Luminosity	Luminous hands and markers
Bezel	Fixed (Non-Rotating)

8. WARRANTY AND SUPPORT

8.1 Warranty Information




Your Sekonda 30085 watch comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear (e.g., battery, strap, crystal). Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For any questions, service, or warranty claims, please contact Sekonda customer support or visit the official Sekonda website for further assistance. Ensure you have your model number (30085) and proof of purchase available.

© 2024 Sekonda. All rights reserved.

Related Documents - 30085

	<p>Sekonda Watch Bracelet Adjustment Guide and Gauge Instructions</p> <p>A comprehensive guide for adjusting Sekonda watch bracelets, detailing procedures for sliding clasps, adjustable clasps, and link adjustments. Includes instructions for using the Sekonda Bracelet Gauge and important notes on warranty and professional servicing.</p>
	<p>Sekonda Watch Bracelet Adjustment Guide</p> <p>A comprehensive guide on how to adjust Sekonda watch bracelets, covering sliding clasps, adjustable clasps, and link adjustments. Includes instructions for using a bracelet gauge and advice on professional services and warranty.</p>
	<p>Sekonda Watch Instruction Guide and 2 Year Guarantee</p> <p>Detailed instruction manual for Sekonda watches, covering setup, operation, water resistance, service, and guarantee information. Learn how to use various functions including chronograph, moon phase, and world timer.</p>
	<p>Sekonda Watch Instruction Guide: Dual Time VD31 & VD35 Models</p> <p>Official instruction manual for Sekonda dual time watches with VD31 and VD35 movements. Learn how to set time, date, and understand water resistance and guarantee information.</p>
	<p>Sekonda IS50 Dual Time Watch Instruction Guide and Guarantee</p> <p>Official instruction guide and warranty information for the Sekonda IS50 Dual Time watch, covering setup, operation, water resistance, and service.</p>
	<p>Sekonda Watch: Simple Instructions and User Guide</p> <p>This official instruction manual provides clear, step-by-step guidance for setting up, operating, and caring for your Sekonda watch. It covers various models including non-date, day-date, multi-dial, and chronograph types, along with essential information on water resistance, warranty, and service.</p>

