



Manuals.plus /

› Lindby /

› Lindby Erin Spot Ceiling Lamp Instruction Manual (Model 9950993)

## Lindby 9950993

# Lindby Erin Spot Ceiling Lamp Instruction Manual

Model: 9950993

## 1. PRODUCT OVERVIEW

---

The Lindby Erin Spot Ceiling Lamp is a modern lighting fixture designed for indoor use, suitable for various rooms such as living rooms, dining rooms, hallways, kitchens, or bathrooms. This lamp features a matte black finish with gold leaf accents and uses three GU10 LED bulbs.

It is designed to create a pleasant atmosphere and enhance the aesthetic of your space.



Image 1.1: The Lindby Erin Spot Ceiling Lamp, featuring three adjustable spotlights with a matte black exterior and gold leaf interior, installed on a white ceiling.

## 2. SPECIFICATIONS

---

<b>Brand</b>	Lindby
<b>Model Number</b>	9950993
<b>Dimensions (L x W x H)</b>	22 x 22 x 15.9 cm
<b>Weight</b>	970 g
<b>Material</b>	Metal
<b>Color</b>	Matte black, gold leaf
<b>Number of Lights</b>	3
<b>Bulb Type</b>	3 x 5 W LED (GU10 socket)
<b>Luminous Flux</b>	1140 Lumen
<b>Color Temperature</b>	3000 Kelvin
<b>Voltage</b>	230 Volt
<b>Power Source</b>	AC (Alternating Current)
<b>IP Protection Class</b>	IP20
<b>Protection Class</b>	I
<b>Average Lifespan</b>	25,000 Hours
<b>Batteries Required</b>	No




Image 2.1: Dimensional drawing of the Lindby Erin Spot Ceiling Lamp, indicating a total diameter of 220mm and a height of 159mm. Each spot has a diameter of 120mm.



Image 2.2: Energy efficiency label for the Lindby Erin Spot Ceiling Lamp, indicating an energy class of G.

### 3. SAFETY INSTRUCTIONS

---

- **Electrical Safety:** Always disconnect power at the main circuit breaker before installation, maintenance, or bulb replacement.
- **Qualified Electrician:** Installation should be performed by a qualified electrician or a person with appropriate electrical knowledge to ensure safety and compliance with local regulations.
- **Indoor Use Only:** This product is rated IP20, meaning it is protected against solid objects larger than 12.5mm but has no protection against water. It is intended for indoor use only in dry environments.
- **Correct Bulbs:** Use only GU10 LED bulbs with a maximum wattage of 5W per bulb, as specified. Using incorrect bulbs may cause damage or fire.
- **Mounting Surface:** Ensure the mounting surface is structurally sound and can support the weight of the fixture.
- **Heat:** LED bulbs can still generate heat. Allow bulbs to cool before handling.
- **Cleaning:** Do not use abrasive cleaners or solvents. Clean with a soft, dry cloth.

### 4. SETUP AND INSTALLATION

---

Follow these steps for safe and proper installation of your Lindby Erin Spot Ceiling Lamp.

#### 1. Prepare for Installation:

- Turn off the main power supply to the installation area at the circuit breaker.
- Gather necessary tools: screwdriver, wire strippers, drill (if needed), mounting hardware.

#### 2. Unpack Components:

Carefully remove all parts from the packaging. Verify that all components are present according to the parts list (refer to Image 4.1).

#### 3. Mount the Mounting Bracket:

- Attach the mounting bracket to the ceiling using appropriate screws and anchors. Ensure it is securely fastened.

#### 4. Electrical Connection:

- Connect the household electrical wires to the lamp's wires. Typically, this involves connecting live (brown/black), neutral (blue), and ground (green/yellow) wires. Ensure connections are secure and insulated.
- *Consult a qualified electrician if you are unsure about electrical wiring.*

#### 5. Attach the Lamp Body:

- Carefully align the lamp body with the mounting bracket and secure it with the provided screws.

#### 6. Install Bulbs:

- Insert the three GU10 LED bulbs into their respective sockets by pushing and twisting them clockwise until they are secure.

7. **Adjust Spotlights:** The individual spotlights can be adjusted to direct light as desired.

8. **Restore Power:** Once installation is complete and all connections are secure, restore power at the main circuit breaker.



Image 4.1: Components of the Lindby Erin Spot Ceiling Lamp, showing the ceiling base, mounting hardware, three decorative spot covers, and three GU10 LED bulbs.

## 5. OPERATING INSTRUCTIONS

The Lindby Erin Spot Ceiling Lamp is operated via a standard wall switch connected to your household electrical circuit. There are no integrated controls on the fixture itself.

- **Turning On/Off:** Flip the wall switch connected to the lamp to turn the light on or off.
- **Adjusting Light Direction:** The individual spotlights can be manually rotated and tilted to direct the light beam to your preferred area.

## 6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your lamp.

- **Cleaning:**
  - Before cleaning, ensure the lamp is turned off and has cooled down.
  - Wipe the lamp's exterior with a soft, dry, lint-free cloth.
  - Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the finish.
- **Bulb Replacement:**
  - Always turn off the power supply at the circuit breaker before replacing bulbs.
  - Allow old bulbs to cool completely before touching them.
  - To remove a GU10 bulb, gently push it into the socket and twist counter-clockwise.
  - Insert a new GU10 LED bulb (max 5W) by aligning the pins, pushing gently, and twisting clockwise until secure.
  - Restore power after replacement.

## 7. TROUBLESHOOTING

If you encounter issues with your Lindby Erin Spot Ceiling Lamp, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Lamp does not light up.	No power supply. Bulb(s) faulty or not properly installed. Loose wiring connection.	Check if the wall switch is on. Check the circuit breaker. Replace faulty bulbs. Ensure bulbs are securely twisted into sockets. <i>If wiring is suspected, consult a qualified electrician.</i>
Light flickers.	Loose bulb connection. Incompatible dimmer switch (if applicable). Faulty bulb.	Ensure bulbs are securely twisted into sockets. This lamp is not specified as dimmable; flickering may occur with incompatible dimmers. Replace the flickering bulb.
Lamp makes buzzing noise.	Incompatible dimmer switch (if applicable). Loose wiring.	Ensure no dimmer switch is used unless explicitly stated as compatible. <i>If wiring is suspected, consult a qualified electrician.</i>

## 8. WARRANTY AND SUPPORT

This product is covered by a return policy of 30 days for refund or replacement, as per the seller's terms.

For any questions regarding the product, quality concerns, or support, please contact the seller directly via their Amazon store. The manufacturer is Lampenwelt.

You can find more information about Lindby products and support on the official Lindby brand store [Lindby Brand Store](#).

