

[manuals.plus](#) /

› [KRUPS](#) /

› [KRUPS 1.7L Glass Electric Kettle KI700852 User Manual](#)

KRUPS KI700852

KRUPS 1.7L Glass Electric Kettle KI700852 User Manual

Model: KI700852

1. INTRODUCTION

Thank you for choosing the KRUPS 1.7L Glass Electric Kettle. This appliance is designed for rapid water boiling, offering convenience and efficiency for your hot beverage needs. Please read this manual carefully before first use to ensure safe and optimal operation.

2. IMPORTANT SAFETY INFORMATION

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Contact manufacturer for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- Extreme caution must be used when moving an appliance containing hot water.
- The kettle is for household use only.
- Do not fill above the 'MAX' line or below the 'MIN' line indicated on the kettle.
- Ensure the lid is securely closed before operating.

3. PRODUCT OVERVIEW

The KRUPS 1.7L Glass Electric Kettle combines a sleek design with efficient performance. Key features include a durable glass body, stainless steel accents, and a powerful heating element for fast boiling.



Figure 1: Kettle Components and Dimensions. This image illustrates the kettle's main parts, including the open lid button, 100% recyclable glass body, automatic switch-off lever, and 360-degree rotating base, along with its approximate height and width.

Components:

- **Glass Body:** Thermal shock-resistant, 100% recyclable glass for pure water taste.
- **Lid:** Features an open lid button for easy filling.
- **Handle:** Ergonomically designed for comfortable pouring.
- **V-shaped Spout:** Designed for precise, drip-free pouring.
- **Anti-Scale Filter:** Integrated in the spout to maintain water purity.
- **Water Level Indicator:** Clear markings for 0.3L to 1.7L capacity.
- **Power Switch:** Manual push-down switch with automatic shut-off.
- **LED Indicator:** Illuminates when the kettle is boiling.
- **360° Rotational Base:** Cordless design for easy placement and lifting.

4. SETUP

1. **Unpack:** Carefully remove the kettle and its base from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, fill the kettle with fresh water to the 'MAX' level. Boil the water and then

discard it. Repeat this process two to three times to remove any manufacturing residues.

3. **Placement:** Place the power base on a flat, stable, heat-resistant, and dry surface, away from the edge of the counter. Ensure the power cord is not dangling where it can be pulled or tripped over.
4. **Connect Power:** Plug the power cord into a grounded electrical outlet.

5. OPERATING INSTRUCTIONS

Boiling Water:

1. **Fill the Kettle:** Press the open lid button to open the lid. Fill the kettle with the desired amount of fresh water. Do not fill below the 'MIN' mark or above the 'MAX' mark (1.7 liters). Close the lid securely.



Figure 2: Filling the Kettle. This image shows the kettle being filled with water, highlighting the ease of use with its open lid.

2. **Place on Base:** Place the kettle firmly onto its 360° rotational power base.
3. **Start Boiling:** Push the power switch down. The LED indicator will illuminate, signaling that the kettle is heating.



Figure 3: Water Boiling Process. This image depicts the kettle actively boiling water, with a visual representation of heat transfer and a cup of tea ready for preparation.

- Automatic Shut-Off:** Once the water reaches a rolling boil, the kettle will automatically switch off, and the LED indicator will extinguish.
- Pouring:** Carefully lift the kettle from its base and pour the hot water using the V-shaped spout.




Figure 4: Precise Pouring. This image demonstrates the kettle's V-shaped spout providing controlled and drip-free pouring into a mug.

- Re-boiling:** If you need to re-boil water, simply push the power switch down again.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your KRUPS electric kettle.

General Cleaning:

- Unplug and Cool:** Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
- Exterior:** Wipe the exterior of the kettle and the power base with a damp cloth and a mild detergent. Do not

use abrasive cleaners or scouring pads, as these can scratch the glass and stainless steel surfaces.

3. **Interior:** The wide opening of the kettle facilitates easy access for cleaning the interior. Use a soft sponge or cloth.



Figure 5: Easy Cleaning. This image shows a hand cleaning the interior of the kettle through its wide opening, demonstrating the ease of maintenance.

4. **Anti-Scale Filter:** The integrated anti-scale filter can be removed for cleaning. Gently pry it out with your fingernail. Rinse it under running water and brush gently if necessary. Reinsert it securely after cleaning.

Descaling:

Mineral deposits (limescale) can build up inside the kettle, especially in hard water areas. Descaling your kettle regularly to maintain efficiency and water purity.

1. **Prepare Solution:** Fill the kettle with a mixture of white vinegar and water (e.g., 1 part vinegar to 2 parts water) or a commercial descaling solution according to its instructions.
2. **Boil and Soak:** Bring the solution to a boil and let it soak for at least 30 minutes, or longer if scale is heavy. For very heavy scale, you may need to re-boil the solution.
3. **Rinse:** Discard the descaling solution. Rinse the kettle thoroughly several times with fresh water to remove any residual vinegar or descaling agent.
4. **Final Rinse Boil:** Fill the kettle with fresh water, boil, and discard to ensure all descaling residue is gone before using for beverages.

7. TROUBLESHOOTING

If you encounter any issues with your KRUPS electric kettle, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Kettle does not turn on.	Not plugged in; power switch not engaged; kettle not properly seated on base; power outage.	Ensure plug is securely in outlet. Push power switch down firmly. Ensure kettle is correctly placed on the base. Check household circuit breaker.

Problem	Possible Cause	Solution
Water is not boiling.	Kettle filled above MAX line; power switch not engaged.	Do not overfill the kettle. Ensure the power switch is pushed down.
Kettle switches off too quickly.	Limescale buildup.	Descale the kettle as per the 'Maintenance and Cleaning' section.
Water tastes unusual or has particles.	New kettle residue; limescale buildup; dirty anti-scale filter.	Perform initial cleaning steps. Descale the kettle. Clean the anti-scale filter.
Kettle leaks from the base.	Overfilling; water spilled during filling.	Do not fill above the MAX line. Be careful not to spill water onto the power base when filling.

If the problem persists after attempting these solutions, please contact KRUPS customer support.

8. SPECIFICATIONS



Feature	Detail
Brand	KRUPS
Model Name	KI700852
Capacity	1.7 Liters
Power	1500W (for rapid boiling)
Material	Glass (thermal shock-resistant), Stainless Steel
Color	Stainless Steel and Black
Special Features	LED Indicator, Anti-Scale Filter, Auto Shut-Off, Boil-Dry Protection, Cordless Design, 360° Rotational Base, V-shaped Spout
Product Dimensions	8.32" L x 5.96" W x 9.39" H
Item Weight	3.49 pounds
UPC	010942228097
Manufacturer	Groupe SEB

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact KRUPS directly. Keep your proof of purchase for any warranty claims.

Manufacturer: Groupe SEB

Related Documents - KI700852

	<p><u>KRUPS Digital Kettle User Manual and Guide</u> Comprehensive user manual for the KRUPS Digital Kettle, covering safety instructions, operation, cleaning, maintenance, and troubleshooting for optimal performance.</p>
	<p><u>Krups Excellence Kettle User Manual and Safety Guide</u> Comprehensive user manual for the Krups Excellence Kettle, detailing setup, operation, safety precautions, cleaning, descaling, and troubleshooting. Includes multilingual index and safety guidelines.</p>
	<p><u>KRUPS Electric Kettle User Manual - Temperature Control, Safety, and Operation Guide</u> Comprehensive user manual for the KRUPS Electric Kettle (Model BW871DF0). Learn about safe operation, temperature control, keep warm function, cleaning, maintenance, and troubleshooting.</p>
	<p><u>KRUPS ProAroma Time Coffee Maker Model 314: Instructions for Use and Warranty</u> Comprehensive guide for the KRUPS ProAroma Time coffee maker (Model #314), covering setup, operation, features like programmable timer and aroma selection, cleaning, decalcifying, and warranty information.</p>
	<p><u>KRUPS Crystal Arome & Crystal Arome Time Coffee Maker User Manual</u> Comprehensive user guide for KRUPS Crystal Arome and Crystal Arome Time coffee makers (Models #398, #458), covering operation, safety, features, maintenance, and warranty information.</p>



[Krups Digital Kettle User Manual](#)

Comprehensive user manual for the Krups Digital Kettle, covering safety instructions, operation, cleaning, maintenance, troubleshooting, and warranty information.