

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Eufy](#) /

> [Anker Eufy Clean X9 Pro with Auto-Clean Station Robot Vacuum Instruction Manual](#)

## Eufy X9 Pro with Auto-Clean Station

# Anker Eufy Clean X9 Pro with Auto-Clean Station Robot Vacuum Instruction Manual

Model: X9 Pro with Auto-Clean Station (T2320)

## 1. INTRODUCTION

Welcome to the instruction manual for your Eufy Clean X9 Pro with Auto-Clean Station. This advanced robot vacuum is designed to provide a comprehensive cleaning experience, combining powerful suction with effective mopping. It features a pressurized dual rotating mop system, an auto-lift mop for carpets, and an innovative auto-clean station that washes and dries the mops automatically. With 5500Pa suction power and AI.See obstacle avoidance, your home will be meticulously cleaned with minimal effort.

This manual will guide you through the setup, operation, maintenance, and troubleshooting of your device, ensuring optimal performance and longevity.



*Image: The Eufy Clean X9 Pro robot vacuum with its Auto-Clean Station, illustrating the transition to a new era of robot cleaning that presses and wipes.*

## 2. SETUP

### 2.1 Package Contents

Before you begin, ensure all items are present:

- Eufy Clean X9 Pro Robot Vacuum
- Auto-Clean Station
- Power Cord
- Replacement Filter
- Instruction Manual

## 2.2 Station Placement

Place the Auto-Clean Station on a hard, flat surface against a wall. Ensure there is at least 0.5 meters (1.6 feet) of clear space on both sides and 1.5 meters (4.9 feet) in front of the station for optimal robot navigation.

## 2.3 Initial Charging & Water Tank Setup

Connect the power cord to the Auto-Clean Station and plug it into a wall outlet. Place the robot vacuum onto the charging contacts. While charging, fill the clean water tank with fresh water and ensure the dirty water tank is empty. The station will automatically manage water for mop washing.

## 2.4 App Connection

Download the Eufy Clean app from your smartphone's app store. Follow the in-app instructions to connect your robot vacuum to your home Wi-Fi network. The app allows for advanced control, mapping, and customization of cleaning settings.



### アプリでお掃除の カスタマイズが可能

進入禁止エリアや吸引力、水量を、  
お部屋ごとに設定ができます。

Image: The Eufy Clean app interface, demonstrating how cleaning can be customized, including setting no-go zones, suction power, and water levels per room.

## 3. OPERATING YOUR ROBOT VACUUM

### 3.1 Starting and Stopping Cleaning

You can start or stop a cleaning cycle using the button on the robot, the Eufy Clean app, or voice commands via Amazon Alexa.

### 3.2 Cleaning Modes

The Eufy Clean X9 Pro offers various cleaning modes:

- **Vacuum Only:** For dry debris on all floor types.

- **Mop Only:** For wet cleaning on hard floors.
- **Vacuum & Mop:** Simultaneous vacuuming and mopping.

Select your preferred mode via the Eufy Clean app.



*Image: The robot vacuum powerfully sucking up debris, highlighting its 5500Pa suction capability.*

### 3.3 Carpet Detection and Mop Lift

The robot automatically detects carpets and lifts its mops by approximately 12mm to prevent wetting. It will then switch to vacuum-only mode on carpets.



*Image: The robot vacuum's mop automatically lifting by 12mm upon detecting a carpet, preventing the carpet from getting wet.*

### 3.4 AI.See Obstacle Avoidance

Equipped with a 3D ToF sensor and AI camera, the AI.See system accurately recognizes and avoids common household obstacles such as cables, slippers, and furniture, ensuring an uninterrupted cleaning path.

## 高性能な障害物回避

3D ToFセンサーとAIカメラで一般的な家具を認識し、ケーブルやコード、スリッパ、家具などの障害物を的確に回避します。

※障害物回避のためのAI.Seeテクノロジーは、画像を保存しません。



*Image: The robot vacuum using its AI.See system to detect and avoid various obstacles on the floor, such as cables and shoes.*

## 3.5 AI.Map 3.0 Technology

The AI.Map 3.0 technology allows for multi-floor mapping, storing up to 5 floor plans. You can select specific rooms or areas to clean, and the app displays detected obstacles on the map for precise cleaning management.

### AI.Map3.0テクノロジー

マルチフロアマッピングで5フロアの保存、掃除する部屋やエリアの選択、障害物のマップ上での表示が可能です。



*Image: The Eufy Clean app showing a detailed floor map created by AI.Map 3.0 technology, allowing users to customize cleaning zones.*

## 4. MAINTENANCE

### 4.1 Auto-Clean Station Maintenance

The Auto-Clean Station automatically washes and dries the mops after each cleaning cycle using warm air, preventing odors and manual effort. It also features automatic dust collection, reducing the frequency of manual dustbin emptying.



*Image: The Auto-Clean Station automatically washing and drying the robot's mops, eliminating manual cleaning tasks.*

## 4.2 Water Tank Maintenance

Regularly check and refill the clean water tank. Empty and clean the dirty water tank to prevent mold and odors. The frequency depends on usage.

## 4.3 Brush Cleaning

The robot features a unique V-shaped rubber brush designed to prevent hair tangles. Periodically remove the main brush and clean any accumulated hair or debris. A cleaning tool is usually provided for this purpose.

## 4.4 Filter Replacement

Replace the filter as recommended in the app or every 3-6 months, depending on usage, to maintain optimal suction performance.

## 4.5 Sensor Cleaning

Wipe the sensors on the robot and the charging contacts on both the robot and the station with a dry cloth to ensure proper navigation and charging.

## 4.6 Video Demonstrations

Video: Eufy X10 Pro Omni Product Introduction. This video demonstrates the robot's cleaning capabilities, obstacle avoidance, and the self-cleaning station's functions, including mop washing and drying.

Video: Eufy Clean X8 Pro with Self-Empty Station Introduction. This video showcases the robot's powerful suction, unique V-shaped brush for hair tangle removal, and the self-empty feature of its station.

Video: Eufy Robot Vacuum Omni C20 Product Video. This video demonstrates the automatic mop washing and drying process, as well as the automatic dust collection feature of the cleaning station.

## 5. TROUBLESHOOTING

---

### 5.1 Common Issues

- **Robot is stuck:** Clear any obstacles around the robot. Check if the wheels or brushes are tangled.
- **No suction/poor cleaning:** Empty the dustbin, clean the main brush, and replace the filter if necessary.
- **Mop not cleaning effectively:** Ensure the clean water tank is filled and the dirty water tank is empty. Clean the mops or replace them if worn.
- **Robot not charging:** Ensure the charging contacts on both the robot and the station are clean and free of debris. Check if the power cord is securely connected.

### 5.2 Error Messages

If the robot displays an error message or indicator light, refer to the Eufy Clean app for specific instructions and troubleshooting steps. The app provides detailed explanations and solutions for most issues.

## 6. SPECIFICATIONS

---

<b>Brand</b>	Eufy
<b>Model Name</b>	X9 Pro with Auto-Clean Station
<b>Model Number</b>	T2320
<b>Suction Power</b>	5500Pa
<b>Mop Type</b>	Pressurized Dual Rotating Mops
<b>Mop Lift Height</b>	Approx. 12mm
<b>Obstacle Avoidance</b>	3D ToF Sensor, AI Camera (AI.See)
<b>Mapping Technology</b>	AI.Map 3.0 (up to 5 floor plans)
<b>Battery Composition</b>	Lithium-ion
<b>Product Dimensions (L x W x H)</b>	35.3 x 32.7 x 11.4 cm (13.9 x 12.9 x 4.5 inches)
<b>Product Weight</b>	4.68 kg (10.32 lbs)
<b>Controller Type</b>	App, Amazon Alexa
<b>UPC</b>	194644122355

## 7. WARRANTY

---

Your Eufy Clean X9 Pro with Auto-Clean Station comes with a maximum 24-month warranty from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects

and malfunctions under normal use. For detailed terms and conditions, please refer to the official Eufy website or contact customer support.

## 8. SUPPORT

---

For further assistance, technical support, or to report any issues, please contact Eufy Customer Support through the following channels:

- **Eufy Clean App:** Access the support section within the app for FAQs and direct contact options.
- **Eufy Official Website:** Visit [www.eufylife.com](http://www.eufylife.com) for product information, FAQs, and contact details.
- **Email Support:** Refer to your product packaging or the Eufy website for the appropriate email address.

Please have your model number (T2320) and purchase information ready when contacting support.