

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Taylor](#) /

› [Taylor Digital Waterproof Kitchen Food and Meat Thermometer Instruction Manual](#)

Taylor 5295845

Taylor Digital Waterproof Kitchen Food and Meat Thermometer Instruction Manual

Model: 5295845

INTRODUCTION

The Taylor Precision Products Waterproof Programmable Folding Thermometer is designed to help you achieve perfect cooking temperatures for various foods. Its waterproof design allows for easy cleaning, and programmable presets simplify the cooking process. This manual provides detailed instructions for setup, operation, and maintenance of your new thermometer.

PRODUCT OVERVIEW

Your Taylor Digital Waterproof Thermometer is equipped with several features to enhance your cooking experience:

- **Waterproof Design:** Certified to IPX7, allowing for safe cleaning under running water or submersion.
- **High Accuracy:** Measures temperatures from -40°F to 482°F (-40°C to 250°C) with precision.
- **Sleek Design with Easy Reading:** Features a convenient folding narrowed tip probe for safe storage and an extra-large, blue backlit 0.5-inch display for visibility in low light.
- **Programmable Presets:** Includes preset temperatures for various protein types, eliminating the need for external charts.
- **Battery Operated:** Comes with two (2) AAA batteries for immediate use.



Figure 1: Front view of the Taylor Digital Thermometer with the probe extended, showing the digital display.



Figure 2: Overview of key features including waterproof capability, backlit display, and programmable settings.

SETUP

Before first use, you need to activate the batteries:

1. Locate the battery compartment on the back of the thermometer.
2. Using a small Phillips head screwdriver (not included), loosen the screws to remove the battery compartment door.
3. Remove the plastic insulation tab protecting the batteries.
4. Ensure the waterproof gasket is securely in place.
5. Replace the battery compartment door and tighten the screws to ensure a tight seal.



Figure 3: View of the battery compartment, showing the two AAA batteries inside.

OPERATING INSTRUCTIONS

Follow these steps to use your thermometer:

1. **Power On/Off:** Extend the probe to automatically power on the thermometer. To power off, fold the probe back into the unit or press and hold the power button () for 2 seconds.
2. **Select Temperature Unit:** Press the °F/°C button to switch between Fahrenheit and Celsius.
3. **Measure Temperature:** Insert the narrowed tip probe into the thickest part of the food, avoiding bone or gristle. The temperature will display on the backlit LCD screen within seconds.
4. **Hold Function:** Press the **HOLD** button to freeze the current temperature reading on the display. Press again to release.
5. **Using Presets:** Press the **SET** button to cycle through pre-programmed temperature settings for different meat types (e.g., Beef, Pork, Poultry, Ground Meat). The display will show an icon indicating the meat type.

6. **Custom Programming:** To set a custom target temperature, cycle through the presets until you find a blank setting (without a farm animal icon). Use the up (▲) and down (▼) arrows to adjust the target temperature.

TAYLOR**FEATURES**



SUPERIOR DESIGN AND PRECISION ACCURACY!
Programmable temperature presets without the wires

5295845 WATERPROOF PROGRAMMABLE THERMOMETER



Figure 4: The thermometer displaying a preset temperature for a specific meat type.

MAINTENANCE

Proper care ensures the longevity and accuracy of your thermometer:

- **Cleaning:** The thermometer is IPX7 waterproof, allowing it to be washed under running water or submerged in a sink for easy cleaning. Hand wash only. Do not place in a dishwasher.
- **Storage:** Fold the probe back into the unit for safe and compact storage. The integrated hang-hole also allows for convenient hanging.
- **Battery Replacement:** If the display becomes dim or unresponsive, replace the two AAA batteries as described in the Setup section.



IPX7 WATERPROOF CERTIFIED!
Designed for easy cleaning and disinfecting between uses

5295845 WATERPROOF PROGRAMMABLE THERMOMETER



Figure 5: The thermometer being cleaned under running water, highlighting its IPX7 waterproof rating.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Thermometer does not turn on.	<p>Check if the plastic insulation tab has been removed from the batteries (see Setup).</p> <p>Ensure batteries are inserted with correct polarity.</p> <p>Replace batteries with new AAA batteries.</p>
Inaccurate temperature readings.	<p>Ensure the probe is inserted into the thickest part of the food, away from bone or gristle.</p> <p>Allow sufficient time for the reading to stabilize.</p> <p>Check battery level; low batteries can affect accuracy.</p>


Problem	Possible Cause / Solution
Display is dim or flickering.	Batteries are low and need to be replaced.

SPECIFICATIONS

- **Model Number:** 5295845
- **Temperature Range:** -40°F to 482°F (-40°C to 250°C)
- **Waterproof Rating:** IPX7
- **Display Type:** Digital, Backlit LCD (0.5-inch digit height)
- **Power Source:** 2 x AAA batteries (included)
- **Probe Length:** 4 inches
- **Dimensions:** Approximately 6.25 x 1.5 inches (folded)
- **Material:** Plastic (outer material)
- **Care Instructions:** Hand Wash Only
- **Country of Origin:** China
- **Manufacturer:** Lifetime Brands Inc.



0.5" LCD
DIGIT
HEIGHT



NARROWED TIP



TEMPERATURE RANGE

-40°F to 482°F | -40°C to 250°C

5295845 WATERPROOF PROGRAMMABLE THERMOMETER



Figure 6: Detailed dimensions and temperature range of the thermometer.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official Taylor website. Keep your purchase receipt for warranty claims.

	<p>Taylor Digital Waterproof Thermometer User Guide</p> <p>Instructions and information for the Taylor Digital Waterproof Thermometer, including how to use, battery information, cleaning, and warranty.</p>
	<p>Taylor 5309295 Wireless Bluetooth Thermometer - Features and Usage</p> <p>Detailed information on the Taylor 5309295 Wireless Bluetooth Thermometer, including its specifications, features, multiple cooking uses, ease of cleaning, and system pairing instructions. Wirelessly track temperatures in ovens, grills, and smokers with this IPX7 waterproof and rechargeable device.</p>
	<p>Taylor 5309295 Waterproof Wireless Meat Thermometer with Charging Case Instruction Manual</p> <p>Instruction manual for the Taylor 5309295 Waterproof Wireless Meat Thermometer with Charging Case, detailing setup, usage, product specifications, care, precautions, FCC compliance, and warranty information.</p>
	<p>Taylor 5309295 Waterproof Wireless Meat Thermometer: Setup & Usage Guide</p> <p>Learn how to use the Taylor 5309295 Waterproof Wireless Meat Thermometer with its companion SMARTTHERMO app for precise cooking. This guide covers setup, operation, care, and safety precautions.</p>
	<p>ZyTemp TN15A Infrared Thermometer Operating Instructions</p> <p>Operating instructions for the ZyTemp TN15A non-contact infrared thermometer, covering features, battery replacement, specifications, and troubleshooting. Learn how to use and maintain your device for accurate temperature measurements.</p>
	<p>Taylor 9877FDA Digital Thermometer Instruction Manual</p> <p>Instruction manual for the Taylor 9877FDA Digital Thermometer, covering first use, battery information, functions, temperature readings, care and precautions, and warranty information.</p>



[Taylor Digital Waterproof Thermometer User Guide](#)

Instructions and information for the Taylor Digital Waterproof Thermometer, including how to use, battery information, cleaning, and warranty.

lang:en score:36 filesize: 160.39 K page_count: 1 document date: 2025-06-18