

THOMSON TV Sound Bar B202



THOMSON B202 Soundbar User Manual

Model: TV Sound Bar B202

1. INTRODUCTION

Thank you for purchasing the THOMSON B202 Soundbar. This 35-inch soundbar is designed to enhance your home audio experience, delivering powerful bass and clear audio for movies, music, and games. Featuring Bluetooth 5.0 for wireless streaming and multiple wired input options, it offers versatile connectivity and superior sound quality.



Image: The THOMSON B202 Soundbar, a sleek black unit, is shown alongside its compact remote control, highlighting the product's design and primary control interface.

2. WHAT'S IN THE BOX

Please check the package contents carefully. If any items are missing or damaged, contact customer support.

- Sound bar
- Power supply

- Remote control
- Coaxial cables
- Wall mounting screws

3. SETUP AND PLACEMENT

3.1 Initial Setup

1. Unpack all components from the box.
2. Choose your preferred placement method (Desktop or Wall Mounting).
3. Connect the power supply to the soundbar and then to a power outlet.
4. Select your desired audio input method (see Section 4: Connectivity).

3.2 Flexible Placement Options

The THOMSON B202 Soundbar offers versatile placement to suit your home entertainment setup.

- **Desktop Placement:** Position the soundbar directly in front of your TV on a flat surface. Ensure it does not obstruct the TV's remote sensor.
- **Wall Mounting:** Use the included wall mounting screws to securely attach the soundbar to a wall below your TV. Refer to the wall mounting template (if provided) for accurate drilling.

Flexible Placement



Image: This illustration demonstrates the two primary placement options for the soundbar: on a desktop surface in front of a television or securely mounted to a wall, showing its adaptability to various home setups.

4. CONNECTIVITY

The THOMSON B202 Soundbar supports both wireless and wired connections to various devices.

4.1 Bluetooth 5.0 Connection

For wireless audio streaming from your smartphone, tablet, or other Bluetooth-enabled devices:

1. Press the 'MODE' button on the soundbar or remote control until 'BT' appears on the display.
2. Enable Bluetooth on your device and search for 'THOMSON B202'.
3. Select the soundbar to pair. A confirmation sound will indicate successful pairing.

4.2 Wired Connections

The soundbar provides multiple ports for wired connections:

- **HDMI (ARC):** Connect to your TV's HDMI ARC port for high-quality audio and control via your TV remote.
- **Optical (OPTI):** Connect to your TV or other audio source using an optical cable for digital audio.
- **AUX:** Use a 3.5mm audio cable to connect to devices with an analog audio output.
- **Coaxial (COAX):** Connect to devices with a coaxial digital audio output.
- **USB:** Insert a USB flash drive for direct playback of audio files.

Wireless or Wired Conectivity

Paris via Bluetooth 5.0 or multiple wired interfaces and enjoy local music via USB driver connection



Image: A detailed view of the soundbar's rear panel showing various input ports including Bass Output, Optical Audio Input, Coaxial Interface, HDMI Audio Input, USB Playback, and 24V/2A Power Connector, alongside an illustration of Bluetooth 5.0 wireless connectivity with a smartphone.

Multiple Connection Methods




Image: A comprehensive diagram illustrating the various wired and wireless connection methods for the soundbar, including Bluetooth, SUB OUT, Optical, AUX, Coaxial, HDMI/ARC, 24V/2A DC IN, and USB, showing compatibility with laptops, desktop PCs, cell phones, and TVs.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press the power button on the soundbar or remote control to turn the unit on or off.

5.2 Volume Control

Use the 'VOL+' and 'VOL-' buttons on the remote control or the side panel of the soundbar to adjust the volume. The soundbar features a 2.1 channel system with dual bass for powerful audio output.

5.3 EQ Modes

The soundbar features three pre-set equalizer modes to optimize audio for different content types. Press the 'MODE' button on the remote to cycle through them:

- **Music Mode:** Optimized for musical playback, providing balanced sound.
- **Movie Mode:** Enhances dialogue and sound effects for an immersive cinematic experience.
- **News Mode:** Clarifies vocal frequencies for clear speech.

Additionally, you can adjust treble and bass intensity (8 levels) using the dedicated 'TRE+'/'TRE-' and 'BAS+'/'BAS-' buttons on the remote control.

3 Equalizer Modes

DSP technology tailors & enhances audio to your media for max immersion




Image: This graphic displays the soundbar and three screens representing the distinct equalizer modes: Music, Movie, and News, illustrating how DSP technology tailors and enhances audio for maximum immersion.



Image: A close-up showing the remote control and the physical buttons on the soundbar, indicating the various control options available to the user.

6. MAINTENANCE

- To ensure the longevity and optimal performance of your THOMSON B202 Soundbar, follow these maintenance guidelines:
- **Cleaning:** Use a soft, dry cloth to wipe the surface of the soundbar. Do not use liquid cleaners or abrasive chemicals, as they may damage the finish.
 - **Ventilation:** Ensure the soundbar has adequate ventilation. Do not block any vents or place it in an enclosed space that could lead to overheating.
 - **Storage:** If storing the soundbar for an extended period, disconnect it from power and store it in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter issues with your soundbar, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No Sound	Power not connected; Incorrect input source; Volume too low; Mute activated.	Ensure power is connected and unit is on. Select correct input source (HDMI, Optical, AUX, etc.). Increase volume. Deactivate mute.
Bluetooth Disconnection	Device too far; Interference; Soundbar not in pairing mode.	Move device closer to soundbar. Avoid obstacles. Re-enter Bluetooth pairing mode on soundbar and device.
Remote Control Not Working	Batteries depleted; Obstruction between remote and soundbar; Remote sensor blocked.	Replace batteries. Remove any obstructions. Ensure remote is pointed at the soundbar's sensor.
Distorted Sound	Volume too high; Poor audio source quality; Incorrect EQ mode.	Lower volume. Try a different audio source. Adjust EQ mode or treble/bass settings.

8. SPECIFICATIONS

Feature	Specification
Model Name	TV Sound Bar B202
Dimensions (D x W x H)	2.6" x 35" x 2.4"
Weight	5.44 pounds
Material	Metal, Acrylonitrile Butadiene Styrene (ABS)
Speaker Type	Subwoofer, 3D (2.1 Channel)
Connectivity Technology	Bluetooth 5.0, HDMI (ARC), Auxiliary, Optical, Coaxial, USB

Feature	Specification
Audio Output Mode	Surround
Power Source	Corded Electric
Included Components	Sound bar, Power supply, Remote, Coaxial cables, Wall mounting screws

9. WARRANTY AND SUPPORT

The THOMSON B202 Soundbar comes with a **12-month limited warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.

For warranty claims, technical support, or any inquiries regarding your product, please contact THOMSON customer service through the retailer where you purchased the product or visit the official THOMSON website for support contact information.

Please retain your proof of purchase for warranty validation.

© 2024 THOMSON. All rights reserved.

For more information, visit the [THOMSON Store on Amazon](#).