

Havit MS1032

Havit Gaming Mouse MS1032 User Manual

Model: MS1032

1. INTRODUCTION

Welcome to the user manual for your Havit Gaming Mouse MS1032. This document provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read it carefully to ensure optimal performance and longevity of your mouse.

The Havit MS1032 is a gaming mouse featuring six adjustable DPI settings, a comfortable ergonomic design, and a non-slip surface. It is engineered for smooth and quiet operation, aiming to reduce fatigue during extended use.

2. SETUP

2.1 Package Contents

- Havit Gaming Mouse MS1032
- User Manual

2.2 System Requirements

- Operating System: Windows XP, Windows 7, Linux
- Available USB port

2.3 Connecting the Mouse

1. Unpack the Havit Gaming Mouse MS1032 from its packaging.
2. Locate an available USB port on your computer.
3. Insert the USB connector of the mouse into the USB port.
4. Your operating system should automatically detect and install the necessary drivers. This process may take a few moments.

5. Once installation is complete, the mouse is ready for use.



Figure 1: Havit MS1032 Gaming Mouse connected via USB.

3. OPERATING INSTRUCTIONS

3.1 Basic Functions

- **Left Click:** Primary action, selection, activation.
- **Right Click:** Opens context menus, performs secondary actions.
- **Scroll Wheel:** Scrolls up/down documents or web pages. Can also be pressed for middle-click functionality.
- **Side Buttons:** Typically used for forward/backward navigation in web browsers or custom functions in games.

3.2 DPI Adjustment

The Havit MS1032 features six adjustable DPI (Dots Per Inch) settings, allowing you to change the mouse sensitivity on the fly. This is useful for adapting to different tasks, such as precise aiming in games or fast navigation across multiple monitors.

To adjust the DPI, locate the DPI button, typically positioned behind the scroll wheel. Press this button to cycle through the available DPI settings. The LED lighting on the mouse may change to indicate the current DPI level, providing visual feedback for your selection.



Figure 2: Location of the DPI button (behind the scroll wheel).

4. MAINTENANCE

4.1 Cleaning

To maintain optimal performance and appearance, clean your mouse regularly:

- Disconnect the mouse from your computer before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive cleaning solution.
- Gently wipe the surface of the mouse.
- For crevices and the optical sensor, use a cotton swab or compressed air to remove dust and debris.
- Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the mouse's finish or internal components.

4.2 Storage

When not in use, store the mouse in a clean, dry environment away from direct sunlight and extreme temperatures to prevent damage.

4.3 General Care

- Avoid dropping the mouse or subjecting it to strong impacts.
- Do not attempt to disassemble the mouse, as this will void the warranty and may cause irreparable damage.
- Keep the mouse away from liquids to prevent electrical damage.

5. TROUBLESHOOTING

If you encounter issues with your Havit Gaming Mouse MS1032, please refer to the following common solutions:

5.1 Mouse Not Responding

- **Check USB Connection:** Ensure the USB cable is securely plugged into a working USB port on your computer. Try a different USB port.
- **Restart Computer:** Sometimes a simple computer restart can resolve connectivity issues.
- **Test on Another Computer:** If possible, test the mouse on another computer to determine if the issue is with the mouse or your computer's setup.

5.2 Cursor Movement is Erratic or Jumpy

- **Clean Sensor:** Ensure the optical sensor on the bottom of the mouse is clean and free of dust or debris.
- **Check Surface:** Use the mouse on a clean, non-reflective, and uniform surface (e.g., a mouse pad). Avoid glass or highly reflective surfaces.
- **Adjust DPI:** If the cursor is too fast or too slow, adjust the DPI setting using the DPI button.

5.3 Buttons Not Working

- **Check for Obstructions:** Ensure no debris is lodged under the buttons.
- **Software Conflict:** If you have custom mouse software installed, try uninstalling it temporarily to see if it resolves the issue.

5.4 LED Lights Not Working

- **Check Connection:** Ensure the mouse is properly connected to the computer.
- **Power Cycle:** Disconnect and reconnect the mouse to reset its power.

6. SPECIFICATIONS



Figure 3: Havit MS1032 Gaming Mouse design overview.

Feature	Detail
Model	MS1032
Brand	Havit
Dimensions	15 x 8 x 5.2 cm
Weight	200g
DPI Settings	6 adjustable levels
Operating Systems	Linux, Windows 7, Windows XP
Connectivity	Wired USB
Batteries Required	No

7. WARRANTY AND SUPPORT

For detailed warranty information and technical support, please refer to the official Havit website or contact your local retailer where the product was purchased. It is recommended to keep your purchase receipt as proof of purchase for any warranty claims.

Manufacturer: Havit

Model Number: MS1032