

XJD AS006T

XJD Toddler Bike 7-in-1 Tricycle Instruction Manual

Model: AS006T

1. PRODUCT OVERVIEW

The XJD 7-in-1 Toddler Bike is a versatile tricycle and balance bike designed to grow with your child from 12 months to 3 years old. It offers multiple modes to support different stages of development, including pushing mode, tricycle mode, and two-wheel balance bike mode. Constructed with a safety carbon steel frame and durable EVA wheels, it ensures a sturdy and comfortable riding experience both indoors and outdoors.



Figure 1: XJD 7-in-1 Toddler Bike with push handle.

Key Features:

- **7-in-1 Design:** Adapts from a push-along tricycle to a two-wheel balance bike.
- **Adjustable Seat Height:** Seat adjusts from 11.8 inches to 14.2 inches (30-36cm) to accommodate growing children.
- **Adjustable Handlebar Angle:** Allows for comfortable steering for different modes and child heights.
- **Removable Pedals:** Easily convert between tricycle and balance bike modes.
- **Adjustable Push Handle:** Extends from 24.4 inches to 36.2 inches for parental control.
- **Sturdy Construction:** Features a carbon steel frame and durable EVA wheels for stability and longevity.
- **Soft PU Leather Seat:** Provides comfort during use.

2. SAFETY INFORMATION

Please read and understand all safety warnings and instructions before allowing a child to use the XJD

Toddler Bike. Failure to follow these instructions may result in serious injury.

- **Recommended Age:** Suitable for children aged 12 months to 3 years.
- **Supervision:** Always supervise children when they are using the product.
- **Protective Gear:** Ensure the child wears appropriate safety gear, including a helmet, knee pads, and elbow pads, especially when transitioning to balance bike mode.
- **Surface:** Use on flat, smooth, and dry surfaces. Avoid uneven terrain, stairs, or inclines.
- **Traffic:** Do not use in traffic or near motor vehicles.
- **Weight Limit:** Adhere to the maximum weight limit specified in the specifications section.
- **Assembly:** Ensure all parts are correctly assembled and securely fastened before each use.
- **No Sharp Corners:** The product is designed with smooth edges to minimize injury risk.



Figure 2: Smooth design for child safety.

3. SETUP AND ASSEMBLY

The XJD Toddler Bike is designed for easy assembly. Follow these steps to set up your bike.

3.1 Initial Assembly

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify all components listed in

the "What's in the Box" section are present.

2. **Install Handlebar:** Insert the handlebar into the front fork stem. Ensure it is aligned correctly and securely tightened.
3. **Attach Seat:** Slide the seat post into the frame. Adjust the seat height to the lowest position for initial setup.
4. **Attach Rear Wheels (Tricycle Mode):** For tricycle mode, ensure the rear wheels are extended and locked into place.



Figure 3: Visual guide to different bike modes.

3.2 Adjustments

- **Adjustable Push Handle:** The push handle can be adjusted from 24.4 inches to 36.2 inches. Locate the adjustment mechanism on the handle and extend or retract to the desired height, then secure it.




Figure 4: Adjusting the push handle height.

- **Adjustable Seat Height:** The soft PU leather seat can be adjusted from 11.8 inches to 14.2 inches. Loosen the clamp beneath the seat, slide the seat to the appropriate height for your child (feet should be flat on the ground in balance bike mode), and securely tighten the clamp.



Figure 5: Adjusting the seat height.

- **Adjust Handlebar Angle:** The handlebar angle can be adjusted for optimal comfort and control in different modes. Locate the adjustment point near the handlebar stem, adjust the angle, and secure it.



Figure 6: Adjusting the handlebar angle.

- **Detachable Pedals:** The pedals can be easily attached or detached to switch between tricycle and balance bike modes. Push the button on the pedal housing and pull to remove. To attach, align and push until it clicks into place.



Figure 7: Detachable pedals for mode conversion.

4. OPERATING MODES

The XJD Toddler Bike offers multiple configurations to adapt to your child's growth and skill level.

4.1 Pushing Mode (with Push Handle)

Ideal for younger toddlers (12-24 months) who are still developing their motor skills. The push handle allows parents to control the direction and speed, providing stability and safety.



Figure 8: Child enjoying the pushing mode.

4.2 Tricycle Mode (with Pedals)

Once your child is comfortable with steering and has developed leg strength, attach the pedals for traditional tricycle riding. This mode helps in developing coordination and pedaling skills.



Figure 9: Child riding in pedal tricycle mode.

4.3 Two-Wheel Balance Bike Mode

For children aged 2-3 years, convert the tricycle into a two-wheel balance bike by removing the pedals and folding the rear wheels inward. This mode is crucial for teaching balance and preparing children for a traditional bicycle without the need for training wheels.



Figure 10: Conversion to two-wheel balance bike mode.

4.4 Little Three-Wheel Bike Mode

This mode is a variation of the tricycle mode, offering a compact three-wheel setup for early riders to gain confidence and stability before moving to two wheels.

4.5 Official Product Video

Watch the official XJD 7-in-1 Kids Tricycles video for a visual guide on assembly and mode transitions.

Your browser does not support the video tag.

Video 1: XJD 7-in-1 Kids Tricycles demonstration.

5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your XJD Toddler Bike.

- **Cleaning:** Wipe down the frame and components with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Inspections:** Periodically check all bolts, screws, and fasteners to ensure they are tight. Re-tighten if necessary.

- **Wheel Condition:** Inspect the EVA wheels for any signs of wear or damage.
- **Storage:** Store the bike in a dry, cool place away from direct sunlight and extreme temperatures to prevent material degradation.

6. TROUBLESHOOTING

If you encounter any issues with your XJD Toddler Bike, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bike feels unstable.	Loose fasteners or incorrect mode setup.	Ensure all bolts and clamps are securely tightened. Verify rear wheels are locked in place for tricycle mode.
Pedals are difficult to attach/detach.	Misalignment or debris in the mechanism.	Ensure proper alignment. Clear any debris from the pedal attachment points. Apply a small amount of silicone lubricant if needed.
Push handle is wobbly.	Handle not fully extended or locked.	Extend the push handle fully until it clicks into the locked position. Ensure the adjustment clamp is tight.

7. SPECIFICATIONS

Attribute	Detail
Product Dimensions	30 x 30 x 30 inches
Item Weight	10.78 pounds
Model Number	AS006T
Recommended Age	12 months - 3 years
Frame Material	Carbon Steel
Wheel Material	EVA
Seat Material	PU Leather
What's in the Box	1 x Tricycle



Figure 11: Product dimensions overview.

8. WARRANTY AND SUPPORT

XJD is committed to providing high-quality products. If you are not satisfied with your XJD Toddler Bike or have any questions, please feel free to contact us.

For support, please visit the official XJD Store on Amazon: [XJD Store](#)

Please retain your proof of purchase for any warranty claims or support inquiries.