



Manuals.plus /

› Arctic Air /

› Arctic Air Tower+ Evaporative Cooler User Manual

Arctic Air AATPLS-MC2

Arctic Air Tower+ Evaporative Cooler User Manual

Model: AATPLS-MC2 | Brand: Arctic Air

INTRODUCTION

The Arctic Air Tower+ Evaporative Cooler is designed to provide cool, refreshing air for large spaces. Utilizing Hydro-Chill Technology with Mist Boost Mode and six cooling jets, it efficiently transforms hot, dry air into a more comfortable environment. This portable unit features multiple fan speeds, oscillation, an auto-off timer, and an LED night light for enhanced user convenience and comfort. This manual provides essential information for the safe and effective operation and maintenance of your new evaporative cooler.



Figure 1: Arctic Air Tower+ Evaporative Cooler in its retail packaging.

- Always unplug the unit from the power outlet before cleaning, refilling, or performing any maintenance.
- Do not immerse the unit, power cord, or plug in water or other liquids.
- Keep out of reach of children and pets.
- Place the unit on a flat, stable surface to prevent tipping.
- Do not block air vents or operate the unit with a damaged cord or plug.
- Use only clean water in the water tank.

PRODUCT FEATURES

- **Hydro-Chill Technology:** Transforms hot air into cool, refreshing air.
- **Mist Boost Mode:** Enhances cooling with additional mist.
- **4 Fan Speeds:** Low, Medium, High, and Turbo settings for customized airflow.
- **Oscillation:** Evenly disperses cool air across a wide area.
- **Auto-Off Timer:** Programmable timer for 2, 6, 8, or 12 hours.
- **LED Night Light:** Dimmable built-in LED light for convenience.
- **Large Water Tank:** Provides up to 16 hours of cooling depending on settings.
- **Portable Design:** Lightweight with a convenient carry handle.



Figure 2: The Arctic Air Tower+ effectively circulating cool air.




Figure 3: Large area cooling for total comfort in your living space.



Figure 4: Overview of the Arctic Air Tower+ features including fan speeds, night light, and timer.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Assemble Base:** The base comes in two pieces. Line them up and snap them together.
3. **Attach Base to Unit:** Align the assembled base with the bottom of the tower unit. Ensure the power cord is aligned with the designated space in the base. Secure the base by turning it into place until it clicks.
4. **Prepare Filter:** The evaporative air filter is located behind the front grille. Remove the grille to access the filter. Rinse it under cool water before first use. Allow it to dry slightly before reinserting.

5. **Fill Water Tank:** Pull out the water tank drawer located at the bottom rear of the unit. Fill the tank with clean, cool water. For enhanced cooling, you may place the included reusable ice pack into the water tank after freezing. Do not overfill past the MAX line.
6. **Plug In:** Connect the power cord to a standard 120V electrical outlet.



Figure 5: Easy fill water tank for convenient operation.

OPERATING INSTRUCTIONS

The control panel is located on the top of the unit with touch-sensitive buttons.

Touch Controls



Figure 6: Intuitive touch controls for easy operation.

- **Power On/Off:** Press the power button to turn the unit on or off.
- **Fan Speed:** Press the fan icon to cycle through 4 quiet speeds: Low, Medium, High, and Turbo. Indicator lights will show the current speed.
- **Cooling Control (Mist):** Press the snowflake icon to activate or deactivate the misting function. This engages the Hydro-Chill Technology for evaporative cooling.
- **LED Night Light:** Press the sun icon to turn the LED night light on or off. The light can be dimmed by holding the button.
- **Auto-Off Timer:** Press the clock icon to set the auto-off timer. Cycle through 2, 6, 8, or 12 hours. The unit will automatically shut off after the selected time.
- **Oscillation:** Press the oscillation icon to activate or deactivate the oscillating function, allowing the unit to rotate and distribute air more widely.

MAINTENANCE

- **Filter Cleaning:** The evaporative air filter should be cleaned regularly, especially if you notice reduced airflow or an odor. Remove the front grille and slide out the filter. Rinse it under cool water and allow it to air dry completely before reinserting.
- **Water Tank Cleaning:** Periodically empty and clean the water tank to prevent mold or mildew buildup. Use a

mild soap and water solution, then rinse thoroughly.

- **Exterior Cleaning:** Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, empty the water tank, clean the filter, and store the unit in a cool, dry place.

TROUBLESHOOTING

- **Unit Not Turning On:**
 - Ensure the power cord is securely plugged into a working outlet.
 - Check if the power button has been pressed.
- **No Mist/Weak Mist:**
 - Check if the water tank is filled with water.
 - Ensure the Cooling Control (snowflake) button is activated.
 - Clean the evaporative filter as it may be clogged.
- **Reduced Airflow:**
 - Check and clean the evaporative filter.
 - Ensure air intake and output vents are not obstructed.
- **Unusual Noise:**
 - Ensure the unit is on a flat, stable surface.
 - Check for any foreign objects inside the unit.

SPECIFICATIONS

Brand	Arctic Air
Model Name	Arctic Air Tower Plus
Model Number	AATPLS-MC2
Product Dimensions	11.81"D x 11.81"W x 36.81"H
Item Weight	10.4 pounds
Voltage	120 Volts
Power Source	Corded Electric
Reservoir Capacity	1.7 Liters
Floor Area Coverage	100 Square Feet
Noise Level	60.6 dB

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Arctic Air customer service. Keep your purchase receipt for warranty claims.

Customer Service: Please refer to the contact information provided with your product or visit the official Arctic Air

website for support resources.