

[Manuals.plus](#) /

› [A-MIND](#) /

› Oukitel WP19 Screen Replacement Kit User Manual

A-MIND For Oukitel WP19

Oukitel WP19 Screen Replacement Kit User Manual

Model: For Oukitel WP19

Brand: A-MIND

PRODUCT OVERVIEW

This high-quality LCD Display Touch Screen Digitizer Glass Panel Full Assembly Replacement Kit is designed specifically for the Oukitel WP19 smartphone. It is intended to fix common screen issues such as cracks, broken glass, dead pixels, unresponsive touch, display problems, and incorrect colors. This kit provides the necessary components to restore your device's display functionality.

PACKAGE CONTENTS

The A-MIND Oukitel WP19 Screen Replacement Kit includes the following items:

- 1x For Oukitel WP19 LCD Screen + Display Touch Digitizer Assembly Replacement
- 1x Strong Suction Cup
- 2x Triangle Opening Tools
- 1x Card Pin
- 1x Plastic Spudger
- 1x Free Tape



Image: Contents of the Oukitel WP19 screen replacement kit, including the screen assembly and various repair tools.

SPECIFICATIONS

Compatible Model	For Oukitel WP19
Screen Size	6.78 inches
Resolution	2160*1080 pixels
Material	IPS LCD (Not Original AMOLED)
Item Weight	0.16 ounces
Package Dimensions	1 x 1 x 0.1 inches

FOR OUKITEL WP19

1080*2460 Pixels / 6.78 inches/396 ppi



Image: Visual representation of the Oukitel WP19 screen, highlighting its 1080*2460 pixel resolution and 6.78-inch size.

IMPORTANT NOTES BEFORE INSTALLATION

Screen replacement is a delicate procedure. Please read the following notes carefully before attempting installation to prevent damage to the product or your device.

Pre-Installation Testing

- **Test Before Installation:** Do not remove any protective film or tags from the new screen. Connect the new screen assembly to the phone's motherboard (without fully installing it) and power on the device to test its functionality (display, touch response). If the screen does not function correctly, contact customer service immediately. Do not force installation if issues are present.
- **Simulated Testing:** This means connecting the screen to the motherboard without full assembly. If the test is successful, proceed with installation. We are not responsible for issues once the screen is fully installed without prior testing.

Safety Precautions

- **Static Electricity:** Pay attention to static electricity. Before attempting any repair, ensure you ground yourself with an ESD (electrostatic discharge) strap. This prevents static electricity from damaging the phone's electronic components.
- **Eye Protection:** Wear eye protection during the repair process. Use caution to avoid cutting your fingers with glass splinters.

Handling the Flex Cable

- **Do Not Over-Bend:** Ensure the LCD flex cable is not over-bent. Bending it more than 90 degrees can cause a black display or other malfunctions.



Image: A warning indicating that the screen is supplied without a frame, advising professional installation or extreme caution for DIY repairs due to potential damage.



Image: Front and back views of the Oukitel WP19 screen assembly, showing the display panel and the flex cable connections.

INSTALLATION GUIDE

This screen replacement is designed for the Oukitel WP19. While the kit provides the necessary tools, detailed installation instructions are not included in this manual. We strongly recommend searching for installation videos on platforms like YouTube or Google, as visual guides are highly beneficial for this type of repair. If you are not confident in your ability to perform the repair, it is advisable to seek assistance from a professional repair store.

General Steps (Consult video guides for specifics):


1. Power off your device completely and disconnect the battery.
2. Carefully remove the damaged screen assembly.
3. Clean any adhesive residue from the phone frame.
4. Connect the new screen assembly's flex cables to the motherboard.
5. Perform the pre-installation test as described in the 'Important Notes' section.
6. If the test is successful, apply new adhesive (if necessary, not included in kit) and carefully install the new screen into the phone frame.

7. Reconnect the battery and reassemble the phone.



Image: Close-up view emphasizing that the screen has been 100% tested before shipping, showing the quality control process.

100% Tested
one by one before shipping



Details of flex cable

Image: Detailed view of the screen's flex cable, highlighting its connection points and delicate nature, crucial for proper installation.

MAINTENANCE

Once installed, treat your new screen with care to ensure its longevity. Avoid dropping the device, exposing it to extreme temperatures, or applying excessive pressure to the screen. Consider using a screen protector and a protective case for added durability.

TROUBLESHOOTING

If you encounter issues after installation, consider the following common problems and solutions:

- **Black Display:** If the screen remains black after installation, ensure the flex cables are securely connected and not over-bent (bent more than 90 degrees). Recheck connections and ensure the battery is properly connected.
- **Touch Not Working / Unresponsive Touch:** Verify that all flex cables are correctly seated. A loose connection can cause touch issues. Re-test the screen before final installation.
- **Wrong Colors / Display Problems:** This can also be caused by loose or damaged flex cable connections. Ensure the cables are clean and properly aligned.
- **Screen Brightness:** If the screen brightness is lower than expected, ensure all connections are secure. Note that replacement screens may have slight variations in brightness compared to original components.

For persistent issues, refer to online video guides or contact customer support.

WARRANTY AND SUPPORT

We provide a 3-month warranty for this product. All Oukitel WP19 LCD screen replacement products undergo strict quality control and are tested thoroughly before shipment to ensure no scratches, dead areas, pixel defects, or lines on the screen. We strive to provide A+ quality products.

If you have any problems with your order or the product, please contact our customer service team. We are committed to providing assistance within 24 hours. For quality-related issues, as long as the screen has no man-made or physical damage, we can arrange a replacement if it does not function normally.

For further assistance, please visit the product page on Amazon or contact the seller directly.