



[Manuals.plus](#) /

› [EBTOOLS](#) /

› EBTOOLS 2.4G Wireless Keyboard and Mouse User Manual

EBTOOLS B0C28XCD27

EBTOOLS 2.4G Wireless Keyboard and Mouse User Manual

Model: B0C28XCD27

1. INTRODUCTION

Thank you for choosing the EBTOOLS 2.4G Wireless Keyboard and Mouse combo. This product is designed for comfortable and efficient use with its low-noise operation, adjustable DPI settings, and reliable 2.4G wireless connectivity. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance.

Get out of traditional thinking and bold color matching Color aesthetics with depth light up your desk



Image: The EBTOOLS 2.4G Wireless Keyboard and Mouse in mixed color yellow, displayed on a desk alongside a laptop and smartphone, showcasing its design and compact form factor.

2. PACKAGE CONTENTS

- 1 x EBTOOLS 2.4G Wireless Keyboard
- 1 x EBTOOLS 2.4G Wireless Mouse
- 1 x USB Receiver (typically stored in the mouse battery compartment)
- User Manual (this document)

3. SETUP INSTRUCTIONS

3.1. Battery Installation

The keyboard and mouse require batteries for operation. Please ensure you have 1 AA battery for the keyboard and 1 AA battery for the mouse (batteries are not included).

1. Locate the battery compartment on the underside of the keyboard.
2. Open the battery compartment cover.
3. Insert the AA battery according to the polarity indicators (+/-) inside the compartment.
4. Close the battery compartment cover securely.



Image: The underside of the EBTOOLS keyboard with the battery compartment open, showing where to insert the AA battery.

3.2. Connecting the USB Receiver

The keyboard and mouse share a single 2.4G USB receiver for wireless connection.

1. Locate the USB receiver. It is typically stored in the battery compartment of the mouse for safekeeping.
2. Remove the USB receiver from its storage slot.
3. Plug the USB receiver into an available USB port on your computer (desktop PC, laptop, etc.).
4. The system should automatically detect and install the necessary drivers. This is a plug-and-play device.

MULTI-FACETED OFFICE IS NOT TIRED

COMPATIBLE WITH MAJOR SYSTEMS, EASY TO OPERATE, JUST PLUG IT IN



DESKTOP PC



LAPTOP



COMPUTER



Image: A diagram illustrating the compatibility of the keyboard and mouse with various systems, including desktop PCs, laptops, and other computers, highlighting its plug-and-play functionality.

Keyboard and mouse using 2.4G wireless mode, to achieve a connection to connect two devices

Plug and play, desktop and then wireless system



Image: An illustration demonstrating the 2.4G wireless connection mode for the keyboard and mouse, emphasizing the ability to connect two devices wirelessly with a single receiver.

4. OPERATING INSTRUCTIONS

4.1. Adjusting Mouse DPI

The mouse features three adjustable DPI (Dots Per Inch) settings to suit your preference and task requirements. You can cycle through these settings by pressing the DPI button, usually located near the scroll wheel on the mouse.

- **800 DPI:** Suitable for precise tasks or slower cursor movement.
- **1600 DPI:** Standard setting for general use.
- **2400 DPI:** Ideal for faster cursor movement, such as gaming or navigating large screens.

4.2. Using Multimedia Keys

The keyboard is equipped with 18 multimedia keys for quick access to various functions. These keys are typically activated by pressing the **Fn** key in combination with the corresponding function key (F1-F12) or dedicated multimedia keys.

STANDARD LAYOUT FEATURES UNAMBIGUOUS

THE KEYBOARD IS EQUIPPED WITH 18 MULTIMEDIA KEYS, WHICH CAN BE EASILY USED WITH FN
FLEXIBLE AND CONVENIENT INTERFACE CONTROL




Image: A detailed view of the EBTOOLS keyboard layout, highlighting the standard keys and the 18 multimedia keys, along with their respective functions such as volume control, media playback, and quick access to applications.

Common multimedia functions include:

- Volume Down / Up / Mute
- Play / Pause / Previous Track / Next Track
- Home / My Computer / Mail / Favorites
- Other system-specific functions

5. MAINTENANCE

5.1. Cleaning

To maintain the longevity and appearance of your keyboard and mouse:

- Use a soft, dry cloth to wipe down the surfaces.
- For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals.
- Use compressed air to remove dust and debris from between the keyboard keys.


5.2. Battery Replacement

When the keyboard or mouse becomes unresponsive or exhibits intermittent connectivity, it may be time to replace

the batteries. Follow the battery installation steps in Section 3.1.

ENERGY SAVING AND LOW POWER CONSUMPTION

LOWER POWER CONSUMPTION, DOUBLE THE BATTERY LIFE



LONG BATTERY LIFE ENERGY SAVING AND LONG STANDBY TIME, THE EQUIPMENT CONTINUOUSLY ONE BATTERY

PLUG AND PLAY THIS DEVICE IS PLUG AND PLAY, THE BACK OF THE KEYBOARD THE BATTERY COMPARTMENT ALSO INSTALLS THE BATTERY

Image: An illustration depicting the energy-saving features of the keyboard and mouse, emphasizing lower power consumption and extended battery life for continuous use.

6. TROUBLESHOOTING

Problem	Solution
---------	----------

Problem	Solution
Keyboard/Mouse not responding	<ul style="list-style-type: none"> • Ensure batteries are correctly installed and not depleted. Replace if necessary. • Check if the USB receiver is securely plugged into a working USB port. Try a different port. • Move the keyboard/mouse closer to the USB receiver to rule out range issues. • Restart your computer.
Intermittent connection	<ul style="list-style-type: none"> • Avoid placing the receiver near other wireless devices (e.g., Wi-Fi routers, cordless phones) that might cause interference. • Ensure there are no large metal objects between the receiver and the devices. • Replace batteries.
Mouse cursor erratic or not moving smoothly	<ul style="list-style-type: none"> • Clean the mouse sensor area. • Try adjusting the DPI setting (Section 4.1). • Use the mouse on a suitable surface (not highly reflective or transparent).

7. SPECIFICATIONS

Feature	Detail
Brand	EBTOOLS
Color	Mixed Color Yellow
Connectivity Technology	2.4G Radio Frequency Wireless
Special Feature	Low Noise Operation
Compatible Devices	Personal Computer (Desktop PC, Laptop)
Operating System	Major PC Operating Systems
Hand Orientation (Mouse)	Ambidextrous
Batteries Required	Yes (1 AA for keyboard, 1 AA for mouse)
Number of Keys (Keyboard)	104
Power Source	Battery Powered
Keyboard Layout	QWERTY
Mouse DPI Settings	800, 1600, 2400 (Adjustable)
Material	ABS

8. OFFICIAL PRODUCT VIDEOS

8.1. Keyboard and Mouse Overview

Your browser does not support the video tag.

Video: An overview of the EBTOOLS Keyboard and Mouse, demonstrating its features and design. This video is provided by the seller, Zhiyavex-US.

8.2. Yunseity Wireless Keyboard and Mouse Demonstration

Your browser does not support the video tag.

Video: A demonstration of the Yunseity Wireless Keyboard and Mouse, showcasing its functionality and user experience. This video is provided by the seller, Zhiyavex-US.

9. WARRANTY AND SUPPORT

EBTOOLS products are designed for reliability and performance. For any questions, technical support, or warranty inquiries, please refer to the contact information provided with your purchase or visit the official EBTOOLS website. Please retain your proof of purchase for warranty claims.

The product comes with a standard return policy of 30 days from the date of purchase for refund or replacement, as per seller terms.