

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Spigen](#) /

› [Spigen ArcPack 30W 10000mAh Super-Compact USB C Power Bank User Manual](#)

Spigen PA2100

Spigen ArcPack 30W 10000mAh USB C Power Bank User Manual

Model: PA2100

INTRODUCTION

Welcome to the user manual for your Spigen ArcPack 30W 10000mAh Super-Compact USB C Power Bank. This manual provides essential information for setting up, operating, and maintaining your device to ensure optimal performance and longevity. Please read this manual carefully before using the product.

WHAT'S INCLUDED

Your Spigen ArcPack Power Bank package includes the following items:

- Spigen ArcPack USB C Power Bank
- 3.3ft USB-C to USB-C Cable
- Storage Pouch
- User Manual (this document)



Image: The Spigen ArcPack Power Bank shown alongside its included USB-C to USB-C cable, highlighting the complete package contents.

KEY FEATURES

The Spigen ArcPack Power Bank is designed with advanced features for efficient and reliable charging:

- **Compact Powerhouse:** Boasts a generous 10000mAh capacity in a super-compact form factor, making it easy to carry.
- **Lightning-Fast Charging:** Experience PD PPS 30W high-speed charging and recharging capabilities. The Type C port supports 30W Power Delivery 3.0 and 25W PPS.
- **Sleek and Stylish Design:** Its sleek edges and premium materials enhance durability and portability, perfect for travel and daily use.
- **Universal Compatibility:** Compatible with a wide range of devices including iPhone, Galaxy, Apple Vision

Pro, Steam Deck, Nintendo Switch, and more.



Great Portability.



Image: A hand placing the compact Spigen ArcPack Power Bank into a handbag, illustrating its excellent portability for on-the-go use.

Heavy Power.

10,000mAh
PD 30W



USB-C to C Cable is included.

Charging speed and temperature may vary based on network conditions, background apps, usage, and Apple's iOS optimizations.

Image: The Spigen ArcPack Power Bank positioned centrally with a smartphone, tablet, and wireless earbuds around it, showcasing its broad compatibility with different electronic devices.

SETUP

Before first use, it is recommended to fully charge your Spigen ArcPack Power Bank.

Charging the Power Bank

1. Connect the included USB-C to USB-C cable to the power bank's USB-C port.
2. Connect the other end of the cable to a compatible USB Power Delivery (PD) wall charger. For the fastest charging, a 30W or higher PD charger is recommended.
3. The LED indicators on the power bank will illuminate to show the charging progress. All four LEDs will be solid when the power bank is fully charged.

A full charge takes approximately 1.8 hours when using a 30W PD charger.



*USB Power Adapter is not included.

**Ready to Use
Quickly.**



1.8H 100%

Image: The Spigen ArcPack Power Bank connected to a wall adapter on a nightstand, with its indicator lights showing a full 100% charge, ready for use.

OPERATING INSTRUCTIONS

Using your Spigen ArcPack Power Bank to charge your devices is simple and efficient.

Charging Your Devices

1. Connect your device to the power bank's USB-C port using a compatible USB-C cable.
2. The power bank will automatically begin charging your device.
3. The LED indicators on the power bank will show the remaining battery level.

The power bank supports Power Delivery (PD 3.0) up to 30W and Programmable Power Supply (PPS) up to 25W, delivering rapid power replenishment for compatible devices.

Super Fast Charging Available.



Image: The Spigen ArcPack Power Bank actively charging a smartphone, with the phone's display indicating 'Super Fast Charging' and 'PPS 25W', demonstrating its fast charging capability.

Universal Compatibility.



Image: The Spigen ArcPack Power Bank displayed with a variety of popular electronic devices including an iPhone, Samsung Galaxy phone, iPad, and AirPods, emphasizing its broad universal compatibility.

SPECIFICATIONS

Feature	Detail
Product Dimensions	4.1 x 1.9 x 0.9 inches
Item Weight	7.4 ounces
Item Model Number	PA2100
Batteries	1 Lithium Ion batteries required (included)

Connector Type	USB Type C
Brand	Spigen
Battery Capacity	10000 Milliamp Hours
Special Feature	Portable Charger
Voltage	20 Volts
Manufacturer	Spigen Korea Co., Ltd
Date First Available	April 24, 2023

MAINTENANCE

To ensure the longevity and optimal performance of your Spigen ArcPack Power Bank, follow these maintenance guidelines:

- Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid dropping or subjecting the power bank to strong impacts.
- Clean the exterior with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- If not in regular use, charge the power bank at least once every three months to maintain battery health.

TROUBLESHOOTING

If you encounter any issues with your Spigen ArcPack Power Bank, please refer to the following common problems and solutions:

Power Bank Not Charging

- Ensure the charging cable is securely connected to both the power bank and the wall adapter.
- Verify that the wall adapter is functioning correctly and provides sufficient power (30W PD recommended for optimal charging).
- Try using a different USB-C cable or wall adapter to rule out cable/adapter issues.

Device Not Charging from Power Bank

- Ensure the power bank has sufficient charge. Check the LED indicators for remaining battery level.
- Verify the charging cable connecting your device to the power bank is not damaged and is securely connected at both ends.
- Some devices may require specific charging protocols. The Spigen ArcPack supports PD 3.0 and PPS. Ensure your device is compatible.
- If your device is a high-power consumption device (e.g., certain gaming handhelds like ROG Ally), it might draw more power than the power bank can supply during active use, leading to slow charging or even draining. Ensure the device is in a low-power state or off for effective charging.

Slow Charging

- Ensure both the power bank and the device support fast charging protocols (PD/PPS).
- Using a lower wattage wall adapter to charge the power bank will result in slower recharge times.
- Charging speed can be affected by various factors such as network conditions, background applications, device usage during charging, and device-specific software optimizations (e.g., Apple's iOS optimizations).

Power Bank Getting Warm During Use

- It is normal for the power bank to become warm during high-speed charging or discharging, especially when delivering maximum power.
- If the power bank becomes excessively hot to the touch, disconnect it immediately from all devices and power sources and allow it to cool down. If the issue persists, contact customer support.

SAFETY INFORMATION

Please observe the following safety precautions to prevent damage to the product or injury to yourself:

- Do not expose the power bank to water, fire, or extreme temperatures (above 45°C / 113°F or below 0°C / 32°F).
- Do not disassemble, puncture, or modify the power bank. This may cause damage, fire, or explosion.
- Keep out of reach of children.
- Dispose of the power bank responsibly according to local regulations for electronic waste. Do not dispose of it in household trash.
- Avoid using damaged cables or adapters, as this can lead to overheating or malfunction.

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Spigen website or contact their customer service directly. Keep your purchase receipt for warranty claims.

A digital version of this user manual is available for download:

[Spigen ArcPack User Manual \(PDF\)](#)

You can also visit the official Spigen Store on Amazon for more products and information:

[Spigen Store on Amazon](#)