Manuals+

Q & A | Deep Search | Upload

DEERC DE84

DEERC Spider Remote Control Car Instruction Manual

Model: DE84 | Brand: DEERC

INTRODUCTION

Thank you for purchasing the DEERC Spider Remote Control Car. This manual provides essential information for setting up, operating, and maintaining your new RC car. Please read it thoroughly before use to ensure safe and optimal performance.

The DEERC Spider RC Car is a versatile 4WD off-road vehicle designed for exciting stunts and multi-terrain play. Its unique double-sided design allows for 360-degree rotations and flips, providing endless entertainment for users aged 6 and up.



The DEERC Spider Remote Control Car showcasing its dynamic 360-degree rotation capability with vibrant LED lights.

WHAT'S IN THE BOX

- 1 x DEERC Spider Remote Control Car
- 1 x Remote Controller
- 2 x 500mAh Rechargeable Batteries (for car)
- 1 x USB Charging Cable
- 1 x Small Screwdriver (for battery compartment)
- Instruction Manual (this document)



All components included in the DEERC Spider Remote Control Car package.

SETUP

1. Battery Installation

For the Remote Controller:

- 1. Locate the battery compartment on the back of the remote controller.
- 2. Use the provided screwdriver to open the battery cover.
- 3. Insert 2 AA batteries (not included) into the compartment, ensuring correct polarity (+/-).
- 4. Close the battery cover and secure it with the screw.

For the RC Car:

- 1. Locate the battery compartment on the underside of the car.
- 2. Use the provided screwdriver to open the battery cover.

- 3. Connect one of the 500mAh rechargeable batteries to the car's power connector.
- 4. Carefully place the battery and wires into the compartment, ensuring they do not obstruct the cover.
- 5. Close the battery cover and secure it with the screw.

2. Charging the Car Batteries

- Connect the rechargeable battery to the USB charging cable.
- Plug the USB charging cable into a standard USB power adapter (e.g., phone charger, computer USB port).
- The indicator light on the USB cable will show charging status (refer to charger's instructions for specific light behavior).
- Charging typically takes 1-2 hours for a full charge, providing up to 30+ minutes of play time.
- Always supervise charging and disconnect once fully charged.



Rechargeable batteries and USB charging cable for extended play.

3. Pairing the Car and Remote

- Ensure both the car and the remote controller have fresh or fully charged batteries.
- Turn on the RC car using the power switch on its underside.
- Turn on the remote controller using its power switch.
- The remote and car should automatically pair using 2.4GHz technology. A successful connection is usually indicated by a solid light on the remote.

OPERATING INSTRUCTIONS

Basic Controls:

- Use the left joystick to control forward and backward movement.
- Use the right joystick to control turning left and right.

Stunt Features:

• **360-Degree Rotation:** The car can perform continuous 360-degree spins. Experiment with joystick combinations to achieve this.



Experience dynamic 360-degree spins with the DEERC Spider RC Car.

• **Double-Sided Driving:** The unique design allows the car to continue driving even after flipping over, ensuring uninterrupted play.



The car's "Double Mode" allows for seamless driving even when flipped.

• Flips and Tricks: Practice different maneuvers to make the car flip and perform various stunts.

Playing Environment:

• Multi-Terrain Capability: The car is designed with non-slipping rubber tires and dual motors for strong power and grip, allowing it to drive on various terrains such as sand, grass, pavement, stone roads, and carpet.



The "Terrain Challenger" can navigate diverse surfaces.

• Multiplayer Fun: Advanced 2.4GHz remote control technology allows multiple cars to play simultaneously without interference.



Enjoy uninterrupted fun with multiple cars thanks to 2.4GHz anti-interference technology.

Official Product Video:

Your browser does not support the video tag.

Official video demonstrating the DEERC Spider Remote Control Car's features and performance.

MAINTENANCE

- Cleaning: Wipe the car with a soft, dry cloth after each use. Avoid using water or harsh chemicals.
- Battery Care:
 - Always fully charge batteries before storage.
 - Remove batteries from the car and remote if not used for extended periods to prevent leakage.
 - Store batteries in a cool, dry place.
- **Durability:** The car features an ABS rugged structure, providing collision resistance. However, avoid excessive impacts to prolong its lifespan.



The car's robust ABS shell and tough rubber tires ensure durability.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Car not responding to remote.	Low batteries in car or remote; not paired; interference.	Charge/replace batteries. Re-pair car and remote. Move away from other 2.4GHz devices.
Short play time.	Battery not fully charged; old battery.	Ensure battery is fully charged. Use the second provided battery. Consider replacing old batteries.
Car not performing stunts correctly.	Insufficient power; incorrect control input.	Ensure batteries are fully charged. Practice control inputs for specific stunts.
Car moves slowly or inconsistently.	Low battery; debris in wheels/axles.	Charge/replace battery. Clean wheels and axles of any obstructions.

SPECIFICATIONS

• Brand: DEERC

• Model Number: DE84

• Product Dimensions: 8.66 x 6.69 x 3.54 inches

Item Weight: 1.08 poundsCountry of Origin: China

• Manufacturer Recommended Age: 6 years and up

• Car Battery: 2 x 500mAh Rechargeable Batteries (included)

• Remote Battery: 2 x AA batteries (not included)

• Play Time: Up to 30+ minutes (per battery)

• Control Frequency: 2.4GHz

• Motors: Dual Motor

• Features: 360° Rotation, Double-Sided Driving, Colorful LED Lights, All-Terrain Capability, Anti-slip Rubber Tires



The powerful dual motor system allows for speeds of up to 8+ MPH.



Anti-slip rubber tires provide excellent grip on various surfaces.

WARRANTY AND SUPPORT

DEERC is committed to providing high-quality products and excellent customer service. We stand behind our products.

• For quick responsive customer support, please contact us:

• **Phone:** +1 (855) 777-8866 (5:00 PM ~ 8:00 AM PDT)

• Email: usa@deerc.com (USA)

Please retain your proof of purchase for any warranty claims.

© 2024 DEERC. All rights reserved.