

Kipcush K3-S

Kipcush Tibetan Meditation Bowl Sound Machine - User Manual

Model: K3-S | Brand: Kipcush

INTRODUCTION

The Kipcush Tibetan Meditation Bowl Sound Machine (Model K3-S) is designed to create a serene and calming environment for various practices such as yoga, meditation, mindfulness, chakra healing, sound therapy, and stress relief. This compact device offers a selection of authentic singing bowl sounds, customizable light settings, and convenient timer functions to enhance your relaxation experience.



Figure 1: The Kipchush Tibetan Meditation Bowl Sound Machine.

KEY FEATURES

- **7 Singing Bowl Sounds:** Includes 3 different sizes of singing bowl sounds, 2 combination sound bowl sounds, and 2 singing bowl sounds mixed with pink noises.
- **Timer Functions:** Set automatic shut-off timers for 15, 30, 60, 90, or 120 minutes, or allow it to play all night.
- **Setting Memory:** The device remembers the last sound and volume settings upon restart.
- **Easy Touch Control:** Intuitive metal grill touch control for power, sound selection, volume, and night light.
- **Night Light with 7 Colors:** Each of the 7 sounds corresponds to a unique color of ambient light, enhancing the sensory experience.
- **Compact and Portable:** Designed for easy transport to yoga classes, offices, or retreats.

SETUP

1. **Unboxing:** Carefully remove the sound machine and all accessories from its packaging.
2. **Placement:** Place the device on a stable, flat surface in a calm and quiet environment, such as a meditation room, yoga space, or any area where you wish to create a soothing atmosphere.
3. **Power Connection:** Connect the provided power adapter to the DC input port on the device. Plug the adapter into a standard 110V electrical outlet. The device is designed to be powered via a wall outlet.

Your browser does not support the video tag.

Video 1: Overview of the Kipcush Singing Bowl Machine, demonstrating its features and ease of use.

OPERATING INSTRUCTIONS

Power On/Off

- To turn the device on, gently touch the power button located on the control panel.
- To turn the device off, gently touch the power button again.

Sound Selection

The device features 7 distinct singing bowl sounds, including variations with pink noise and natural sounds. Each sound corresponds to a specific light color.

- Press the sound selection button (bell icon) to cycle through the 7 available sounds.
- The device will announce the selected sound number (e.g., "Sound 1").

7 Singing Bowl Sounds





- 
-  3 Separate singing bowl sounds
 -  2 Combined singing bowl sounds
 -  2 Composite white noise singing bowl sounds

Figure 2: The 7 Singing Bowl Sounds available on the device.

Volume Control

- Use the volume up (+) and volume down (-) buttons to adjust the sound level to your preference.

Night Light Control

The device features an integrated night light with 7 corresponding colors for each sound.

- To turn the night light on/off, gently touch the metal grill on the top of the device.
- To adjust the brightness of the night light, use the light intensity buttons (sun icons).

Touch Control Night Light

7 sounds correspond to 7 colors of lights



Figure 3: Touch control for the night light feature.

Timer Functions

The timer allows you to set the duration for the sound to play before automatically turning off.

- Press the timer button (clock icon) to cycle through the available timer options: 15, 30, 60, 90, or 120 minutes.
- The device will announce the selected timer duration.
- If no timer is selected, the device will play continuously until manually turned off.

Auto-off Timer & Memory Function

Remember the last sound volume, light, timer settings



Figure 4: Timer functions for customized play duration.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the device. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the device with care to avoid dropping or physical damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Not properly plugged in; power outlet issue.	Ensure the power adapter is securely connected to the device and the wall outlet. Try a different outlet.
No sound or low volume.	Volume set too low; incorrect sound selected.	Increase the volume using the '+' button. Cycle through sounds to ensure one is active.
Night light not working.	Light function is off; brightness set too low.	Gently touch the metal grill to activate the light. Increase brightness using the light intensity buttons.
Timer not functioning correctly.	Incorrect timer setting.	Ensure the desired timer duration is selected by pressing the timer button until the correct duration is announced.

SPECIFICATIONS

Feature	Detail
Product Dimensions	3.9 x 3.9 x 1.9 inches
Item Weight	15.84 ounces
Model Number	K3-S
Color	White
Material	Plastic
Manufacturer	Kipcush

IMPORTANT INFORMATION

Directions

Place the device in a calm and quiet environment, such as a meditation room, yoga space, or any place where you wish to create a soothing, healing atmosphere.

Legal Disclaimer






Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided with your product packaging or visit the official Kipcush website. Keep your purchase receipt for any warranty claims. You can also visit the [Kipcush Store on Amazon](#) for more information and product offerings.

© 2024 Kipcush. All rights reserved.

Related Documents - K3-S

	<p>Sound Oasis BST-150 Sleep Sound Therapy System Alarm Clock Instruction Manual</p> <p>Comprehensive instruction manual for the Sound Oasis BST-150 Sleep Sound Therapy System Alarm Clock, covering setup, operation, features, sound card descriptions, app integration, technical specifications, and warranty.</p>
	<p>Neurosonic Owner's Guide: Improve Sleep, Reduce Stress, Enhance Recovery</p> <p>Comprehensive guide to using the Neurosonic device for relaxation, stress relief, improved sleep quality, and physical recovery. Learn about programs, usage, safety, and maintenance.</p>
	<p>Inner Engineering: A Yogi's Guide to Joy by Sadhguru</p> <p>Explore the path to inner transformation and lasting joy with Sadhguru's 'Inner Engineering: A Yogi's Guide to Joy'. This guide offers practical yogic principles and tools for self-mastery and enhanced well-being.</p>
	<p>Mindfulness, Bliss, and Beyond: A Meditator's Handbook by Ajahn Brahm</p> <p>Explore Buddhist meditation with Ajahn Brahm's 'Mindfulness, Bliss, and Beyond'. This handbook guides practitioners through techniques for achieving deep states of meditation, overcoming mental hindrances, and cultivating inner peace and profound insight. Features a foreword by Jack Kornfield and published by Wisdom Publications.</p>
	<p>2020-21 Bowl Season Media Guide: A Celebration of College Football</p> <p>Official media guide for the 2020-21 college football bowl season, featuring schedules, participating teams, and historical insights for all bowl games. Discover 'A Celebration of College Football' and its traditions.</p>

Karaoke microphone AT0010 - K3



Instructions for use

TeKKiWear is a registered trademark of TeKKiWear. All other trademarks are the property of their respective owners. TeKKiWear is not responsible for any damage or loss of data caused by the use of this product. TeKKiWear is not responsible for any damage or loss of data caused by the use of this product.



[TeKKiWear Karaoke Microphone AT0010 - K3 User Manual and Specifications](#)

User manual and specifications for the TeKKiWear AT0010 - K3 karaoke microphone, detailing its features, operation, connectivity, and troubleshooting for an enhanced singing experience.