

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BODEGA](#) /

› [BODEGACOOLER 28 Bottle Compressor Wine Cooler User Manual](#)

BODEGA JC-82

BODEGACOOLER 28 Bottle Compressor Wine Cooler User Manual

Model: JC-82 | Brand: BODEGA

1. INTRODUCTION

This user manual provides essential information for the safe and efficient operation of your BODEGACOOLER 28 Bottle Compressor Wine Cooler. Designed for optimal wine preservation, this freestanding mini fridge features advanced compressor cooling, a digital touchscreen, LED display, and split storage capabilities for both red and white wines. Please read this manual thoroughly before installation and use, and retain it for future reference.

2. SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not touch cold surfaces, especially when the appliance is operating.
- Ensure proper grounding. Connect only to properly grounded outlets.
- Do not use extension cords or ungrounded (two-prong) adapters.
- Unplug the appliance before cleaning or making any repairs.
- Keep ventilation openings clear of obstruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. PRODUCT OVERVIEW

The BODEGACOOLER wine cooler is designed to provide an optimal environment for your wine collection. Key features include a robust compressor cooling system, a double-paned thermopane glass door for UV protection, soft LED interior lighting, and removable chrome shelves.



Figure 3.1: Front view of the BODEGACOOLER 28 Bottle Compressor Wine Cooler, showcasing its sleek design and glass door.

Double Glass Door

The glass is also designed to minimize the effect of UV rays on your wine bottles



Figure 3.2: Illustration of the double-paned thermopane glass door, designed to protect wine from harmful UV light.



Figure 3.3: Close-up view of the soft interior LED lighting and the removable chrome shelves, which allow for flexible storage and easy access to bottles.

4. SETUP

4.1 Unpacking

Carefully remove all packaging materials. It is recommended to keep the original packaging for future transport or service needs. Before plugging in the unit, allow it to stand upright for at least 24 hours. This allows the refrigerant fluids to settle, which is crucial for proper compressor function and to prevent damage.

4.2 Placement

This wine cooler is designed for freestanding installation. Ensure there is adequate air circulation around the unit. Maintain a minimum clearance of 2-3 inches (5-7.5 cm) from walls and other appliances to allow for proper heat

dissipation. Avoid placing the unit in direct sunlight or near heat sources such as ovens or radiators. The dimensions of the unit are approximately 16.9"W x 17.7"D x 33.07"H inches.

Great Wine Storage

Fits 750ml standard wine bottles



Figure 4.1: Diagram illustrating the freestanding placement and key dimensions of the wine cooler.



Figure 4.2: Example of the wine cooler placed as a freestanding unit in a kitchen environment.

4.3 Electrical Connection

Connect the appliance to a dedicated, grounded 115V~60Hz electrical outlet. Do not overload the circuit. Ensure the power cord is not pinched or damaged.

5. OPERATING INSTRUCTIONS

5.1 Temperature Control

The wine cooler features a digital touchscreen control panel located on the top of the door. The temperature range is 41°F to 64.4°F (5°C to 18°C). To adjust the temperature, use the up and down arrows on the control panel. Press the temperature setting button to confirm your selection. The LED display will show the current internal temperature.



Figure 5.1: Close-up of the electronic digital thermostat control panel, showing temperature display and adjustment buttons.

5.2 Interior LED Lighting

The soft white LED lighting illuminates the interior of the wine cooler, allowing you to view your collection without opening the door. The light can be turned on or off using the dedicated light button on the control panel.

5.3 Arranging Bottles

The wine cooler is equipped with removable chrome shelves. These shelves can be adjusted or removed to accommodate different bottle sizes and shapes. For optimal air circulation, avoid overcrowding the shelves. The unit is designed to hold up to 28 standard 750ml wine bottles.

6. MAINTENANCE

6.1 Cleaning

Always unplug the wine cooler before cleaning. Clean the interior with a soft cloth dampened with a solution of mild detergent and warm water. The exterior can be wiped with a soft, damp cloth. Do not use abrasive cleaners or solvents. The shelves can be removed and washed separately.

6.2 Automatic Defrosting

This appliance features an automatic defrosting system, eliminating the need for manual defrosting. During the defrost cycle, frost on the evaporator will melt and drain into a drip tray at the back of the unit, where it evaporates.

7. TROUBLESHOOTING

Before contacting customer support, please refer to the following table for common issues and their solutions:

Problem	Possible Cause	Solution
Appliance does not operate.	Not plugged in; circuit breaker tripped; power outage.	Ensure plug is securely in outlet; check circuit breaker; verify power supply.
Temperature is not cold enough.	Door not closed properly; frequent door openings; warm ambient temperature; temperature setting too high.	Ensure door is sealed; minimize door openings; place unit in cooler area; lower temperature setting.
Excessive noise.	Unit not level; vibrating against wall; normal compressor operation.	Adjust leveling feet; ensure clearance from walls; some compressor noise is normal. If noise is unusually loud or constant, contact support.
Interior light not working.	Light switch off; LED bulb failure.	Press the light button on the control panel; contact support for bulb replacement if needed.
Water on floor.	Drain tube clogged or displaced.	Check and clear the drain tube at the back of the unit.

Note: This wine cooler features a built-in smart memory chip. In case of a sudden power failure or reboot, it will restore to the original settings without the need for manual reset.

8. SPECIFICATIONS

Feature	Detail
Brand Name	BODEGA
Model Info	JC-82
Item Weight	56.1 pounds (25.49 Kilograms)

Feature	Detail
Product Dimensions (W x D x H)	16.9" x 17.7" x 33.07" inches
Capacity	28 Bottles / 3.02 Cubic Feet
Annual Energy Consumption	139 Kilowatt Hours
Temperature Range	41°F - 64.4°F (5°C - 18°C)
Power Supply	115V~60Hz
Input Power	85W
Nominal Current	1.2A
Refrigerant	R600a (21g)
Installation Type	Freestanding
Number of Racks	7 (Removable)
Defrost System	Automatic
Door Material Type	ABS+Glass (Double-paned)
Special Features	Digital Touch Control, LED lighting, Smart Memory Chip

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the seller directly. This product is typically supported by ONETREE HOME USA. Additional protection plans may be available for purchase to extend coverage beyond the standard warranty period.

For assistance, you may contact the seller or visit the official BODEGA website for support resources.

Seller: ONETREE HOME USA

Protection Plans: Available (e.g., 2-Year, 3-Year Protection Plans)