

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MISTRAL](#) /

› [MISTRAL Greenleaf MHV880R-G 8-inch DC High Velocity Table Fan User Manual](#)

## MISTRAL MHV880R-G

# MISTRAL Greenleaf MHV880R-G 8-inch DC High Velocity Table Fan User Manual

Model: MHV880R-G

## 1. INTRODUCTION

Thank you for choosing the MISTRAL Greenleaf MHV880R-G 8-inch DC High Velocity Table Fan. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new fan. Please read these instructions thoroughly before use and retain them for future reference.

## 2. SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always observe the following basic safety precautions:

- Ensure the power supply voltage matches the rating label on the fan.
- Do not operate the fan with a damaged cord or plug. If the cord or plug is damaged, contact authorized service personnel.
- Keep the fan away from water or other liquids. Do not immerse the fan in water.
- Do not insert fingers or any objects through the grille when the fan is operating.
- Place the fan on a stable, flat surface to prevent it from tipping over.
- Unplug the fan from the power outlet before cleaning or performing any maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

## 3. PRODUCT OVERVIEW

The MISTRAL Greenleaf MHV880R-G is an 8-inch DC High Velocity Table Fan designed for efficient air circulation. It features multiple speed settings, operating modes, and oscillation functions for personalized comfort.

### 3.1 Components

- Fan Unit (with integrated base)
- Remote Control

- Power Cord

### 3.2 Key Features

- 8 Speed Settings
- 3 Operating Modes (Normal, Natural, Sleep)
- 25W DC Motor
- 8-Hour Timer Function
- Auto-Oscillation: 70° Left-Right and 70° Up-Down
- Adjustable Tilt
- Remote Controlled Operation



Image 1: Front view of the MISTRAL Greenleaf MHV880R-G fan, showing the fan blades behind a wooden-patterned grille and the control panel on the white base.



Image 2: Angled view of the MISTRAL Greenleaf MHV880R-G fan, highlighting its compact design and the wooden-patterned support arm connecting the fan head to the base.

## 4. SETUP

- 1. Unpacking:** Carefully remove the fan and all components from the packaging. Retain packaging for storage or transport if needed.
- 2. Placement:** Place the fan on a firm, level surface. Ensure there is adequate space around the fan for proper air circulation and oscillation. Avoid placing it near curtains or other objects that could obstruct the airflow or get caught in the fan blades.
- 3. Power Connection:** Insert the power plug into a suitable electrical outlet. Ensure the outlet meets the fan's power requirements.

## 5. OPERATING INSTRUCTIONS

The fan can be operated using the control panel on the base or the included remote control.

### 5.1 Control Panel / Remote Control Functions

- Power Button (>):** Press to turn the fan ON or OFF.
- Speed Button (+/- or Speed):** Adjusts the fan speed from 1 to 8. Press '+' to increase speed, '-' to decrease speed.
- Mode Button (Mode):** Cycles through the 3 operating modes: Normal, Natural, and Sleep.
- Oscillation Button (OSC):** Activates or deactivates the automatic oscillation function (70° Left-Right and 70° Up-Down).
- Timer Button (Timer):** Sets the operating timer for up to 8 hours. Each press increases the timer by 1 hour.

## 5.2 Operating Modes

- **Normal Mode:** Provides a constant airflow at the selected speed.
- **Natural Mode:** Simulates natural breeze by varying the fan speed intermittently.
- **Sleep Mode:** Operates at a lower, quieter speed, often gradually decreasing speed over time to promote a comfortable sleeping environment.

## 5.3 Manual Tilt Adjustment

The fan head can be manually tilted up or down to direct airflow as desired. Gently adjust the fan head to the preferred angle.

## 6. MAINTENANCE AND CLEANING

Regular cleaning helps maintain the fan's performance and extends its lifespan.

1. **Before Cleaning:** Always unplug the fan from the power outlet before cleaning.
2. **Exterior Cleaning:** Wipe the exterior surfaces of the fan with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish.
3. **Grille Cleaning:** Use a vacuum cleaner with a brush attachment to remove dust from the front and rear grilles. For more thorough cleaning, the grilles may be removable (refer to specific instructions if provided in a detailed manual, otherwise avoid disassembly).
4. **Storage:** If storing the fan for an extended period, clean it thoroughly and store it in its original packaging or a dust-free environment.

## 7. TROUBLESHOOTING

### Troubleshooting Guide

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply. Power cord not properly connected.	Check if the power plug is securely inserted into the outlet. Ensure the power outlet is functioning.
Fan is not oscillating.	Oscillation function is not activated.	Press the 'OSC' button on the control panel or remote control to activate oscillation.
Remote control is not working.	Batteries are depleted or incorrectly inserted. Obstruction between remote and fan.	Replace batteries with new ones, ensuring correct polarity. Remove any obstructions between the remote control and the fan's receiver.
Reduced airflow or unusual noise.	Dust accumulation on fan blades or grilles.	Unplug the fan and clean the grilles and blades as described in the Maintenance section.

If the problem persists after attempting these solutions, please contact customer support.

## 8. SPECIFICATIONS

### Product Specifications

Feature	Detail

Feature	Detail
Brand	MISTRAL
Model	MHV880R-G
Electric Fan Design	Table Fan
Power Source	Corded Electric
Power Consumption	25W
Number of Speeds	8
Operating Modes	3 (Normal, Natural, Sleep)
Oscillation	70° Left-Right, 70° Up-Down (Auto-Oscillation)
Timer	Up to 8 hours
Included Components	Remote Control
Product Dimensions	27.5D x 23W x 37H centimetres
Color	White
Special Features	Adjustable Tilt, Oscillating, Remote Controlled, Timer
Form Factor	Tabletop


## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or visit the official MISTRAL website. Keep your purchase receipt as proof of purchase for any warranty claims. For further assistance, you may contact MISTRAL customer service through their official channels. Details can typically be found on the product packaging or the brand's website.

© 2023 MISTRAL. All rights reserved.

## Related Documents - MHV880R-G

 <p><b>Mistral 11 Fin Retro Column Heater with Timer</b> Instruction Manual Model: MCAL-11T</p>	<p><a href="#">Mistral 11 Fin Retro Column Heater with Timer Instruction Manual</a></p> <p>Comprehensive instruction manual for the Mistral 11 Fin Retro Column Heater with Timer (Model: MCAL-11T). Covers important safeguards, safety precautions, positioning, heat settings, timer operation, care and cleaning, technical specifications, and warranty information.</p>
--	---

 <p><b>mistral</b> 16" Stand Fan with Remote MSF1679R</p> <p><b>STAND FAN</b></p> <p>Please read this instruction manual thoroughly before operating and keep it for future reference</p>	<p><a href="#"><u>Mistral 16" Stand Fan with Remote MSF1679R - User Manual &amp; Safety Guide</u></a></p> <p>Comprehensive user manual and safety instructions for the Mistral 16" Stand Fan with Remote, model MSF1679R. Learn about assembly, operation, controls, and maintenance.</p>
 <p><b>mistral</b> 16" Stand Fan with Remote MSF1679R</p> <p><b>STAND FAN</b></p> <p>Please read this instruction manual thoroughly before operating and keep it for future reference</p>	<p><a href="#"><u>Mistral 16" Stand Fan with Remote MSF1679R User Manual</u></a></p> <p>User manual for the Mistral 16" Stand Fan with Remote (Model MSF1679R), detailing safety instructions, product parts, assembly, operation via control panel and remote, modes, and maintenance procedures.</p>
 <p><b>mistral</b> 16" DC Stand Fan MSF165TMB</p>	<p><a href="#"><u>Mistral 16" DC Stand Fan MSF165TMB User Manual</u></a></p> <p>Official user manual for the Mistral 16" DC Stand Fan, model MSF165TMB. Includes safety instructions, cleaning and maintenance, parts identification, technical specifications, and operating instructions.</p>
 <p><b>mistral</b> SUP ACTIVE INFLATABLE STAND UP PADDLE BOARD</p> <p>IAN 445850_2307</p>	<p><a href="#"><u>Mistral SUP Active Inflatable Stand Up Paddle Board User Manual</u></a></p> <p>Comprehensive user manual for the Mistral SUP Active inflatable stand up paddle board. Includes setup, inflation, safety, usage, care, and repair instructions.</p>
 <p><b>mistral</b> 16K BTU Portable Aircon with Remote MPAC1600R</p> <p><b>PORTABLE AIR CONDITIONER</b></p> <p>Please read this instruction manual thoroughly before operating and keep it for future reference</p>	<p><a href="#"><u>Mistral 16K BTU Portable Air Conditioner MPAC1600R User Manual</u></a></p> <p>Comprehensive user manual for the Mistral 16K BTU Portable Air Conditioner MPAC1600R, covering safety instructions, technical parameters, parts, controls, operations, installation, Wi-Fi setup, troubleshooting, and maintenance.</p>