

**NETTA 104080**

# NETTA 1950W Electric Stove Heater Model 104080

## User Manual

Your comprehensive guide to safe and efficient operation.

### 1. IMPORTANT SAFETY INSTRUCTIONS

---

Please read all instructions carefully before using this electric stove heater. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the heater is placed on a firm, level surface.
- Do not cover the heater or obstruct the air inlets/outlets. This can cause overheating.
- Keep flammable materials (curtains, furniture, bedding) at least 1 meter (3 feet) away from the heater.
- Do not use this heater in bathrooms, laundry areas, or similar indoor locations where water may be present.
- Unplug the heater when not in use or before cleaning.
- This product is equipped with a built-in thermal cut-off device to prevent overheating. If the heater overheats, it will automatically shut off. Unplug the unit, allow it to cool, and then plug it back in.
- The heater also features tip-over protection. If the unit is accidentally knocked over, it will automatically power off.
- Do not insert any objects into the ventilation or exhaust openings as this may cause an electric shock or fire, or damage the heater.
- Supervise children and pets when the heater is in operation.



Image 1: Safety features including overheating protection and tip-over protection, ensuring safe operation.

## 2. PRODUCT OVERVIEW

The NETTA Electric Stove Heater Model 104080 provides a classic fireplace aesthetic with modern heating capabilities. It features a realistic flame effect and two heat settings, designed for portability and ease of use.



Image 2: Front view of the NETTA Electric Stove Heater, showcasing the realistic flame effect.

# NETTA BLACK 1750W-1950W ELECTRIC STOVE HEATER

SINGLE DOOR WITH REALISTIC FLAME EFFECT



ADJUSTABLE THERMOSTAT



REALISTIC FLAME EFFECT



AUTOMATIC THERMAL CUT-OFF



2 HEAT SETTINGS



ELEGANT DESIGN



Image 3: Overview of the heater's main features, including adjustable thermostat, flame effect, and safety cut-off.

## 3. SETUP AND ASSEMBLY

The NETTA Electric Stove Heater is largely pre-assembled. Minor assembly may be required for attaching the legs.

1. Carefully remove the heater from its packaging.
2. If the legs are not pre-attached, align each leg with the designated mounting points on the base of the heater. Secure them using the provided screws. Ensure all screws are tightened securely for stability.
3. Place the heater on a stable, level, and heat-resistant surface. Ensure there is adequate clearance from walls and other objects (minimum 1 meter / 3 feet).
4. Plug the power cord into a standard electrical outlet. Ensure the outlet voltage matches the heater's requirements (220-240V, 50Hz).

## 4. OPERATING INSTRUCTIONS

The heater features simple controls for flame effect and heat settings.




Image 4: Control panel with switches for flame effect, heat settings, and thermostat dial.

#### 4.1. Flame Effect

- Locate the switch marked with a light bulb icon ( ).
- Flip this switch to the 'ON' position to activate the realistic flame effect.
- Flip the switch to the 'OFF' position to deactivate the flame effect.
- The flame effect can be used independently of the heating function.

#### 4.2. Heat Settings

The heater offers two heat output levels:

- Level I (Low Heat):** Flip the switch marked 'I' to the 'ON' position for a lower heat output.
- Level II (High Heat):** Flip the switch marked 'II' to the 'ON' position for a higher heat output.
- You can use Level I or Level II, but not both simultaneously.

#### 4.3. Adjustable Thermostat



ADJUSTABLE  
THERMOSTAT



Image 5: Thermostat dial for setting desired room temperature.

- The thermostat dial allows you to set your desired room temperature, ranging from 15°C to 36°C.
- Turn the dial clockwise to increase the desired temperature and counter-clockwise to decrease it.
- The heater will operate until the room reaches the set temperature, then cycle on and off to maintain it.

## 5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your heater.

1. Always unplug the heater from the power outlet and allow it to cool completely before cleaning.
2. Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners, polishes, or chemical solvents, as these may damage the finish.
3. Ensure no water enters the interior of the heater.
4. Periodically check the power cord and plug for any signs of damage. If damaged, do not use the heater and contact customer support.
5. For storage, cover the heater to protect it from dust and store it in a dry, cool location.

## 6. TROUBLESHOOTING

If you encounter issues with your NETTA Electric Stove Heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power to the unit, thermal cut-off activated, or tip-over switch activated.	Check if the power cord is securely plugged in. Verify the wall outlet is functional. Unplug the heater, wait 10-15 minutes for it to cool, then plug it back in. Ensure the heater is upright on a stable surface.
No heat output.	Heat settings not selected, thermostat set too low, or thermal cut-off activated.	Ensure Level I or Level II heat switch is engaged. Increase the thermostat setting. Check for obstructions around air vents.
Flame effect not working.	Flame effect switch is off.	Ensure the flame effect switch (light bulb icon) is in the 'ON' position.
Heater makes a noticeable fan noise.	Normal operation of the internal fan for heat distribution.	This is typical for fan-assisted heaters. Ensure vents are clear to prevent strain on the fan.
Thermostat seems temperamental.	Room temperature fluctuations, or sensor obstruction.	Ensure the heater is not placed near drafts or direct sunlight which can affect temperature readings. Allow the heater to run for a period to stabilize room temperature.

If the problem persists after attempting these solutions, please contact NETTA customer support.

## 7. SPECIFICATIONS

---

Detailed technical specifications for the NETTA Electric Stove Heater Model 104080.



Image 6: Physical dimensions and weight of the electric stove heater.

Feature	Detail
Brand	NETTA
Model Number	104080
Power Source	Corded Electric
Heat Output	1950 Watts
Voltage	220-240V, 50Hz (typical for EU/UK)
Product Dimensions (L x W x H)	35 cm x 21.5 cm x 44 cm
Weight	4.5 kg
Material	Plastic
Finish Type	Matte Black
Installation Type	Freestanding

Feature	Detail
Special Features	Flame Effect, Portable, Adjustable Thermostat, Automatic Thermal Cut-off, Tip-Over Protection
Thermostat Range	15°C - 36°C

## 8. WARRANTY AND SUPPORT

Your NETTA Electric Stove Heater Model 104080 comes with a 365-day warranty from the date of purchase.

For warranty claims, technical support, or any questions regarding your product, please contact NETTA customer service through their official website or the retailer where the product was purchased. Please have your model number (104080) and proof of purchase ready.

© 2024 NETTA. All rights reserved.

### Related Documents - 104080

 <p><b>STOVE HEATER</b></p> <p>NETTA</p> <p>RATED POWER: 1500W HEAT SETTINGS: TWO THERMAL CUT OFF FLAME EFFECT</p> <p>EN USER INSTRUCTION &amp; OPERATION MANUAL</p>	<p><a href="#"><u>NETTA SF-1519 Stove Heater: User Instruction and Operation Manual</u></a></p> <p>This manual provides comprehensive instructions for operating and maintaining the NETTA SF-1519 Stove Heater. It includes essential safety warnings, details on heat settings (1750W-1950W), thermostat control, cleaning procedures, and warranty information. Learn how to safely use your electric stove heater for domestic indoor use.</p>
 <p><b>PTC FAN HEATER</b></p> <p>NETTA</p> <p>RATED POWER: 2000W THREE HEAT SETTINGS OVERHEAT PROTECTION OVER-VOLTAGE PROTECTION</p> <p>EN USER INSTRUCTION &amp; OPERATION MANUAL</p>	<p><a href="#"><u>NETTA PTC Fan Heater NT20-20A: User Manual and Operation Guide</u></a></p> <p>Official user manual for the NETTA PTC Fan Heater, model NT20-20A. Provides detailed instructions on safe operation, features, troubleshooting, maintenance, and product specifications. Includes information on warranty and disposal. Suitable for domestic use.</p>
 <p><b>2500W OIL HEATER</b></p> <p>NETTA</p> <p>RATED POWER: 2500W FIRE-STOP THERMOCOUPLE POWER SETTINGS: 3</p> <p>EN USER INSTRUCTION &amp; OPERATION MANUAL</p>	<p><a href="#"><u>NETTA 2500W Oil Heater: User Manual, Operation &amp; Safety Guide</u></a></p> <p>Comprehensive user manual for the NETTA 2500W Oil Heater (Model ZOH207-1125T). Includes safety warnings, assembly instructions, operating procedures, timer settings, maintenance tips, and disposal information.</p>

<p><b>NETTA 700W SPRAY GUN</b></p>  <p><b>NETTA</b> 700W SPRAY GUN</p> <p><b>EN USER INSTRUCTION &amp; OPERATION MANUAL</b></p> <p><b>EN</b></p> <p><b>NETTA</b> 700W SPRAY GUN</p> <p><b>HATCH CAPACITY</b> 1.5L</p> <p><b>VOLTAGE</b> 220V</p> <p><b>CABLE LENGTH</b> 5 METERS</p> <p><b>PARTS &amp; ACCESSORIES</b></p>	<p><a href="#"><b>NETTA 700W Spray Gun User Manual: Operation, Safety &amp; Troubleshooting</b></a></p> <p>Comprehensive guide for the NETTA 700W Spray Gun (PLD3040A). Includes detailed instructions on operation, safety precautions, cleaning, maintenance, and troubleshooting for optimal performance.</p>
<p><b>NETTA ICE MAKER</b></p>  <p><b>NETTA</b> ICE MAKER</p> <p><b>EN USER INSTRUCTION &amp; OPERATION MANUAL</b></p> <p><b>EN</b></p> <p><b>NETTA</b> ICE MAKER</p> <p><b>WATER CAPACITY</b> 1.2L</p> <p><b>DAYWISE CAPACITY</b> 12KG</p> <p><b>KILOGRAM CAPACITY</b> 150W</p> <p><b>BATTERIE VIE</b></p>	<p><a href="#"><b>NETTA IMB1000-GS Ice Maker User Manual and Operation Guide</b></a></p> <p>This user manual provides comprehensive instructions for the NETTA IMB1000-GS Ice Maker. It covers safety precautions, operating procedures, cleaning and maintenance, troubleshooting common issues, spare parts, product disposal, and warranty information. Key features include a 1.2L water capacity, 12KG daily ice output, and 150W power consumption.</p>
<p><b>NETTA 12L COMPACT DEHUMIDIFIER</b></p>  <p><b>NETTA</b> 12L COMPACT DEHUMIDIFIER</p> <p><b>EN USER INSTRUCTION &amp; OPERATION MANUAL</b></p> <p><b>EN</b></p> <p><b>NETTA</b> 12L COMPACT DEHUMIDIFIER</p> <p><b>Power Cable</b> 1.5M</p> <p><b>Product Weight</b> 12KG</p> <p><b>Size</b> 120x40x30 CM</p> <p><b>Room Coverage</b> 50-120M<sup>2</sup></p> <p><b>Please keep this manual safe for future reference!</b></p>	<p><a href="#"><b>NETTA 12L Compact Dehumidifier User Manual and Operation Guide</b></a></p> <p>Comprehensive user manual and operation guide for the NETTA 12L Compact Dehumidifier, covering safety, installation, operation, maintenance, troubleshooting, and warranty information.</p>