

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [XIAOMI](#) /

› [Xiaomi Redmi Buds 4 Active User Manual](#)

XIAOMI M2232E1

Xiaomi Redmi Buds 4 Active User Manual

Model: M2232E1 | Brand: XIAOMI

INTRODUCTION

This manual provides detailed instructions for the use and maintenance of your Xiaomi Redmi Buds 4 Active. Please read it carefully before using the product to ensure proper operation and longevity.

KEY FEATURES

- **Advanced Bluetooth® 5.3:** Ensures stable and efficient wireless connectivity.
- **12mm Dynamic Driver:** Delivers rich and immersive audio quality.
- **Google Fast Pair:** Enables quick and seamless pairing with compatible Android devices.
- **Up to 28 Hours Long Listening Time:** Combined battery life with the charging case.
- **Noise Cancellation (for calls):** High-sensitivity microphone reduces ambient background noise for clear communication.
- **Intuitive Touch Controls:** Manage calls, music playback, and activate low-latency gaming mode with simple touches.
- **Low Latency Gaming Mode:** Reduces audio delay for an improved gaming experience.
- **Compact Design:** Ergonomically designed for comfortable wear.

PRODUCT OVERVIEW



Figure 1: Xiaomi Redmi Buds 4 Active earbuds in their open charging case, showing both earbuds.



Figure 2: Xiaomi Redmi Buds 4 Active charging case, closed, highlighting its compact and sleek black design.



Figure 3: Two Xiaomi Redmi Buds 4 Active earbuds with water droplets, demonstrating their water resistance.



Figure 4: Xiaomi Redmi Buds 4 Active charging case with a white USB-C cable plugged in, indicating charging.

SETUP

- Charging:** Before first use, fully charge the earbuds and the charging case. Connect the USB-C cable to the charging port on the case and a power source. The indicator light will show charging status.
- Initial Pairing:**
 - Open the charging case. The earbuds will automatically enter pairing mode.
 - On your device (smartphone, tablet, etc.), enable Bluetooth.
 - Search for "Redmi Buds 4 Active" in the list of available Bluetooth devices and select it to connect. For Android devices, Google Fast Pair will simplify this process by showing a pop-up notification.
 - Once connected, a confirmation sound will play.
- Wearing the Earbuds:** Insert the earbuds into your ears and gently rotate them until they fit snugly and comfortably.

OPERATING INSTRUCTIONS

Touch Controls

The Redmi Buds 4 Active feature intuitive touch controls on the back of each earbud. The following actions can be performed:

Action	Function
Single Tap	Answer/End Call, Play/Pause Music

Action	Function
Double Tap	Next Track, Reject Call
Triple Tap	Previous Track
Long Press (2 seconds)	Activate Voice Assistant
Long Press (both earbuds simultaneously)	Toggle Low Latency Gaming Mode On/Off

Low Latency Gaming Mode

To enhance your gaming experience, the Redmi Buds 4 Active offer a low latency mode. Activate or deactivate this mode by long-pressing both earbuds simultaneously. This reduces audio delay, providing better synchronization between audio and video during gameplay.

Call Management

The high-sensitivity microphone with noise reduction ensures clear communication during calls, even in noisy environments. Use the single tap to answer or end calls, and double tap to reject incoming calls.

Your browser does not support the video tag.

Video 1: An overview of the Xiaomi Redmi Buds 4 Active, highlighting key features like Bluetooth 5.3, 12mm dynamic drivers, Google Fast Pair, and touch controls. It also demonstrates the noise reduction for calls and low latency gaming mode.

MAINTENANCE

- Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Water Resistance:** The earbuds are water-resistant. Avoid prolonged exposure to water or submersion. Dry thoroughly if exposed to moisture.
- Battery Care:** To preserve battery life, avoid fully discharging the earbuds and case frequently. Charge them regularly.

TROUBLESHOOTING

Problem	Solution
Earbuds not pairing	Ensure Bluetooth is enabled on your device. Place earbuds in the case, close, then open again to re-enter pairing mode. Forget the device on your phone and try pairing again.
No sound from one earbud	Check battery level of both earbuds. Try resetting the earbuds (refer to manufacturer's website for specific reset instructions if not in manual).
Low volume	Adjust volume on both your device and through earbud controls. Ensure earbuds are properly seated in your ears.
Charging issues	Ensure the charging cable and power source are working. Clean the charging contacts on both the earbuds and the case.

Problem	Solution
Poor call quality	Ensure the microphone is not obstructed. Move to a quieter environment if possible.

SPECIFICATIONS

Feature	Detail
Model Name	M2232E1
Connectivity Technology	Bluetooth 5.3
Audio Driver Type	12mm Dynamic Driver
Charging Time (with case)	Up to 28 Hours Listening Time
Bluetooth Range	10 Meters
Control Method	Touch
Item Weight	42 Grams (total) / 1.48 ounces
Product Dimensions	0.89 x 1.22 x 0.82 inches
Color	Black
Noise Control	Active Noise Cancellation (for calls)


WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official XIAOMI website. Keep your proof of purchase for warranty claims.

You can also visit the [Xiaomi Store on Amazon](#) for more product details and support resources.

© 2023 XIAOMI. All rights reserved.

Related Documents - M2232E1

	<p>Redmi Buds 4 Active User Manual</p> <p>User manual for the Redmi Buds 4 Active wireless earphones, detailing product overview, charging, wearing instructions, connection methods, function overview, specifications, and safety information.</p>
	<p>Redmi Buds 4 Active User Manual</p> <p>User manual for the Xiaomi Redmi Buds 4 Active wireless earphones, covering setup, usage, features, specifications, and safety information.</p>



[Manuel d'utilisation Xiaomi Redmi Buds 4 Active](#)

Manuel d'utilisation complet pour les écouteurs sans fil Xiaomi Redmi Buds 4 Active. Guide d'installation, utilisation, fonctionnalités, spécifications techniques et consignes de sécurité.

Redmi Buds 5

Обзор продукта

Перед использованием внимательно прочтите данный руководство и сохраните его для дальнейшего использования.



Содержимое пакета



Первый раз использую




Достаньте наушники




Утомительный



Зарядка



Включение



Выключение



Первое подключение



Подключение двух устройств



Отключено



Автоматическое подключение



Восстановление заводских настроек



Обзор функций

Если наушники не работают при сенсорном управлении, наушники могут не работать при прикосновении к ним.



Соединение с приложением

1. Сканируйте QR-код при закрытии и установке наушников. Активируйте, чтобы выполнить дополнительные функции.

2. Следуйте инструкциям в приложении, чтобы подключить наушники.



(Android & iOS)

Отсканируйте QR-код, чтобы загрузить приложение Холм Гарнитура.

Примечание: В некоторых приложениях убедитесь, что функция Bluetooth на смартфоне включена. Пожалуйста, находим в чехол зарядку, чтобы крышка и убедитесь, что наушники находятся рядом с чехлом.



[Redmi Buds 6 Active User Manual - Xiaomi Wireless Earphones](#)

User manual for the Xiaomi Redmi Buds 6 Active wireless earphones, detailing setup, features, specifications, safety guidelines, and warranty information.



Redmi Buds 6 Active User Manual

[Redmi Buds 6 Active User Manual: Setup, Features, and Safety Guide](#)

Comprehensive user manual for Xiaomi Redmi Buds 6 Active wireless earphones, covering product overview, package contents, setup, wearing, charging, connectivity, functions, specifications, safety information, and warranty details.