

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [RIENOK](#) /

› [RIENOK S1 Mini Portable Bluetooth Speaker User Manual](#)

## RIENOK S1 Mini

# RIENOK S1 Mini Portable Bluetooth Speaker User Manual

Model: S1 Mini | Brand: RIENOK

## INTRODUCTION

---

Thank you for choosing the RIENOK S1 Mini Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read these instructions carefully before use.

## PACKAGE CONTENTS

---

Verify that all items are present in your package:

- RIENOK S1 Mini Portable Bluetooth Speaker (x1 or x2, depending on purchase)
- USB-C Charging Cable
- 3.5mm AUX Audio Cable
- Lanyard
- User Manual

# Portable Speaker Perfect for Hiking



Image: The RIENOK S1 Mini speaker, USB-C charging cable, 3.5mm AUX cable, and user manual are included in the package.

## PRODUCT OVERVIEW

---

Familiarize yourself with the speaker's buttons and ports for easy operation.

### Controls and Ports

- **Power Button:** Press and hold to turn on/off. Short press to change RGB light modes.
- **Bluetooth Button:** Short press to enter Bluetooth pairing mode.
- **Volume Up (+):** Increase volume.
- **Volume Down (-):** Decrease volume.
- **Play/Pause Button:** Play or pause audio. Answer/end calls.
- **Bass Boost Button:** Enhance bass output.
- **USB-C Port:** For charging the speaker.
- **Micro SD Card Slot:** Insert a Micro SD card for direct audio playback.
- **AUX-In Port:** Connect external audio devices via 3.5mm cable.

# Decent Bass

With Bass Boost Button



Image: The speaker highlights its Bluetooth, TF Card, Aux-in, Bass Boost, Type-C charging, and hands-free call features.

## SETUP

---

### Initial Charging

Before first use, fully charge the speaker using the provided USB-C cable and a compatible power adapter (not included). The LED indicator will show charging status.

### Bluetooth Pairing

1. Ensure the speaker is charged.
2. Press and hold the Power button to turn on the speaker. The LED light will illuminate.
3. Press the Bluetooth button. The speaker will enter pairing mode, indicated by a flashing LED.
4. On your device (smartphone, tablet, laptop), enable Bluetooth and search for "RIENOK S1 Mini" in the list of available devices.
5. Select "RIENOK S1 Mini" to connect. A confirmation sound will indicate successful pairing.

The speaker features Bluetooth 5.3 for a stable and extended wireless range.

## OPERATING INSTRUCTIONS

---

## Power On/Off

- To power on, press and hold the Power button for 2-3 seconds.
- To power off, press and hold the Power button for 2-3 seconds.

## Volume Control

- Press the "+" button to increase volume.
- Press the "-" button to decrease volume.

## Music Playback

- Press the Play/Pause button to play or pause the current track.
- Double-press the "+" button for the next track.
- Double-press the "-" button for the previous track.

## RGB Light Modes

Short press the Power button to cycle through different RGB breathing light modes. The lights change color with the music's rhythm.

## Bass Boost Function

Press the dedicated "Bass" button to activate or deactivate the bass boost feature for deeper sound.

# 30W Powerful Sound



Image: The Bass Boost button on the speaker's control panel is shown.

## Hands-Free Calling

- When a call comes in, press the Play/Pause button to answer.
- During a call, press the Play/Pause button to end the call.

## Micro SD Card Playback

Insert a Micro SD card (up to 32GB, formatted to FAT32) into the designated slot. The speaker will automatically switch to Micro SD card mode and begin playing audio files (MP3, WMA, WAV, FLAC, APE formats supported).

## AUX-In Mode

Connect an external audio device (e.g., MP3 player, computer) to the speaker's AUX-In port using the 3.5mm audio cable. The speaker will automatically switch to AUX mode.

## TRUE WIRELESS STEREO (TWS) PAIRING

---

If you have two RIENOK S1 Mini speakers, you can pair them together for a true wireless stereo experience.

1. Ensure both speakers are powered off.
2. Turn on both speakers. They will automatically enter Bluetooth pairing mode.
3. On one of the speakers (this will be your primary speaker), double-press the Bluetooth button. The speakers will attempt to connect to each other.
4. Once successfully paired, you will hear a confirmation tone, and the LED indicators on both speakers will synchronize.
5. Now, connect your device to the primary speaker via Bluetooth as described in the "Bluetooth Pairing" section.



Image: Two RIENOK S1 Mini speakers are shown wirelessly paired, providing a stereo sound experience from a single smartphone.

## CHARGING

---

The RIENOK S1 Mini speaker is equipped with a 3600mAh battery, providing up to 30 hours of playtime (actual playtime varies by volume level and audio content).

- Connect the provided USB-C cable to the speaker's charging port and the other end to a USB power source (e.g., wall adapter, computer USB port).
- The LED indicator will show the charging status. It will typically turn off or change color once fully charged.



Image: The RIENOK S1 Mini speaker is depicted with an indicator showing its 30-hour playtime capability.

## MAINTENANCE

---

To ensure the longevity and performance of your RIENOK S1 Mini speaker:

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Water Resistance:** The speaker is IPX7 waterproof, meaning it can withstand immersion in water up to 1 meter for 30 minutes. Ensure the charging port cover is securely closed before exposure to water. Do not expose to saltwater or other chemicals.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge regularly.



Image: The RIENOK S1 Mini speaker is shown with water splashing on it, illustrating its IPX7 waterproof capability.

## TROUBLESHOOTING

---

If you encounter issues with your speaker, refer to the following common solutions:

Problem	Solution
Speaker does not turn on.	Ensure the battery is charged. Connect to a power source and try again.
Cannot pair via Bluetooth.	Make sure the speaker is in pairing mode (flashing LED). Disable and re-enable Bluetooth on your device. Move closer to the speaker.
No sound or low volume.	Check volume levels on both the speaker and your connected device. Ensure the speaker is not muted. If using AUX, check cable connection.

Problem	Solution
TWS pairing fails.	Ensure both speakers are fully charged and within close proximity. Follow TWS pairing steps carefully. Disconnect any existing Bluetooth connections before attempting TWS pairing.
Sound distortion.	Reduce the volume on both the speaker and your device. Ensure the audio source is of good quality.

## SPECIFICATIONS

Feature	Detail
Model Name	RIENOK Portable Bluetooth Speaker 30W Dual Pairing
Speaker Type	Outdoor
Special Feature	Portable
Compatible Devices	Smartphone, Tablet, Laptop
Surround Sound Channel Configuration	2.1
Waterproof Rating	IPX7
Control Method	App (implied, but primarily physical buttons)
Wireless Communication Technology	Bluetooth 5.3
Speaker Size	19 Centimeters
Power Source	Battery Powered
Battery Capacity	3600 Milliamp Hours
Speaker Maximum Output Power	30 Watts
Connectivity Technology	Auxiliary, Bluetooth, USB (for charging)
Audio Output Mode	Stereo
Mounting Type	Freestanding
Specific Uses For Product	Outdoor activities, pool, beach, parties

## SAFETY INFORMATION

- Do not disassemble, repair, or modify the speaker.
- Keep away from extreme temperatures, direct sunlight, and heat sources.
- Do not expose to open flames.
- Use only the provided charging cable.
- Keep out of reach of children.

- Dispose of the product responsibly according to local regulations.

## WARRANTY AND SUPPORT

---

The RIENOK S1 Mini Portable Bluetooth Speaker comes with a **Limited Warranty**. For detailed warranty terms, conditions, and customer support, please refer to the warranty card included in your package or visit the official RIENOK website.