



[Manuals.plus](#) /

> [NOPAARD](#) /

> NOPAARD 60-Inch Smart Ceiling Fan with Lights (Model 60-YJ682) Instruction Manual

NOPAARD 60-YJ682

NOPAARD 60-Inch Smart Ceiling Fan with Lights (Model 60-YJ682) Instruction Manual

Your guide to installation, operation, and maintenance.

[Safety Information](#)

[Package Contents](#)

[Installation](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

INTRODUCTION

Thank you for choosing the NOPAARD 60-Inch Smart Ceiling Fan. This manual provides essential information for the safe installation, efficient operation, and proper maintenance of your new ceiling fan. Please read all instructions carefully before beginning installation and retain this manual for future reference.

This smart ceiling fan features a quiet DC motor, 6 adjustable speeds, dimmable LED lighting with color temperature control (3000K warm yellow, 4000K bright daylight, 5000K cool white), and multiple control options including remote, Tuya App, Alexa, and Google Assistant voice commands. Its reversible dual-direction fan function ensures comfort year-round.

SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these instructions:

1. Read all instructions and safety information before installing your new fan.
2. All electrical wiring must be performed by a qualified electrician in accordance with national and local electrical codes.
3. Disconnect power at the main circuit breaker before installation or servicing.
4. The mounting bracket must be securely fastened to the building structure or a ceiling fan rated outlet box capable of supporting the fan's weight (minimum 35 lbs).
5. Ensure the fan blades are at least 7 feet (2.1 meters) from the floor and 30 inches (76 cm) from any wall or obstruction.
6. Do not operate the fan if there are any signs of damage.
7. Do not insert objects into the path of the fan blades.

PACKAGE CONTENTS

Carefully unpack your ceiling fan and inspect the contents. Ensure all parts are present and undamaged. If any parts are missing or damaged, contact customer service.



Image: All components of the NOPAARD 60-Inch Smart Ceiling Fan laid out on a surface, including blades, motor, downrods, remote, and mounting hardware.

- Motor Assembly
- Fan Blades (3x)
- Downrods (6-inch and 10-inch)
- Mounting Bracket
- Canopy & Canopy Cover
- Light Kit & Light Cover
- Remote Control & Wall Mount
- Hardware Pack (screws, wire nuts, washers)
- Instruction Manual

INSTALLATION

Professional installation is recommended for electrical components. Ensure power is disconnected at the circuit breaker before proceeding.

1. Mounting the Ceiling Bracket

Securely attach the mounting bracket to a ceiling joist or a fan-rated outlet box using the provided screws. Ensure the bracket is firmly in place to support the fan's weight.

Video: Demonstrates the process of installing the ceiling mounting bracket, including securing it to the ceiling and preparing the electrical wiring.

2. Assembling the Fan Blades

Attach the fan blades to the motor assembly. Ensure all screws are tightened securely. The fan blades are reversible, offering different aesthetic options (natural wood or white).



Image: Illustrates the reversible fan blades, showing airflow direction for both winter (updraft) and summer (downdraft) modes.

3. Downrod Selection and Assembly

Choose the appropriate downrod (6-inch or 10-inch) based on your ceiling height. The fan also supports flush mounting for ceilings lower than 9 feet or vaulted/sloped ceilings less than 20 degrees.

Quick Guide for Selecting Downrod

Ceiling Height	Downrod Length
9 feet	Included 5 to 10 inches
10 feet	15 inches
11 feet	15 to 24 inches
12 feet	36 inches
13 feet	48 inches
14 feet	60 inches
15 feet	72 inches

Thread the electrical wires through the chosen downrod and secure the downrod to the motor assembly. Ensure the safety pin is correctly inserted.

Video: Detailed steps for downrod installation, including threading wires and securing components.

4. Hanging the Fan and Electrical Connections

Carefully lift the fan assembly and hang it onto the ceiling mounting bracket. Make all necessary electrical connections (Live, Neutral, Ground) using wire nuts. Ensure all connections are secure and properly insulated.

Suitable for Different Height and Angle



DOWNROD OPTION



MOUNTING OPTION



Flat Ceiling



Sloped Ceiling $\leq 20^\circ$

IDEAL ROOM SIZES

 200-400 SQ.FT

DAMP RATING



Dry Location



Covered Damp Location

Image: Diagram showing the fan's dimensions, downrod options (6-inch and 10-inch), and suitable mounting types (flat ceiling, sloped ceiling $< 20^\circ$).

5. Installing the Light Kit

Connect the light kit wires to the fan's designated light kit wires. Secure the light kit to the fan's motor housing. Finally, attach the light cover by twisting it clockwise until it locks into place.



Image: Demonstrates the dimmable LED light feature, showing different color temperatures (3000K, 4000K, 5000K) and brightness levels.

OPERATING INSTRUCTIONS

Your NOPAARD Smart Ceiling Fan offers multiple convenient control methods.

Remote Control

The included remote control allows full functionality of your fan and light. Insert 2 AAA batteries (included) into the remote.

- **Power On/Off:** Press the power button to turn the fan and light on or off.
- **Fan Speed:** Select from 6 variable speeds (1-6) to adjust airflow.
- **Light Control:** Turn the LED light on/off, adjust brightness (0%-100%), and change color temperature (3000K, 4000K, 5000K).
- **Reverse Function:** Activate the dual-direction fan for summer cooling (downdraft) or winter heat circulation (updraft).
- **Timer:** Set the fan to turn off automatically after 2 or 4 hours.

App Control (Tuya App)


Download the Tuya Smart App from your smartphone's app store. Follow the in-app instructions to connect your NOPAARD Smart Ceiling Fan to your home Wi-Fi network (2.4GHz only). Once connected, you can control all fan functions from anywhere in your house.

Voice Control (Alexa & Google Assistant)

Integrate your NOPAARD Smart Ceiling Fan with Amazon Alexa or Google Assistant devices. Enable the Tuya Smart skill/action in your smart home app and link your accounts. You can then use voice commands to control fan speed, light settings, and turn the fan on/off.



4 WAYS TO CONTROL
60" INDOOR OUTDOOR CEILING FAN

-  Remote Control
-  TUYA APP Control
-  Voice Control
-  Wall Control

NOTE: Can only turn on/off the fan and lights together, can not operate them separately and can not adjust.


-  2.4GHz Wifi
-  Amazon Alexa
-  Google Assistant
-  Tuya App

Image: Visual representation of the four control methods: Remote Control, TUYA APP Control, Voice Control (Alexa & Google Assistant), and Wall Control (Note: Wall control functionality may vary).

35DB RUNS IN MUTE MODE

Super Quiet - soft and even wind allows you to enjoy a good sleep.



Quiet
35dB



Timers
2H



Sleep
Mode

Quiet 35dB



fallen leaves

our fan light

talk softly

Image: Illustrates the fan's quiet operation (less than 35dB) with features like timers and sleep mode for undisturbed rest.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your NOPAARD Smart Ceiling Fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents.
- **Tighten Screws:** Periodically check all screws on the fan blades and mounting hardware to ensure they are tight. Loose screws can cause wobbling or noise.
- **No Lubrication Needed:** The DC motor is permanently lubricated and does not require additional oiling.

TROUBLESHOOTING

If you experience issues with your fan, refer to the following common problems and solutions:

Common Issues & Solutions

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low	Check circuit breaker; Verify all wire connections; Replace remote control batteries.
Fan wobbles	Loose blade screws; Improperly mounted bracket; Unbalanced blades	Tighten all blade screws; Ensure mounting bracket is secure; Use balancing kit (not included) if necessary.
Noisy operation	Loose screws; Motor housing rubbing; Incorrect installation	Check and tighten all screws; Ensure no parts are rubbing; Re-check installation steps.
Light does not work	Loose light kit connection; Faulty LED driver	Check light kit wiring connections; Contact customer service for replacement parts.
Remote not responding	Low battery; Remote not paired	Replace remote batteries; Refer to remote pairing instructions in the full manual.

SPECIFICATIONS

- **Brand:** NOPAARD
- **Model Name:** 60-YJ682
- **Size:** 60 Inch
- **Number of Blades:** 3
- **Power Source:** DC
- **Voltage:** 120 Volts
- **Wattage:** 50 watts
- **Air Flow Capacity:** 7894 Cubic Feet Per Minute (CFM)
- **Noise Level:** 35 Decibels (at speeds 1-2)
- **Light Type:** Dimmable LED (3000K, 4000K, 5000K)
- **Control Method:** App, Remote, Voice
- **Special Features:** Adjustable Height, App Operable, LED Light, Quiet 6 Speed DC Motor, Remote Controlled, Reversible Motor
- **Room Type:** Bedroom, Dining Room, Home Office, Kitchen, Living Room
- **Indoor/Outdoor Usage:** Indoor (Damp-rated for covered outdoor patios)
- **Item Weight:** 13.52 pounds
- **Product Dimensions:** 31.1"D x 8.46"W x 11.81"H
- **Certification:** ETL Listed

WARRANTY & SUPPORT

NOPAARD offers a 24-month quality assurance for this product and a 10-year warranty for the DC motor. If you encounter any issues or have questions regarding installation, operation, or product quality, please do not hesitate to contact NOPAARD customer service. Our professional team is ready to assist you.

For customer service, please refer to the contact information provided in your product packaging or visit the official NOPAARD website.

