



[Manuals.plus](#) /

> [OTHOWE](#) /

> OTHOWE 6.5-inch Running Boards for 2017-2023 Honda Ridgeline Instruction Manual

## OTHOWE T6-82-BLK UB6-30705-6

# OTHOWE 6.5-inch Running Boards Instruction Manual

MODEL: T6-82-BLK UB6-30705-6

For 2017-2023 Honda Ridgeline

## Product Overview

---

These OTHOWE 6.5-inch running boards are designed to provide a safe and convenient step for entering and exiting your 2017-2023 Honda Ridgeline truck. Constructed from high-quality materials, they offer durability and a secure footing, enhancing vehicle accessibility.



Image: A silver Honda Ridgeline truck showcasing the installed OTHOWE running boards, providing a clear view of their appearance on the vehicle.

## Vehicle Compatibility

---

This product is specifically designed for and compatible with the following vehicle models:

- 2017 Honda Ridgeline
- 2018 Honda Ridgeline
- 2019 Honda Ridgeline
- 2020 Honda Ridgeline
- 2021 Honda Ridgeline
- 2022 Honda Ridgeline
- 2023 Honda Ridgeline

## Key Features

---

- **Durable Construction:** Made from high-durability galvanized carbon steel with non-slip plastic steps. The surface features a double anti-rust black powder coating for enhanced longevity and a premium appearance.
- **Wide Step Surface:** The 6.5-inch wide step provides ample foot room, ensuring safer entry and exit for all users, including children and the elderly.
- **High Load Capacity:** Supports a maximum load capacity of 500 pounds (approximately 226 kg).
- **Adjustable Design:** Features a slider design underneath the steps, allowing for front-to-back adjustment to customize the position for easy installation and personalized fit.



Image: A detailed diagram highlighting the key features of the running board, such as its 6.5-inch width, textured surface, and durable construction materials.

## Safety Guidelines

- Always ensure all mounting hardware is securely tightened before use.
- Do not exceed the maximum weight capacity of 500 pounds per side.
- Regularly inspect the running boards and mounting hardware for any signs of wear, damage, or corrosion.

- Clean the step pads regularly to maintain their non-slip properties.

## Package Contents

---

Please verify that all components are present and undamaged before beginning installation. If any parts are missing or damaged, contact customer support immediately.

- Left Running Board (1)
- Right Running Board (1)
- Mounting Brackets (Specific quantity for vehicle model)
- Hardware Kit (Bolts, washers, nuts, etc.)
- Installation Instructions (This document)

## Installation Instructions

---

### Tools Required:

- Ratchet wrench set
- Socket set (appropriate sizes for bolts)
- Torque wrench (recommended for proper tightening)
- Safety glasses
- Work gloves

### Pre-Installation Check:


Before installation, inspect the vehicle's factory mounting bolt holes on the chassis. For older vehicles, these holes may be corroded and require cleaning or re-tapping to ensure proper fitment and secure attachment.

### Step-by-Step Installation:

1. **Identify Mounting Points:** Locate the factory mounting points on the underside of your Honda Ridgeline chassis. These are typically pre-drilled holes designed for accessories.
2. **Attach Brackets:** Secure the mounting brackets to the vehicle's frame using the provided hardware. Ensure the brackets are oriented correctly for the left and right sides of the vehicle.
3. **Position Running Boards:** Carefully lift each running board and align it with the attached brackets. The integrated slider design allows for minor adjustments to achieve the desired position along the vehicle's side.
4. **Secure Running Boards:** Attach the running boards to the brackets using the remaining hardware. At this stage, tighten the bolts only enough to hold the running board in place, allowing for final adjustments.
5. **Adjust and Align:** Adjust the running boards to ensure they are level and properly positioned along the vehicle's side. Verify that there is adequate clearance from other vehicle components.
6. **Final Tightening:** Once satisfied with the alignment, progressively tighten all bolts to the manufacturer's recommended torque specifications. While specific torque values are not provided, a common recommendation is 20 ft-lbs for bracket-to-body bolts and 15 ft-lbs for running board-to-bracket bolts. Always refer to vehicle-specific guidelines if available.
7. **Verify Security:** After tightening, gently test the running boards by applying downward pressure to ensure they are firmly secured and do not wobble.

**Important:** *If you are not mechanically inclined or uncomfortable with the installation process, it is recommended to seek professional assistance to ensure proper and safe installation.*

**There are some sliders under the steps to better customize the position**



**Reinforced endcaps**

Image: An underside view of the running board, illustrating the adjustable slider mechanism for customized positioning and the reinforced endcaps.

## Usage

---

To use the running boards, simply step onto the textured surface when entering or exiting the vehicle. The non-slip pads provide traction for secure footing, especially in wet or muddy conditions.




Image: A close-up of the running board's textured surface, highlighting the non-slip design for improved safety and grip.

## Care and Maintenance

---

- **Cleaning:** Wash the running boards regularly with mild soap and water to remove dirt, mud, and road salt. Avoid abrasive cleaners or harsh chemicals that could damage the powder coating.
- **Inspection:** Periodically check all mounting bolts and hardware for tightness. Re-tighten if necessary. Inspect the running boards for any signs of rust, cracks, or damage, especially after off-road use or exposure to harsh weather conditions.
- **Corrosion Prevention:** If any scratches or chips appear on the powder coating, touch them up promptly to prevent rust and maintain the product's appearance and integrity.



Image: A close-up view of the running board's surface, demonstrating its textured finish and resistance to environmental factors.

## Troubleshooting Common Issues

Issue	Possible Cause	Solution
Running board feels loose	Mounting bolts are not fully tightened.	Re-tighten all mounting bolts to specifications.
Difficulty aligning	Brackets are incorrectly positioned or running board is not centered.	Loosen bolts, adjust bracket or running board position using the slider feature, then re-tighten.
Rust spots appearing	Damage to powder coating exposing bare metal.	Clean the area, sand lightly, and apply a rust-inhibiting primer and black automotive paint.

Issue	Possible Cause	Solution
Squeaking noise	Friction between metal components or loose parts.	Check all connections for tightness. Apply a small amount of grease to contact points if necessary.

If issues persist after attempting these solutions, please contact customer support for further assistance.

## Product Specifications

---

Feature	Detail
Brand	OTHOWE
Model Name	T6-82-BLK UB6-30705-6
Material	Galvanized Carbon Steel
Finish	Double Anti-Rust Black Powder Coating
Step Width	6.5 inches
Max Load Capacity	500 lbs (approx. 226 kg)
Product Dimensions (L x W x H)	208.28 x 16.51 x 5.08 cm (approx. 82 x 6.5 x 2 inches)
Item Weight	22.23 kg (approx. 49 lbs)
Color	Black

## Warranty and Customer Support

---

This product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or contact OTHOWE customer support directly.

If you encounter any problems during installation or use, or have questions regarding product quality, please contact our customer service team as soon as possible for assistance. We are committed to providing high-quality products and support.