

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [KUU](#) /

› [KUU XBOOK-3 14.1 inch Laptop User Manual](#)

## KUU XBOOK-3

# KUU XBOOK-3 14.1 inch Laptop User Manual

Model: XBOOK-3

## 1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your KUU XBOOK-3 14.1 inch Laptop. Please read this guide thoroughly before using your device to ensure proper function and longevity. Keep this manual for future reference.

## 2. SAFETY INFORMATION

- Do not expose the laptop to extreme temperatures, direct sunlight, or high humidity.
- Avoid placing heavy objects on the laptop.
- Use only the original power adapter provided with the device.
- Keep the laptop away from liquids and strong magnetic fields.
- Do not attempt to disassemble or repair the laptop yourself. Contact qualified service personnel for assistance.
- Ensure proper ventilation to prevent overheating.

## 3. PACKAGE CONTENTS

Upon unpacking your KUU XBOOK-3 Laptop, please verify that all items listed below are present:

- KUU XBOOK-3 14.1 inch Laptop
- Power Adapter (12V 2A DC 3.5 Input)
- Keyboard Stickers (Spanish, Italian, German, French)
- User Manual (this document)

## 4. PRODUCT OVERVIEW

Familiarize yourself with the key components and features of your KUU XBOOK-3 Laptop.



**Figure 4.1:** The KUU XBOOK-3 Laptop in its standard open position, showcasing the 14.1-inch display and Windows 11 Pro operating system.

**180° opening and closing angle**  
**Unlock more poses**



**Figure 4.2:** The KUU XBOOK-3 Laptop's screen can open up to 180 degrees, offering flexible viewing angles for various tasks.



Ergonomic Design



Comfortable to operate

# Large size keyboard

# large touchpad



**Figure 4.3:** The ergonomic design of the KUU XBOOK-3 features a large keyboard and a spacious touchpad for comfortable and efficient operation.



Figure 4.4: Side view of the KUU XBOOK-3 Laptop, highlighting the available ports for connectivity, including miniSD, earphone jack, USB 2.0, USB 3.0, DC 3.5 charging port, and Mini HDMI.

## 5. SETUP

### 5.1 Initial Power On

1. **Charge the Battery:** Before first use, connect the power adapter to the DC 3.5 charging port on the laptop and then to a power outlet. Allow the laptop to charge for at least 30 minutes.
2. **Power On:** Press and hold the power button (usually located on the top right of the keyboard) until the screen illuminates.
3. **Windows 11 Pro Setup:** Follow the on-screen instructions to complete the initial setup of Windows 11 Pro. This includes selecting your language, region, connecting to a Wi-Fi network, and creating a user account.

### 5.2 Connecting Peripherals

Your KUU XBOOK-3 Laptop supports various external devices:

- **USB Devices:** Connect USB mice, keyboards, external hard drives, or flash drives to the USB 2.0 or

USB 3.0 ports.

- **External Display:** Use the Mini HDMI port to connect to an external monitor or projector. You may need an adapter (not included) for standard HDMI connections.
- **Audio Devices:** Plug headphones or external speakers into the standard 3.5mm headphone jack.

## 6. OPERATING YOUR LAPTOP

---

### 6.1 Windows 11 Pro Basics

Your laptop comes pre-installed with Windows 11 Pro, offering a secure and responsive operating environment. Familiarize yourself with the Start Menu, Taskbar, and File Explorer for efficient navigation.

### 6.2 Keyboard and Touchpad


The laptop features a full-size QWERTY keyboard and a large touchpad. Keyboard stickers are provided for various language layouts if needed.

- **Touchpad Gestures:** Refer to Windows 11 settings for customizing touchpad gestures (e.g., two-finger scroll, pinch-to-zoom).
- **Function Keys (Fn):** Use the 'Fn' key in combination with the F1-F12 keys to access special functions like brightness control, volume adjustment, and Wi-Fi toggle.

### 6.3 Display Settings

The 14.1-inch IPS FHD (1920x1080) display offers clear visuals. You can adjust display settings through Windows 11:

- Right-click on the desktop and select 'Display settings' to change resolution, scale, and orientation.
- The screen supports a 180-degree opening angle for versatile use.



**Figure 6.1:** The KUU XBOOK-3 features a micro-border full screen with a 5mm ultra-narrow frame, providing an immersive viewing experience with a 178° wide viewing angle.

## 6.4 Connectivity (Wi-Fi, Bluetooth)

- **Wi-Fi:** The laptop supports Dual Band Wi-Fi (802.11 A/B/G/N) for stable wireless internet access. To connect, click the Wi-Fi icon in the taskbar, select your network, and enter the password.
- **Bluetooth:** Bluetooth 4.2 allows connection to wireless peripherals like headphones, speakers, or mice. Enable Bluetooth in Windows settings and pair your devices.

## 6.5 Ports and External Devices

The KUU XBOOK-3 is equipped with the following ports:

- 1 x USB 3.0 port
- 1 x USB 2.0 port
- 1 x Mini HDMI port
- 1 x Standard 3.5mm Headphone Jack
- 1 x MiniSD (TF Card) slot
- 1 x DC 3.5 charging port

## 7. MAINTENANCE

---

### 7.1 Cleaning

- Use a soft, lint-free cloth to clean the screen and exterior surfaces.
- For stubborn marks, slightly dampen the cloth with water or a screen-safe cleaner.
- Avoid spraying liquids directly onto the laptop.
- Regularly clean the keyboard and touchpad to remove dust and debris.

### 7.2 Battery Care

- To maximize battery lifespan, avoid fully discharging the battery frequently.
- Store the laptop in a cool, dry place if not used for extended periods, with the battery charged to around 50%.
- The integrated Lithium Polymer battery (3800mAh, 7.6V) is not user-replaceable.

### 7.3 Storage Expansion

The KUU XBOOK-3 comes with a 256GB SATA SSD. You can expand storage:

- **TF Card:** Insert a MicroSD (TF) card into the dedicated slot for additional storage, up to 1TB.
- **External SSD:** Connect an external SSD via the USB 3.0 port for portable storage.

## 8. TROUBLESHOOTING

---

This section addresses common issues you might encounter with your KUU XBOOK-3 Laptop.

Problem	Possible Cause	Solution
Laptop does not power on.	Low battery or power adapter issue.	Ensure the power adapter is securely connected and the laptop is charged. Try a different power outlet.
Wi-Fi connection issues.	Incorrect password, router problem, or Wi-Fi disabled.	Verify Wi-Fi password. Restart your router. Check if Wi-Fi is enabled in Windows settings or via Fn key.
Slow performance.	Too many applications running, low storage, or outdated drivers.	Close unnecessary applications. Free up disk space. Update Windows and device drivers.
External display not detected.	Incorrect cable, display input, or Windows display settings.	Ensure Mini HDMI cable is connected properly. Select the correct input on your monitor. Press Windows key + P to cycle through display modes.

If you encounter issues not covered here, please refer to the support section.

## 9. SPECIFICATIONS

---

Detailed technical specifications for the KUU XBOOK-3 Laptop:



**Figure 9.1:** Visual summary of the KUU XBOOK-3's core specifications, including processor, graphics, memory, storage, display, and physical attributes.

Feature	Specification
Model	XBOOK-3
Operating System	Windows 11 Pro
Processor	Intel Celeron J4125 (4 cores, 4 threads, 2GHz base, up to 2.7GHz burst)
Graphics	Intel UHD Graphics 600
RAM	8GB LPDDR4
Storage	256GB SATA SSD (expandable via TF card up to 1TB)
Display	14.1 inch IPS FHD (1920x1080)
Camera	0.3 Megapixels (300,000 pixels)

Feature	Specification
Audio	Built-in 8R/1.0W*2 Stereo Speaker
Wi-Fi	Dual Band Wi-Fi (802.11 A/B/G/N)
Bluetooth	Bluetooth 4.2
Ports	1x USB 3.0, 1x USB 2.0, 1x Mini HDMI, 1x 3.5mm Headphone Jack, 1x MiniSD (TF Card) slot, 1x DC 3.5 Charging Port
Battery	3800mAh, 7.6V Li-ion polymer battery
Dimensions	322 mm x 210 mm x 21 mm
Weight	1.4 kg

## 10. WARRANTY AND SUPPORT

Your KUU XBOOK-3 Laptop comes with a one-year VIP warranty service. For any questions or technical assistance, please contact KUU customer support through the retailer where you purchased the product or visit the official KUU website for support resources.

Please retain your proof of purchase for warranty claims.