GOBOULT X1 Pro

GOBOULT X1 Pro Wired Earphones User Manual

Model: X1 Pro

INTRODUCTION

Thank you for choosing the GOBOULT X1 Pro Wired Earphones. These earphones are designed to provide a high-quality audio experience with deep bass, convenient controls, and durable construction. This manual will guide you through the setup, operation, and maintenance of your new earphones.

WHAT'S IN THE BOX

Upon unboxing your GOBOULT X1 Pro Wired Earphones, please ensure all the following items are present:

- GOBOULT X1 Pro Wired Earphones
- Eartips (various sizes)
- User Manual

Your browser does not support the video tag.

Video: Unboxing the GOBOULT X1 Pro Wired Earphones. This video demonstrates the contents of the product packaging, including the earphones, various eartips, and the user manual.

FEATURES

The GOBOULT X1 Pro Wired Earphones come equipped with several key features to enhance your audio experience:

- **10mm BoomX Bass Drivers:** Large drivers deliver deep, rich, and resonant audio.
- **Type-C Wired Connectivity:** Ensures a seamless and uninterrupted listening experience with convenient Type-C connection.
- **Inline Controls:** Easily manage music playback, calls, and volume without accessing your device.
- **IPX5 Water Resistance:** Repels water and sweat, making them suitable for workouts and outdoor activities.
- **Comfort Fit:** Ergonomically designed for a secure and comfortable fit that lasts all day.
- **Pro+ Calling Mic:** Provides crisp and clear audio for calls.
- **Voice Assistant Support:** Compatible with voice assistants like Siri and Google Assistant.

Image: Key features of the GOBOULT X1 Pro Earphones, highlighting their design, controls, voice assistant compatibility, comfortable fit, enhanced bass, and water resistance.

Image: Detailed view of the GOBOULT X1 Pro Earphones' internal 10mm drivers, the inline control unit, and the Type-C connector for universal compatibility.

SETUP

1. **Select Ear Tips:** Choose the ear tips that provide the most comfortable and secure fit for your ears. A proper seal is crucial for optimal sound quality and bass response. Gently attach them to the earphone nozzles.

2. **Connect to Device:** Insert the Type-C connector of the earphones into the Type-C port of your smartphone, tablet, laptop, or other compatible device.

3. **Adjust Fit:** Place the earphones in your ears. The ergonomic design with ear hooks helps ensure a stable and comfortable fit, especially during movement.

Image: Demonstrates the snug fit of the GOBOULT X1 Pro Earphones in the ear, the durable Kevlar cable, and compatibility with voice assistants like Siri and Google Assistant.

OPERATING INSTRUCTIONS

Using Inline Controls

The inline control unit allows for easy management of your audio and calls:

- **Play/Pause:** Press the center button once to play or pause music.
- **Next Track:** Double-press the center button to skip to the next song.
- **Previous Track:** Triple-press the center button to go back to the previous song.
- **Answer/End Call:** Press the center button once to answer an incoming call or end an ongoing call.
- **Reject Call:** Press and hold the center button for approximately 2 seconds to reject an incoming call.
- **Volume Control:** Use the dedicated volume up (+) and volume down (-) buttons to adjust the audio level.

Voice Assistant

To activate your device's voice assistant (e.g., Siri, Google Assistant), press and hold the center button on the inline control unit for a few seconds until the assistant activates.

MAINTENANCE

- **Cleaning:** Regularly clean the ear tips and earphone body with a soft, dry cloth. For ear tips, you may gently remove them and wash with mild soap and water, ensuring they are completely dry before reattaching.
- **Storage:** When not in use, store the earphones in a clean, dry place, preferably in a protective pouch, to prevent tangling and damage.
- **Water Resistance:** While the earphones are IPX5 water-resistant, meaning they can withstand splashes and sweat, they are not designed for submersion in water. Avoid exposing them to heavy rain or prolonged water contact. Ensure the Type-C port is dry before connecting to a device.

TROUBLESHOOTING

Problem	Solution
No sound or low volume	- Ensure the Type-C connector is fully inserted into your device. - Check the volume level on both your device and the earphones' inline controls. - Test with another audio source or device to rule out device-specific issues. - Ensure ear tips are properly seated and forming a seal in your ear.
Microphone not working	- Ensure the earphones are fully connected. - Check your device's audio input settings to confirm the earphone microphone is selected. - Clean the microphone port if it appears obstructed.
Inline controls unresponsive	- Ensure the earphones are securely connected to your device. - Some devices may have limited compatibility with inline controls; check your device's manual.

SPECIFICATIONS

Feature	Detail
Model Name	X1
Headphones Jack	Type-C
Connectivity Technology	Wired
Audio Driver Size	10 Millimetres
Frequency Response	20 Hz
Water Resistance Level	IPX5 Water Resistant
Microphone Format	Omnidirectional Microphone
Control Type	Button, Voice
Compatible Devices	Cellphones, Desktops, Gaming Consoles, Laptops, Tablets
Item Weight	30 Grams
Product Dimensions	8 x 12 x 1.5 cm

WARRANTY AND SUPPORT

Your GOBOULT X1 Pro Wired Earphones come with a **3 Months Manufacturer's Warranty** from the date of purchase. This warranty covers manufacturing defects.

For warranty claims, technical support, or further inquiries, please contact GOBOULT customer service. You may also consider purchasing an extended warranty for additional coverage, such as the "1 Year Extended Warranty by OneAssist" if available.

Your browser does not support the video tag.

Video: Overview of GOBOULT X1 Pro Wired Earphones features, including 10mm bass drivers, Type-C connectivity, IPX5 water resistance, inline controls, custom fit, Pro+ calling mic, and warranty information.