Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- , DOYO /
- > DOYO Wireless PC Gaming Controller User Manual

DOYO 711B

DOYO Wireless PC Gaming Controller User Manual

Model: DOYO 711B Brand: DOYO

PRODUCT OVERVIEW

The DOYO 711B Wireless PC Gaming Controller is designed to provide an immersive gaming experience across multiple platforms, including PC (Windows 7/8/10/11) and Steam. Featuring dual-vibration feedback and high-performance joysticks, this gamepad ensures precise control and responsive gameplay.



Image: The DOYO Wireless PC Gaming Controller shown with its accompanying USB wireless receiver.

FEATURES

- Wide Compatibility: Supports PC (Windows XP/7/8/8.1/10/11), Steam PC gaming consoles, PS3, and Android.
- 2.4G Wireless Transmission: Ensures a stable connection without delay via the included USB receiver.
- **Improved Design:** Classic left and right shoulder button design, 12 function keys, and support for two controllers simultaneously (game support required).
- Vibration Feedback: Provides automatic vibration feedback for an enhanced gaming experience.
- High-Performance Chip: Utilizes a high-performance chip for good stability and zero game delay.
- High Precision Joysticks: 360-degree highly accurate positioning for precise control.



Image: The controller illustrating its double vibration feature, providing tactile feedback during gameplay.



Image: A close-up view of the controller's upgraded joystick, highlighting its 360-degree accurate positioning.

PACKAGE CONTENTS

Please check the package for the following items:

- DOYO Wireless PC Gaming Controller (1 unit)
- USB Wireless Receiver (1 unit)
- User Manual (this document)

SETUP

1. Battery Installation

The controller requires 3 AAA batteries (not included). To install:

1. Locate the battery compartment on the back of the controller.

- 2. Open the battery cover.
- 3. Insert 3 AAA batteries, ensuring correct polarity (+/-).
- 4. Close the battery cover securely.



Image: The rear view of the controller showing the open battery compartment, indicating where to insert AAA batteries.

2. Connecting to PC/Steam

The DOYO Wireless PC Gaming Controller uses a 2.4G wireless USB receiver for connection.

- 1. Plug the USB wireless receiver into an available USB port on your PC or Steam console.
- 2. The system should automatically recognize the device. The controller is designed for plug-and-play functionality.
- 3. If the controller does not connect automatically, press the "MODE" button on the controller to initiate pairing. The indicator lights on the controller will show connection status.
- 4. For optimal performance, ensure the controller is within 15 meters of the USB receiver.



Image: A visual representation of the USB wireless receiver being plugged into a laptop, demonstrating the wireless connection setup.

Support multi platform Windows XP/7/8/10/11 LECT START Steam(Xinput) **Android**

Image: The controller displayed with icons representing its multi-platform compatibility, including Windows, Steam, PS3, and Android.

OPERATING INSTRUCTIONS

Basic Operation

- Once connected, the controller is ready for use in compatible games.
- The controller features standard gamepad buttons, D-pad, and dual analog sticks for precise control.
- The "MODE" button can be used to switch between different modes if supported by the game or system, or to initiate pairing. Hold the "MODE" button down to power on and off the controller.
- The dual vibration motors will provide haptic feedback during gameplay, enhancing immersion.

Your browser does not support the video tag.

Video: A demonstration of the DOYO 711B controller in use during a game, showcasing its responsive operation and smooth control.



Image: A close-up view of the central SELECT, MODE, and START buttons on the controller.



Image: Two individuals enjoying a game using the DOYO wireless controllers, illustrating multi-player capability.

MAINTENANCE

- Keep the controller and USB receiver dry and clean.
- Avoid exposing the device to extreme temperatures or direct sunlight.
- Clean the surface with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Remove batteries if the controller will not be used for an extended period to prevent leakage.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Controller does not power on.	Check if batteries are installed correctly and have sufficient charge. Ensure the "MODE" button is pressed and held to power on.
Controller not connecting to PC.	Ensure the USB wireless receiver is securely plugged into a working USB port. Try a different USB port. Press the "MODE" button on the controller to re-initiate pairing. Ensure the controller is within the 15-meter transmission range. Check your PC's device manager to see if the controller is recognized. You may need to manually update or install drivers if not automatically detected (though it's designed for plug-and-play).
Vibration feedback not working.	Ensure the game you are playing supports vibration feedback. Check in-game settings to ensure vibration is enabled. Verify controller drivers are up to date.
Input lag or unresponsive controls.	Ensure the controller is within optimal range of the USB receiver. Minimize interference from other 2.4Ghz wireless devices. Check battery level; low batteries can affect performance.

SPECIFICATIONS

• Model: DOYO 711B

• Connectivity: 2.4G Wireless (USB Receiver)

• Compatibility: PC (Windows XP/7/8/8.1/10/11), Steam, PS3, Android

• Power Source: 3 x AAA Batteries (not included)

• Transmission Distance: Up to 15 meters

• Features: Dual Vibration Feedback, 12 Function Keys, 360-degree High Accuracy Joysticks

• **Dimensions:** Approximately 7.01 x 4.49 x 2.64 inches (17.8 x 11.4 x 6.7 cm)

• Weight: Approximately 7.83 ounces (222 grams)

• Manufacturer: DOYO



Image: The rear side of the DOYO controller, showing its ergonomic design and button layout.

WARRANTY AND SUPPORT

DOYO provides the following warranty and support for this product:

- Money-Back Guarantee: 30-Day Money-Back Guarantee from the date of purchase.
- Replacement Warranty: 90-Day Replacement Warranty for manufacturing defects.
- **Customer Support:** For any setting issues or operational questions, please contact DOYO customer service. Step-by-step troubleshooting and 24/7 service are available.

For further assistance, please refer to the contact information provided with your purchase or visit the official DOYO support website.

Related Documents - 711B



711B PC 2.4G Wireless Controller User Manual

User manual for the 711B PC 2.4G Wireless Controller, covering product functions, special features, connection to PC, driver installation (Xinput and Directinput), function detection (button test, joystick calibration, vibration test), sleep/wake modes, low voltage reminders, and electrical parameters.



DOYO 820 270 Degree Bluetooth Steering Wheel User Manual

Comprehensive user manual for the DOYO 820 270 Degree Bluetooth Steering Wheel, detailing its features, setup, and usage across multiple platforms including PS4, PS3, Nintendo Switch, PC (Windows), iOS, and Android. Learn about connection methods, button functions, advanced settings like dead zone and sensitivity adjustment, vibration control, firmware upgrades, and troubleshooting.



735 Wireless Controller User Manual



Comprehensive user manual for the 735 Wireless Controller, detailing product features, connection instructions for Switch, PC, Android, iOS, TURBO key settings, backkey settings, vibration, gyro calibration, NFC function, and KeyLinker app usage.

Control Contro

whether the Essering which connection is normal, and then go to the PC s till gains sorted to perform a handlood age to see if it reponds. If it is sorted, then these connections with the

DOYO Racing Wheel Driver Download and PC Connection Troubleshooting Guide

Download drivers for your DOYO racing wheel and find solutions to common PC connection issues, including pedal and vibration problems. Compatible with Xbox, PS4, and PC.



KT612 Wireless Guitar Controller for PC/PS3 - Function Instructions and Setup Guide

Comprehensive instructions for the KT612 wireless 2-in-1 guitar controller, covering setup, connection to PS3 and PC, game mode switching, button functions, and troubleshooting for Guitar Hero and Rockband games, plus Clone Heroes setup.

note hill, then it in haid to describe the delay in her that the game asset to describe the string but it came compared a service region the using what and the using what is alreaded, you need to describe the driver more build the described will are facilities.

F (SE 1865) TEXTSOL FOR THE SET, JANE SET SE CONTRACT METER SHOP SET SERVICE SET CONTRACT SET SET SERVICE SET SET SERVICE SET SET SERVICE SET SERVICE SET SET SERVICE SET SERVICE SET SERVICE SET SERVICE SET SERVICE SET SE

Company converged to the whole for contracting problem, where it general.

So deline for Contracting the contracting the contracting the contracting the contracting the contracting problem. The contracting problem is the contracting problem in the contracting problem is the contracting problem in the contracting problem is the contracting the contr

reportes of in helpfoling you.

From a resolute reportable without applies pended or our bit valued (in data a second-ol),
where help has been pointed as it players playing to the pended of the second out the contract of the data and provide absolute absolute and provide absolute and provide absolute a

DOYO R808 Steering Wheel PC Connection Guide and Troubleshooting

Troubleshooting guide for the DOYO R808 steering wheel, covering PC connection issues, driver downloads, and input mode settings for optimal gaming performance.