



Manuals.plus /

› **Kalamera /**

› Kalamera KRC-51FCSS Wine Cooler User Manual

Kalamera KRC-51FCSS-U1

Kalamera KRC-51FCSS Wine Cooler User Manual

Model: KRC-51FCSS-U1

INTRODUCTION

Thank you for choosing the Kalamera KRC-51FCSS Wine Cooler. This compact and efficient wine refrigerator is designed to store your wine collection at optimal temperatures, preserving its quality and flavor. With a capacity of 18 bottles and a precise temperature control system, it is an ideal solution for wine enthusiasts with limited space.



Image: Angled view of the Kalamera KRC-51FCSS Wine Cooler, showcasing its sleek design and glass door with wine bottles visible inside.

SAFETY INFORMATION

Please read all instructions carefully before using the appliance. Keep this manual for future reference.

- Ensure the appliance is placed on a stable, level surface away from direct sunlight or heat sources.
- Allow the unit to stand upright for at least 24 hours before plugging it in to allow the refrigerant to settle.
- Do not block ventilation openings.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Unplug the appliance before cleaning or performing maintenance.
- This appliance is intended for household use only.

SETUP

Unpacking

Carefully remove all packaging materials. Inspect the wine cooler for any shipping damage. Report any damage to your retailer immediately.

Placement

Place the wine cooler in a location with adequate air circulation. Ensure there is at least 10 cm (4 inches) of space around the back and sides for proper ventilation. Avoid placing it near heat-generating appliances or in direct sunlight.

Innenmaße

257x655x332 mm (B x H x T)



780mm
Höhe inkl.
Gummifüße

445mm

345mm

Image: Diagram showing the dimensions of the Kalamera KRC-51FCSS Wine Cooler: 445mm width, 345mm depth, 776mm height (including rubber feet). Internal dimensions are 257x655x332 mm (H x W x D).

Leveling

Adjust the leveling feet at the bottom of the unit to ensure it is perfectly level. This is crucial for proper operation and door alignment.

Power Connection

Plug the wine cooler into a dedicated 220 VAC grounded electrical outlet. Do not use extension cords or adapter plugs.

OPERATING INSTRUCTIONS

Control Panel

The wine cooler features a touch control panel located on the exterior of the glass door. This allows for easy temperature adjustments without opening the door.



Image: Close-up view of the touch control panel, showing temperature display and control buttons.

Temperature Setting

Use the **Up** and **Down** arrows on the touch panel to set your desired temperature. The temperature can be set precisely within a range of 5°C to 18°C (41°F to 64°F). The display will show the current internal temperature.

Internal Lighting

The wine cooler is equipped with white LED internal lighting. Press the light bulb icon on the control panel to turn the light on or off.

Loading Bottles

The wine cooler can hold up to 18 standard 0.75-liter wine bottles (up to 310mm in height). Arrange bottles on the removable wooden shelves. Ensure bottles are not touching the back wall to allow for proper air circulation.



Abnehmbar Holzauflagen



Image: Close-up view of the removable wooden shelves, highlighting their design and how bottles are stored.

MAINTENANCE

Cleaning

- Always unplug the appliance before cleaning.
- Clean the interior with a soft cloth and a mild, non-abrasive detergent. Rinse with clean water and dry thoroughly.
- Wipe the exterior with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- The wooden shelves can be removed and wiped clean with a damp cloth. Ensure they are completely dry before placing them back in the unit.

Defrosting

This wine cooler features an automatic defrost system, minimizing the need for manual defrosting. Any accumulated frost will melt and evaporate automatically.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Wine cooler does not operate.	No power supply.	Check if the power plug is properly inserted into the outlet. Check the circuit breaker.
Temperature is not cold enough.	Door not closed properly; excessive door opening; high ambient temperature; poor ventilation.	Ensure door is fully closed. Reduce frequency of door openings. Place unit in a cooler environment. Ensure adequate space around the unit for ventilation.
Unit is noisy.	Unit is not level; objects touching the unit.	Adjust leveling feet. Ensure nothing is touching the back or sides of the unit. Normal compressor operation produces some sound (approx. 40-41 dB).
Vibration.	Unit is not level.	Adjust the leveling feet to ensure the unit is stable and level.

SPECIFICATIONS

Feature	Detail
Brand	Kalamera
Model Number	KRC-51FCSS-U1
Capacity	18 Bottles / 51 Liters
Temperature Range	5°C - 18°C (41°F - 64°F)
Dimensions (W x D x H)	44.5 x 34.5 x 77.6 cm
Weight	26.5 kg
Noise Level	40-41 dB
Energy Efficiency Class	G
Voltage	220 VAC
Defrost System	Automatic
Special Features	White LED lighting, Energy-efficient compressor, Touch control panel, Removable wooden shelves, Stainless steel glass door.
Country of Origin	China
EPREL Product Page	View on EPREL



ENERG ⚡



Kalamera

KRC-51FCSS



127 kWh/annum



18



ABC**D**

2019/2016

Image: Energy label for the Kalamera KRC-51FCSS wine cooler, showing energy class G, 127 kWh/annum consumption, 18 bottle

capacity, and 41 dB noise level.

WARRANTY AND SUPPORT

Warranty Information

The Kalamera KRC-51FCSS Wine Cooler comes with a manufacturer's warranty of 24 months from the date of purchase. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Kalamera customer support. Refer to your purchase documentation for specific contact details or visit the official Kalamera website.

You can also visit the Kalamera store on Amazon for more information:[Kalamera Store](#)

