

## Freezimer Dreamice X3

# Freezimer Dreamice X3 Nugget Ice Maker User Manual

Model: Dreamice X3

## INTRODUCTION

Thank you for choosing the Freezimer Dreamice X3 Nugget Ice Maker. This countertop appliance is designed to produce soft, chewable nugget ice quickly and efficiently, perfect for various beverages and occasions. This manual provides essential information for safe operation, setup, maintenance, and troubleshooting to ensure optimal performance and longevity of your ice maker.



Image: The Freezimer Dreamice X3 Nugget Ice Maker, showcasing its compact design, a full ice bin, an ice scoop, and a refreshing blue beverage with nugget ice.

## IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury when using your ice maker, follow these basic precautions:

- Read all instructions before use.
- Do not touch the evaporator or ice blades when the unit is in operation.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Supervise children closely when the appliance is in use.
- Unplug the ice maker from the outlet when not in use or before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only potable water for ice production.

- Ensure proper ventilation around the unit. Maintain at least 5 inches of space on all sides.
- Do not place the ice maker near heat sources or in direct sunlight.

## PRODUCT OVERVIEW

### Components and Features

The Freezimer Dreamice X3 is designed for user convenience and efficient ice production.

# Enjoy Chewable Nugget Ice

be in love with soft, crunchy samll ices



Image: Demonstrates the appeal of chewable nugget ice, highlighting its soft and crunchy texture compared to other ice types.

- **Nugget Ice Production:** Produces soft, chewable pebble ice.
- **High Capacity:** Capable of producing up to 40 lbs of ice per 24 hours.
- **Self-Cleaning Function:** Simplifies maintenance and ensures hygiene.
- **Kid-Friendly Design:** Features a suitable height and front ice drawer for easy access.
- **Quiet Operation:** Operates at approximately 40dB, comparable to a quiet conversation.
- **Smart Touch Panel:** Intuitive controls with indicator lights.
- **See-Through Water Tank:** Allows for easy monitoring of water levels.



- **Compact and Lightweight:** Easy to place on countertops and move as needed.



Image: The smart touch panel of the ice maker, showing the indicator light zone and operation touch zone for easy control.

## Control Panel Functions

- **Indicator Light Zone:**
  - **Add Water:** Illuminates when the water reservoir needs refilling.
  - **Ice Full:** Illuminates when the ice bin is full.
  - **Cleaning:** Illuminates during the self-cleaning cycle.

- **Power:** Indicates the unit is powered on.
- **Operation Touch Zone:**
  - **Clean Key:** Initiates the self-cleaning cycle.
  - **Light Key:** Controls the internal light.
  - **ON/OFF Key:** Powers the unit on or off.

## SETUP

---

### 1. Unpacking

Carefully remove the ice maker from its packaging. Retain the packaging materials for future storage or transport if needed. Remove all protective films and tapes from the unit.

### 2. Placement

Place the ice maker on a flat, stable surface away from direct sunlight and heat sources (e.g., stoves, ovens). Ensure there is at least 5 inches of clear space around the unit for proper ventilation.

# COMPACT DESIGN, LESS SPACE

Small body dimensions to fit perfectly into a compact countertop



Image: Illustrates the compact dimensions of the ice maker, making it suitable for various countertop spaces.

### 3. Initial Cleaning

Before first use, it is recommended to clean the interior of the ice maker. Follow the self-cleaning instructions in the Maintenance section or manually clean with a mild detergent and warm water. Rinse thoroughly.

### 4. Water Filling

Open the lid of the water reservoir located on top of the unit. Fill the reservoir with potable water up to the "MAX" fill line. Do not overfill.






Image: Demonstrates the process of refilling the top water tank, emphasizing the MAX fill line for proper operation.

## OPERATING INSTRUCTIONS

### 1. Making Ice

1. Ensure the unit is plugged into a grounded electrical outlet.
2. Fill the water reservoir with potable water as described in the Setup section.
3. Press the **ON/OFF Key** on the control panel to start the ice making process. The unit will begin producing ice within minutes.
4. The ice maker will automatically stop when the ice bin is full or when the water level is too low.

Image: Illustrates the rapid ice production capability, showing ice ready in as little as 7 minutes and daily output.

### 2. Ice Collection

Once ice is produced, it will drop into the ice bin. The front ice drawer allows for easy access to the nugget ice. Use the provided ice scoop to retrieve ice.





Image: Shows the ice bin filled with nugget ice, indicating its capacity to hold up to 3 lbs of ice.

### 3. Melted Ice Recycling

The Dreamice X3 features a melted ice recycling system. If ice in the bin melts, the water will drain back into the reservoir to be re-used for ice production. This minimizes water waste.

- **Plan A (Storage):** If you plan to store ice for more than 2 hours, it is best to transfer it to a freezer. The ice bin does not have insulation for extended storage.
- **Plan B (Continuous Production):** When the "Ice Full" light is on, do not remove ice if you want the machine to automatically remake ice once the melted water returns to the reservoir.

# Melted Ice Recycling



Image: Visual representation of how melted ice is recycled back into the water reservoir for continuous ice production.

## 4. Indicator Lights

The control panel features indicator lights to inform you of the ice maker's status:

- **Red Light (Add Water):** Always flashing when water needs to be added.
- **White Light (Power):** Always on when the unit is powered.
- **Ice Full Light:** Illuminates when the ice bin is full.
- **Cleaning Light:** Illuminates during the self-cleaning cycle.



Image: Details the indicator lights on the control panel, specifically showing the "Add Water" (red, flashing) and "Power" (white, on) lights.

## MAINTENANCE

### 1. Regular Cleaning

Regular cleaning helps maintain the quality of your ice and the longevity of the machine.

- **Self-Cleaning Cycle:**
  - Ensure the water reservoir is filled.



- Press the **Clean Key** on the control panel. The unit will run a cleaning cycle, circulating water through its system.
- Once the cycle is complete, drain the water as described below.
- **Manual Cleaning:**
  - Unplug the unit.
  - Remove the ice bin.
  - Clean the interior with a soft cloth and a mild, food-safe detergent.
  - Rinse thoroughly with clean water.
  - Wipe dry before reassembling.

## 2. Draining Water

To drain the water from the unit, locate the drainage outlet on the bottom left side of the machine. Place the ice maker near a sink or use a container to collect the water. Unplug the seal to allow water to drain completely.



Image: Shows the convenient drainage system, allowing for easy emptying of the water reservoir.

## 3. Storage

If storing the ice maker for an extended period, ensure it is thoroughly cleaned and completely dry. Drain all water from the reservoir and internal components. Store in a cool, dry place, preferably in its original packaging.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir; unit not plugged in; air temperature too high.	Fill water reservoir; ensure unit is plugged in; operate in a cooler environment.
"Add Water" light is on.	Water level is low.	Add potable water to the reservoir up to the MAX line.
"Ice Full" light is on.	Ice bin is full.	Remove ice from the bin.

Problem	Possible Cause	Solution
Ice tastes strange or has an odor.	Unit needs cleaning; stale water.	Perform a self-cleaning cycle or manual clean; replace water in reservoir.
Unit is noisy.	Normal operation sounds; unit not level.	Ensure unit is on a flat, stable surface. Some operational noise is normal.

## SPECIFICATIONS

Feature	Detail
Model Number	Dreamice X3
Brand	Freezimer
Ice Type	Nugget (Pebble) Ice
Daily Ice Production	Up to 40 lbs / 24 hours
Ice Storage Capacity	Approx. 3 lbs
Product Dimensions (L x W x H)	14.5 x 11.2 x 10.2 inches
Item Weight	26.1 Pounds
Noise Level	Approx. 40dB
Self-Cleaning Function	Yes

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Freezimer website. If you encounter any issues not covered in this manual, please contact Freezimer customer service for assistance.

You can visit the Freezimer Store on Amazon for more information:[Freezimer Store](#)