

Gavigain Gavigainiwh0bn6m2r

Gavigain Portable Electronic Scale User Manual

Model: Gavigainiwh0bn6m2r

Safety Information	Product Overview	Setup	Operating Instructions	Maintenance
	Troubleshooting	Specifications	Warranty and Support	

1. SAFETY INFORMATION

Please read all instructions carefully before using the Gavigain Portable Electronic Scale. Retain this manual for future reference.

- Do not immerse the scale in water or other liquids.
- Avoid dropping or subjecting the scale to strong impacts.
- Do not attempt to disassemble or repair the scale yourself. Contact customer support if issues arise.
- Keep the scale away from extreme temperatures and direct sunlight.
- Ensure batteries are inserted correctly according to polarity markings. Remove batteries if the scale will not be used for an extended period.

2. PRODUCT OVERVIEW

2.1 Components

- **LCD Display:** Shows weight readings and unit.
- **Power/Unit Button:** Turns the scale on/off and changes weighing units.
- **Weighing Hook:** For attaching items to be weighed.
- **Key Ring:** For portability and attachment.
- **Battery Compartment:** Located on the back for battery installation.



Figure 1: Various views of the Gavigain Portable Electronic Scale, highlighting its compact design and battery access.

The Gavigain Portable Electronic Scale is designed for convenience and accuracy. Its compact size and key chain design make it easy to carry for various weighing needs.



Figure 2: Product dimensions of the Gavigain Portable Electronic Scale, showing its compact size of approximately 6cm x 3.8cm x 1.9cm.

3. SETUP

3.1 Battery Installation

The scale requires batteries for operation. Follow these steps to install them:

1. Locate the battery compartment cover on the back of the scale.
2. Gently slide or lift the cover to open the compartment.
3. Insert the required batteries (e.g., 2 x AAA, not specified in product data, assuming common small scale batteries) into the compartment, ensuring correct polarity (+/-) as indicated.
4. Replace the battery compartment cover until it clicks securely into place.



Figure 3: The open battery compartment of the scale, ready for battery insertion.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

- To turn on the scale, press the **Power/Unit** button. The LCD display will light up and show '0.000'.
- To turn off the scale, press and hold the **Power/Unit** button for a few seconds until the display turns off. The scale also features an auto-off function to conserve battery power.

4.2 Weighing Items

1. Ensure the scale is powered on and displaying '0.000'.
2. Carefully attach the item to be weighed to the weighing hook.

3. Hold the scale steady. The weight will be displayed on the LCD screen.



Figure 4: The electronic scale in use, weighing a basket of produce.

4.3 Changing Units (lb/kg)

- While the scale is on and displaying '0.000', press the **Power/Unit** button briefly to cycle through available weighing units (e.g., kg, lb).
- Select your desired unit before weighing.

Clear LCD display and lock function, easy to read and record the digits.

Auto off design, energy saving and Eco-friendly.



Figure 5: The scale displaying a clear LCD reading in a kitchen setting.

4.4 Lock Function

The scale features a lock function to hold the displayed weight. This allows you to remove the item and still see its weight.

- When a stable weight is detected, the display may automatically lock the reading.
- To unlock or clear the reading, briefly press the **Power/Unit** button.

5. MAINTENANCE

5.1 Cleaning

- Wipe the scale with a soft, damp cloth. Do not use abrasive cleaners or immerse in water.
- Ensure the scale is completely dry before storage or next use.

5.2 Storage

- Store the scale in a cool, dry place.
- If not used for an extended period, remove the batteries to prevent leakage and damage.

6. TROUBLESHOOTING

If you encounter issues with your scale, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Scale does not turn on.	Dead or incorrectly installed batteries.	Check battery polarity or replace with new batteries.
Inaccurate readings.	Scale not on a stable surface; overloaded; environmental factors.	Ensure scale is held steady. Do not exceed maximum weight capacity. Avoid drafts or vibrations.
Display shows 'Err' or 'OL'.	Overload beyond maximum capacity.	Remove the item immediately. Do not weigh items exceeding 25 kg.
Display is dim or flickering.	Low battery power.	Replace batteries.

7. SPECIFICATIONS

Feature	Detail
Brand	Gavigain
Model Number	Gavigainiwh0bn6m2r
Maximum Weight Capacity	25 Kilograms
Accuracy	5g (0.005 kg)
Product Dimensions	2 x 3 x 6 cm
Item Weight	50 g
Material	Plastic
Special Features	Auto Shut Off, Clear LCD Display, Lock Function
Power Source	Battery Powered (Type not specified, typically AAA or CR2032)

8. WARRANTY AND SUPPORT

Gavigain products are manufactured to high-quality standards. For specific warranty details, please refer to the documentation provided with your purchase or contact the retailer.

If you require technical assistance or have questions not covered in this manual, please contact Gavigain customer support through your purchase platform or the official brand website.