

[manuals.plus](#) /› [SENTRY](#) /› [SENTRY OSH140 Wired USB-C Over-Ear Headphones Instruction Manual](#)

SENTRY OSH140

SENTRY OSH140 Wired USB-C Over-Ear Headphones Instruction Manual

Brand: SENTRY | Model: OSH140

INTRODUCTION

Thank you for choosing the SENTRY OSH140 Wired USB-C Over-Ear Headphones. These headphones are designed to provide a high-quality audio experience with the convenience of a direct USB-C connection. Featuring 40mm drivers and studio-grade earpads for noise isolation, they deliver clear, balanced sound. The integrated inline microphone allows for hands-free communication, and the collapsible design with an included protective case ensures portability and durability.

WHAT'S IN THE BOX

- SENTRY OSH140 Wired USB-C Over-Ear Headphones
- Deluxe Hard Case



Figure 1: Front view of SENTRY OSH140 Wired USB-C Over-Ear Headphones.



Figure 2: SENTRY OSH140 headphones showing the inline controls on the cable.

COMFORT-FIT DESIGN



Plush
Earpads



Folding
Headband



Padded
Headband


Visit: sentryindustries.com



Figure 3: SENTRY OSH140 headphones folded, next to the included protective hard case.

IN-LINE CONTROL

 **SENTRY**
INDUSTRIES



Visit: sentryindustries.com

Figure 4: SENTRY OSH140 headphones neatly stored inside their deluxe hard case.

SETUP

1. **Unpack:** Carefully remove the headphones and the deluxe hard case from the packaging.
2. **Unfold:** Gently unfold the earcups from their collapsed position until the headband is fully extended.
3. **Connect:** Insert the USB-C connector of the headphone cable directly into the USB-C port of your compatible device (e.g., cellphone, desktop, Mac, iPad, Switch, MP3 player). No additional drivers or software are typically required for basic audio functionality.
4. **Adjust:** Place the headphones over your ears, ensuring the soft earpads fully cover them. Adjust the headband for a comfortable and secure fit.

OPERATING INSTRUCTIONS

The SENTRY OSH140 headphones feature an inline remote with a built-in microphone for convenient control of your audio and calls.



Figure 5: Diagram illustrating the functions of the inline control buttons.

Audio Control:

- **Play/Pause:** Press the center button once.
- **Next Track:** Press the center button twice quickly.
- **Previous Track:** Press the center button three times quickly.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.

Call Control:

- **Answer/End Call:** Press the center button once during an incoming call or to end an active call.
- **Reject Call:** Press and hold the center button for approximately 2 seconds during an incoming call.
- **Microphone:** The built-in microphone is automatically active during calls.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use liquid cleaners or sprays.
- **Storage:** When not in use, fold the headphones and store them in the provided deluxe hard case to

protect them from dust, scratches, and damage.

- **Cable Care:** Avoid sharp bends or excessive pulling on the USB-C cable to prevent internal damage.
- **Water Resistance:** These headphones are not water resistant. Avoid exposure to moisture or liquids.

TROUBLESHOOTING

Problem	Solution
No sound from headphones.	<ul style="list-style-type: none">◦ Ensure the USB-C connector is fully inserted into your device.◦ Check the volume level on your device and on the headphone's inline controls.◦ Test the headphones with another compatible device to rule out device-specific issues.
Microphone not working.	<ul style="list-style-type: none">◦ Ensure the headphones are properly connected.◦ Check your device's audio input settings to confirm the inline microphone is selected.◦ Test the microphone with another application or device.
Sound quality is poor.	<ul style="list-style-type: none">◦ Ensure the USB-C connection is secure.◦ Check the audio source quality.◦ Adjust the volume to a comfortable level.

SPECIFICATIONS

Feature	Detail
Model Name	OSH140
Connectivity Technology	Wired USB-C
Headphones Jack	USB-C
Audio Driver Type	Dynamic Driver
Driver Size	40mm
Impedance	32 Ohms
Frequency Response	20 KHz (Note: The provided data states 20 KHz, which is typically the upper limit of human hearing. A full range would be 20Hz-20kHz)
Sensitivity	110 dB

Feature	Detail
Noise Control	Sound Isolation (via Studio Grade Earpads)
Microphone	Inline Mic
Control Type	Media Control (Inline Remote)
Earpiece Shape	Over-Ear
Material	Plastic (Headphones), Nylon (Carrying Case)
Color	Black
Product Dimensions	3.75 x 0.75 x 6.75 inches
Item Weight	1.5 Ounces
Water Resistance Level	Not Water Resistant
Compatible Devices	Cellphones, Desktop, Mac, iPad, Switch, MP3

WARRANTY AND SUPPORT

Sentry Industries provides an extensive 90-day warranty on all products, offering free replacements within this period. For any product inquiries, technical support, or warranty claims, please contact Sentry Industries customer service through their official website or the retailer where the product was purchased. For additional information, please visit the [SENTRY Store on Amazon](#).

PRODUCT OVERVIEW VIDEO

Your browser does not support the video tag.

Video 1: An official product overview of the Sentry OSH140 Over-Ear USB-C Headphones, provided by Amazon Videos (Seller).