

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [NOTABRICK](#) /

› [NOTABRICK Bluetooth Speaker User Manual](#)

NOTABRICK Ni

NOTABRICK Bluetooth Speaker User Manual

Model: Ni

INTRODUCTION

Thank you for choosing the NOTABRICK Bluetooth Speaker. This powerful 40W speaker is designed to deliver high-fidelity audio with deep bass, featuring advanced DSP technology for distortion-free sound. Its IPX7 waterproof rating makes it ideal for various environments, from outdoor adventures to home use. Enjoy up to 15 hours of continuous playtime and dynamic 7-color LED lighting that enhances any atmosphere. This manual provides detailed instructions to help you get the most out of your speaker.

WHAT'S IN THE BOX

- 1 x NOTABRICK Bluetooth Speaker
- 1 x Type-C Charging Cable
- 1 x AUX Cable
- 1 x Quick Use Reading Guide

SETUP


1. Charging the Speaker

Before first use, fully charge your NOTABRICK speaker. Connect the provided Type-C charging cable to the speaker's Type-C port (located under the protective flap) and the other end to a USB power adapter (not included). The LED indicator will show charging status.



The speaker features a Type-C port for charging and can also act as a power bank for emergency charging of other devices.

2. Powering On/Off

Press and hold the **Power button** () for 2-3 seconds to power the speaker on or off. A sound prompt will indicate the power status.

3. Bluetooth Pairing

Upon powering on, the speaker will automatically enter Bluetooth pairing mode, indicated by a flashing blue LED. On your device (smartphone, tablet, etc.), enable Bluetooth and select "NOTABRICK Ni" from the list of available devices. A confirmation sound will indicate successful pairing.

4. Multiple Playback Modes

The speaker supports various input methods:




- **Bluetooth Mode:** Connect wirelessly as described above.
- **AUX-in Mode:** Use the provided 3.5mm AUX cable to connect to devices without Bluetooth.
- **SD/TF Card Mode:** Insert a micro SD/TF card with audio files into the designated slot.
- **USB Flash Drive Mode:** Insert a USB flash drive with audio files into the USB port.



The speaker's ports are protected by a waterproof flap, allowing for various wired connections.


OPERATING THE SPEAKER

1. Button Functions

Button	Function
Power ()	Press and hold for 2-3 seconds to Power On/Off.
Volume Up (+)	Short press to increase volume. Long press for next track.
Volume Down (-)	Short press to decrease volume. Long press for previous track.
Play/Pause ()	Short press to Play/Pause music. Short press to Answer/End calls. Long press to Reject calls.
Mode (M)	Short press to switch between Bluetooth, AUX, SD/TF, and USB modes. Long press to change LED light modes.
Bluetooth ()	Short press to disconnect current Bluetooth device. Long press to enter TWS (True Wireless Stereo) pairing mode.

2. LED Lighting Function

The speaker features dynamic 7-color LED lighting that synchronizes with the music. Press and hold the **Mode (M)** button to cycle through different light modes or turn the lights off.



Dynamic RGB lighting adds a visual element to your audio experience.

3. Deep Bass and DSP Technology


Equipped with dual large passive radiators and an advanced DSP chip, the NOTABRICK speaker delivers powerful, distortion-free audio with enhanced deep bass. This technology ensures a rich and immersive listening experience across all music genres.



Internal design highlighting the woofers and passive radiators for superior bass performance.

4. IPX7 Waterproof Rating

The speaker boasts an IPX7 waterproof rating, meaning it can be submerged in up to 1 meter of water for 30 minutes without damage. This makes it perfect for use by the pool, at the beach, or in other wet environments.



Enjoy your music worry-free near water with the IPX7 waterproof design.

5. Extended Playtime and Power Bank Functionality

With up to 15 hours of continuous playback at medium volume, your music can last all day. The built-in high-capacity battery also functions as a power bank, allowing you to charge your smart devices on the go via the USB-A output port.

15 HOURS Playtime

Built in 3600mAh battery.



The speaker provides up to 15 hours of playtime on a single charge.

6. Portability

Designed for portability, the speaker features a convenient carry strap and a compact form factor, making it easy to transport for any outdoor activity or gathering.



Easily carry your speaker on adventures with its integrated strap.

MAINTENANCE

To ensure the longevity and optimal performance of your NOTABRICK speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, damp cloth to wipe the speaker's surface. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the protective flap over the ports is securely closed when not in use, especially in wet environments.
- **Battery Care:** For best battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use for extended periods.

TROUBLESHOOTING

If you encounter any issues with your NOTABRICK speaker, please refer to the following common solutions:

- **Speaker not turning on:** Ensure the battery is charged. Connect the speaker to a power source using the Type-C cable.
- **Cannot pair via Bluetooth:** Make sure the speaker is in pairing mode (flashing blue LED). Ensure Bluetooth is enabled on your device and it is within range (10 meters). Try forgetting the device on your phone and re-pairing.
- **No sound:** Check the volume levels on both the speaker and your connected device. Ensure the correct playback mode (Bluetooth, AUX, SD/TF, USB) is selected.
- **Distorted sound:** Reduce the volume on both the speaker and your device. Ensure the audio source is of good quality.
- **Water damage:** While IPX7 rated, prolonged exposure beyond specified limits or exposure to corrosive liquids may cause damage. Ensure the protective flap is always sealed when near water.

SPECIFICATIONS

Feature	Detail
Model Name	Ni
Speaker Type	Outdoor
Speaker Maximum Output Power	40 Watts
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth 5.3
Bluetooth Range	10 Meters
Audio Output Mode	Stereo, Surround Sound
Special Features	LED Light, Built-In Microphone, Stereo Pairing, Built-In Powerbank, USB Port, DSP Chip, Deep Bass
Water Resistance Level	IPX7 Waterproof
Battery Life	15 Hours
Power Source	Battery Powered (1 Lithium Ion battery included)

Feature	Detail
Product Dimensions	3.9"D x 3.9"W x 9.4"H
Item Weight	3.34 pounds
Included Components	Speaker, Type-C charging cable, AUX cable, Quick Use Reading Guide
UPC	768447594734

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided on the product packaging or visit the official NOTABRICK website. Keep your purchase receipt for any warranty claims.