

[Manuals.plus](#) /

› [Vicsoon](#) /

› Vicsoon Touch Wake Up Night Light with Sunrise Simulation Alarm Clock Instruction Manual (Model: B0CFXY8XQS)

Vicsoon B0CFXY8XQS

Vicsoon Touch Wake Up Night Light with Sunrise Simulation Alarm Clock (Model: B0CFXY8XQS)

Instruction Manual

[Overview](#)

[Setup](#)

[Operation](#)

[Specifications](#)

[Troubleshooting](#)

1. PRODUCT OVERVIEW

The Vicsoon Touch Wake Up Night Light is a versatile device designed to enhance your sleep and wake-up experience. It combines a sunrise simulation alarm clock, a dimmable night light with multiple color options, and a sound machine with natural sleep aid sounds. Crafted from toy-grade material, it prioritizes safety and eye comfort, making it suitable for all users, including children.



Image: The Vicsoon Touch Wake Up Night Light, showcasing its sleek design and digital time display.

2. SETUP

2.1 Unboxing and Initial Power-On

- Carefully remove the alarm clock and all accessories from the packaging.
- Connect the provided USB cable to the device's input port and plug the adapter into a power outlet. The digital display will light up.



5.9 inch

Stable Base



4 inch

Ⓣ Timer Setting
(Turn off the lamp at 10/30/60 mins)

⌚ Clock Settings

⊖ Decrease volume/Adjust time&alarm

⊕ Increase volume/Adjust time&alarm

⌚ Alarm clock settings

SPECIFICATIONS

⏻	Input:5V/1A
💡	Lighting Power:3W
⚖️	Weight:0.63lbs(288g)
🔧	Material:Toy-grade ABS + PP

What's in the box





① Vicsoon Sunrise Alarm Clock

② User Manual

③ An Adapter

Image: The Vicsoon Touch Wake Up Night Light, showing its dimensions, specifications, and included accessories: the alarm clock, user manual, and power adapter.

2.2 Setting the Time

- Locate the "Time Set" button on the device's control panel (usually on the bottom or top).
- Press and hold the "Time Set" button until the hour display starts blinking.
- Use the +/- buttons (or rotating dial if available) to adjust the hour. Press "Time Set" again to confirm.
- Repeat the process for setting the minutes.
- Confirm AM/PM setting if applicable.

3. OPERATING INSTRUCTIONS

3.1 Sunrise Simulation Alarm

The sunrise simulation feature gradually increases light intensity 30 minutes before your set alarm time, mimicking a natural sunrise for a gentle awakening. This helps your body naturally prepare to wake up.

- Set your desired alarm time using the alarm setting buttons.
- Ensure the sunrise simulation feature is activated (refer to the manual for specific button/touch controls).
- The light will gradually brighten over 30 minutes before your alarm sounds.




Image: A visual representation of the sunrise simulation, showing light intensity increasing from 0% to 100% over a 30-minute period before the alarm.

3.2 RGB Mood Lights & Dimmable Brightness

The night light offers soft warm white light with 3 adjustable brightness levels and a rich blend of vibrant RGB colors (blue, purple, red, orange, green, and a color cycle mode). Control is typically via smart touch.

- Tap the light control area (often the top surface) to cycle through warm white brightness levels (low, medium, high).
- Long press the light control area to switch to RGB color mode. Tap again to cycle through individual colors or activate the color cycle.
- To dim or brighten the RGB colors, use the dedicated brightness control buttons or touch-and-hold functionality.



Image: The alarm clock showcasing its 6 RGB mood light options: Pink, Blue, Green, Purple, Orange, and a dynamic Color Cycle.




Image: Three distinct brightness levels (30%, 60%, 100%) for the warm white light, demonstrating its dimmable feature.

3.3 Sleep Aid Sounds & Sunset Simulation

The device offers 7 natural sleep aid sounds (Birdsong, Ocean Wave, Streams, Beep, Rain, light only, beep only) to help you relax. The sunset simulation gradually dims the light, mimicking a natural sunset to promote relaxation before sleep. A sleep timer can automatically turn off audio or alarms.

- Press the "Sound" button to cycle through the available sleep aid sounds.
- Adjust the volume of the sounds using the volume control buttons.
- To activate sunset simulation, press the "Sunset" button. The light will gradually dim over a set period (e.g., 10/30/60 minutes).
- Set the sleep timer (10/30/60 minutes optional) to automatically turn off sounds or alarms after a chosen duration.



Image: Icons representing the various natural sounds available: Birdsong, Ocean Wave, Streams, Beep, and Rain, designed to aid sleep.



Image: A visual representation of the sunset simulation, showing light intensity decreasing from 100% to 0% over a customizable period.

3.4 Snooze Function

When the alarm sounds, tap the snooze button (often the main touch area on top) to temporarily silence the alarm for 5 minutes. The alarm will sound again after the snooze period.

3.5 Bluetooth Speaker Functionality

The device can function as a Bluetooth speaker, allowing you to play audio from your smartphone or other Bluetooth-enabled devices.

- Press the "BT" (Bluetooth) button to activate Bluetooth pairing mode. The device will become discoverable.
- On your smartphone or device, search for available Bluetooth devices and select "Vicsoon Alarm Clock" (or similar name).
- Once paired, you can stream audio directly to the alarm clock.

Your browser does not support the video tag.

Video: An official Vicsoon video demonstrating the features of the Sunrise Alarm Clock, including its light and sound functions.

4. SPECIFICATIONS

Feature	Detail
Brand	Vicsoon
Model	B0CFXY8XQS
Color	Pink
Display Type	Digital
Style	Sunrise alarm clock
Special Features	Adjustable Brightness, Alarm, Auto Dimmable, Mood Light, Noise Machine
Product Dimensions	4"W x 5.9"H
Power Source	Corded Electric

Material	Plastic
Item Weight	10.2 ounces
Connectivity Technology	USB
Certifications	CE, FCC, RoHS

5. MAINTENANCE

- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the device away from water or excessive moisture.
- Avoid dropping the device or subjecting it to strong impacts.

6. TROUBLESHOOTING

6.1 Alarm Not Sounding / Light Not Activating

- Ensure the alarm is correctly set and activated (check alarm icon on display).
- Verify the volume level for the alarm sound is not set to zero.
- Check if the device is properly plugged into a power source.

6.2 Display Too Bright/Dim

- Use the dedicated dimmer or brightness control buttons to adjust the display intensity.

6.3 Bluetooth Pairing Issues

- Ensure the device is in Bluetooth pairing mode (indicated by a blinking Bluetooth icon).
- Turn off and on Bluetooth on your smartphone, then try pairing again.
- Move your smartphone closer to the alarm clock to ensure a strong signal.

7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided in the original product packaging or visit the official Vicsoon website. The product is CE, FCC, and RoHS certified, ensuring strict safety and quality standards.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question