

**KBICE KB 3.0 + Side Tank**

# KBICE 3.0 Countertop Nugget Ice Maker Instruction Manual

Brand: KBICE | Model: KB 3.0 + Side Tank

## 1. INTRODUCTION

Thank you for choosing the KBICE 3.0 Countertop Nugget Ice Maker. This appliance is designed to provide you with soft, chewable nugget ice quickly and conveniently. Please read this manual thoroughly before operation to ensure safe and efficient use of your ice maker.

## 2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using the appliance.
- Ensure the voltage matches the rating label on the appliance.
- Do not immerse the power cord, plug, or any part of the appliance in water or other liquids.
- Unplug from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep adequate ventilation space around the ice maker (at least 6 inches on all sides).
- This appliance is for household use only.

## 3. WHAT'S IN THE Box

- KBICE 3.0 Nugget Ice Maker Unit
- Side Water Tank
- Instructions Manual
- Quick Start Guide
- Citric Acid Cleaning Packets
- Water Funnel

## 4. PRODUCT OVERVIEW

The KBICE 3.0 is a compact countertop ice maker designed for convenience and efficiency. It produces soft, chewable nugget ice, perfect for various beverages.



**Figure 4.1:** KBICE 3.0 Nugget Ice Maker. This image shows the compact design of the ice maker with its integrated side water tank and a glass filled with nugget ice.



**Figure 4.2:** Self-Dispensing Feature. The ice maker features automatic dispensing, eliminating the need for an ice scoop.



**Figure 4.3:** Quick Ice Making. Produces ice in as little as 35 minutes, with a maximum capacity of 32 lbs in 24 hours, and operates quietly at 42dBA.



**Figure 4.4:** 2 lbs Storage Capacity. The internal bin can store up to 2 pounds of nugget ice.



**Figure 4.5:** Self-Cleaning Function. The ice maker

features a self-cleaning mode activated by holding the 'Clean' button for 3 seconds.



**Figure 4.6:** Convenient Side Water Tank. The external water tank holds up to 125 fluid ounces and automatically replenishes the internal tank.



**Figure 4.7:** LED Touch Panel. Simple and straightforward controls for easy operation.

## 5. SETUP

- 1. Unpacking:** Carefully remove the ice maker and all accessories from the packaging.
- 2. Placement:** Place the ice maker on a flat, stable surface away from direct sunlight and heat sources. Ensure there is at least 6 inches of clearance on all sides for proper ventilation.
- 3. Initial Cleaning:** Before first use, perform a self-cleaning cycle. Refer to the 'Maintenance' section for detailed cleaning instructions.
- 4. Fill Water Tank:** The ice maker comes with a detachable side water tank. You can either detach the tank and fill it directly or use the provided funnel to pour water into the main unit's reservoir. The main internal water tank holds 88 ounces, and the side tank holds 125 fluid ounces.

## ACCESS TO REFILL WATER



**Figure 5.1:** Water Port for Funnel. Use the provided funnel to easily add water to the main reservoir.



**Figure 5.2:** Side Tank Attachment. The side tank attaches magnetically and automatically replenishes the main reservoir.

## 6. OPERATING INSTRUCTIONS

- Power On:** Plug the ice maker into a grounded electrical outlet. The LED touch panel will illuminate.
- Making Ice:** Press the 'Make Ice' button on the LED touch panel. The machine will begin the ice-making cycle. The first batch of ice typically takes about 40 minutes. The machine will continuously make ice until the ice bin is full or the water tank is empty.
- Dispensing Ice:** Place your glass or container under the ice dispenser outlet. Press and hold the

'Dispense' button on the LED touch panel to release nugget ice. Release the button to stop dispensing.

4. **Add Water Indicator:** If the 'Add Water' indicator light illuminates, it means the water reservoir is low. Refill the side tank or the main reservoir as described in the 'Setup' section.



**Figure 6.1:** Automatic Ice Dispensing. Simply press the 'Dispense' button to get ice directly into your cup.



**Figure 6.2:** Intuitive LED Touch Panel. Easily control ice making and dispensing with clear indicators.

## 7. MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your KBICE 3.0 Nugget Ice Maker.

1. **Self-Cleaning Cycle:** The ice maker features a convenient self-cleaning function. To activate, ensure the water tank is full, then press and hold the 'Clean' button for 3 seconds. The cleaning cycle will run for approximately 30 minutes.
2. **Drip Tray Cleaning:** The drip tray should be emptied and cleaned regularly to prevent water overflow and maintain hygiene. Simply pull out the tray, empty any water, wash with mild soap and water, rinse, and dry thoroughly before replacing.

- 3. Exterior Cleaning:** Wipe the exterior of the ice maker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- 4. Long-Term Storage:** If the ice maker will not be used for an extended period, perform a self-cleaning cycle, drain all water from the unit and tanks, and dry thoroughly. Store in a cool, dry place.



Figure 7.1: Initiating Self-Cleaning. Hold the 'Clean' button for 3 seconds to start the automatic cleaning process.

## 8. TROUBLESHOOTING

If you encounter any issues with your ice maker, please refer to the following common problems and solutions. For more detailed troubleshooting, consult the Quick Start Guide or contact customer support.

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir; water line blocked; machine not powered on.	Fill water tank; check for kinks in water line; ensure power cord is securely plugged in.
Ice is not dispensing.	Ice bin is empty; dispense button not held down.	Wait for ice production; press and hold the 'Dispense' button.

Problem	Possible Cause	Solution
Unusual noise during operation.	Lack of water; machine needs cleaning; ventilation blocked.	Refill water; run self-cleaning cycle; ensure proper clearance around the unit.
"Add Water" indicator is on.	Water level is low.	Refill the water tank.

## 9. SPECIFICATIONS

Feature	Specification
Product Dimensions	16"D x 16"W x 17.5"H
Weight	55 Pounds
Ice Production Capacity	Up to 32 lbs in 24 hours
Ice Storage Capacity	2 lbs
Water Tank Capacity (External)	125 fluid ounces
Water Tank Capacity (Internal)	88 fluid ounces
Noise Level	48dBA
Wattage	20 kWh
Manufacturer	FLURIDA

## 10. WARRANTY AND SUPPORT

KBICE offers a **1-Year Quality Protection** for this product. Additionally, you are eligible for **30-day easy returns**. For any questions, troubleshooting assistance, or warranty claims, please contact KBICE customer support. Information can typically be found on the product packaging or the official KBICE website.

This product is from a small business brand. Support small businesses.