

[Manuals.plus](#) /

> [SKIL](#) /

> SKIL Twist 2.0 Rechargeable 4V Screwdriver User Manual

## SKIL SD5619-01

# SKIL Twist 2.0 Rechargeable 4V Screwdriver

Model: SD5619-01

## INTRODUCTION

The SKIL Twist 2.0 4V Rechargeable Screwdriver is designed for quick and comfortable completion of small jobs and repairs, such as assembling furniture or tightening screws in confined spaces. This ergonomic electric screwdriver features a unique pivoting head, multiple torque settings, and an integrated LED light for enhanced visibility. Its convenient USB-C charging port ensures easy recharging.





Image: The SKIL Twist 2.0 Rechargeable 4V Screwdriver, showcasing its compact design and red and black color scheme.

## SAFETY INFORMATION

Always observe basic safety precautions when using electric tools to reduce the risk of fire, electric shock, and personal injury.

- **Read all instructions:** Familiarize yourself with the tool's operation and safety guidelines before use.
- **Keep work area clean:** Cluttered areas invite accidents.
- **Avoid dangerous environments:** Do not use power tools in damp or wet locations, or expose them to rain. Keep work area well lit.
- **Keep children away:** All visitors should be kept at a safe distance from the work area.
- **Dress properly:** Do not wear loose clothing or jewelry. Contain long hair.
- **Use safety equipment:** Always wear eye protection. Use a face or dust mask if operation is dusty.

- **Do not overreach:** Keep proper footing and balance at all times.
- **Disconnect tools:** Disconnect the tool from the power source before making any adjustments, changing accessories, or storing.
- **Avoid unintentional starting:** Ensure the switch is in the off position before plugging in.
- **Check for damaged parts:** Before further use, carefully check the tool for proper operation and intended function.
- **Do not force tool:** It will do the job better and safer at the rate for which it was designed.
- **Store idle tools:** When not in use, tools should be stored in a dry, high, or locked-up place, out of reach of children.

## PACKAGE CONTENTS

---

Verify that all items are present in your package:

- SKIL Twist 2.0 4V Rechargeable Screwdriver (1)
- USB Type-C Charging Cable (1)
- 2-inch Bits: PH2 (1), SL6 (1)



Image: The SKIL Twist 2.0 Screwdriver displayed in its retail packaging, showing the screwdriver, USB-C cable, and two bits.

## SETUP

### Charging the Screwdriver

The SKIL Twist 2.0 features an integrated battery with a USB-C charging port. Before first use, fully charge the screwdriver.

1. Locate the USB-C charging port on the screwdriver.
2. Connect the provided USB-A to USB-C charging cable to the screwdriver.
3. Plug the USB-A end of the cable into a compatible USB power adapter (not included) or a USB port on a computer.
4. Allow the screwdriver to charge until the battery indicator lights show a full charge.



## INTEGRATED BATTERY WITH USB-C CHARGING PORT

Image: The SKIL Twist 2.0 screwdriver connected to a USB-C charging cable, illustrating the charging port location.

### Inserting and Removing Bits

The screwdriver uses a 1/4-inch hex collet for quick bit changes.

1. Ensure the screwdriver is turned off.
2. Firmly push the desired 1/4-inch hex bit into the collet until it clicks into place.
3. To remove a bit, pull it straight out from the collet.



## 1/4-INCH HEX COLLET

Image: A hand inserting a screwdriver bit into the 1/4-inch hex collet of the SKIL Twist 2.0.

### OPERATING INSTRUCTIONS

#### Pivoting Head Adjustment

The screwdriver's head can pivot and lock into three positions (0, 22.5, and 45 degrees) for improved ergonomics and access in tight spaces.

1. To adjust the head, locate the pivot lock mechanism.
2. Press the lock button and rotate the head to the desired angle (0°, 22.5°, or 45°).
3. Release the lock button to secure the head in position. Ensure it is fully locked before operation.



## PIVOTING HEAD WITH LOCK OFF

Image: A hand demonstrating the pivoting head feature of the SKIL Twist 2.0, showing it angled for better access.

### **Forward & Reverse Trigger Button**

The trigger button controls the rotation direction of the screwdriver.

- Press the top part of the trigger button for forward (tightening) rotation.
- Press the bottom part of the trigger button for reverse (loosening) rotation.
- Release the button to stop the screwdriver.



## FORWARD & REVERSE TRIGGER BUTTON

Image: A close-up of the SKIL Twist 2.0, highlighting the forward and reverse trigger button for easy one-finger operation.

### Torque Setting Control

The screwdriver features three torque settings to adapt to various applications, preventing overtightening or stripping screws.

1. Locate the torque setting selector on the tool body.
2. Rotate the selector to choose the desired torque level (1, 2, or 3).
3. Start with a lower torque setting for delicate materials or small screws and increase if more power is needed.



## TORQUE SETTING CONTROL

Image: A hand adjusting the torque setting control on the SKIL Twist 2.0, showing the three available settings.

### LED Light

An integrated LED light illuminates the work area for improved visibility in low-light conditions.

- The LED light automatically activates when the trigger button is pressed.
- It will turn off when the trigger is released.



## LED LIGHT

Image: The SKIL Twist 2.0 screwdriver with its LED light illuminated, shining on a screw in a dark cabinet.

### MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your SKIL Twist 2.0 screwdriver.

- **Cleaning:** Wipe the tool with a clean, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the screwdriver in a dry place, away from direct sunlight and extreme temperatures. Ensure it is fully charged before long-term storage.
- **Battery Care:** Avoid completely draining the battery frequently. Recharge as needed.
- **Bit Maintenance:** Keep screwdriver bits clean and free of debris. Replace worn or damaged bits to prevent stripping screws.

### TROUBLESHOOTING

If you encounter issues with your SKIL Twist 2.0 screwdriver, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Screwdriver does not turn on.	Battery is depleted.	Charge the screwdriver using the provided USB-C cable.
Screwdriver lacks power or stops during use.	Low battery charge. / Torque setting is too low.	Recharge the battery. / Increase the torque setting.
Bit slips or strips screw head.	Incorrect bit size. / Torque setting is too high or too low. / Worn bit.	Ensure correct bit size for the screw. Adjust torque setting. Replace worn bits.
Pivoting head does not lock.	Lock mechanism obstructed or damaged.	Ensure no debris is blocking the lock. If damaged, contact customer support.

## SPECIFICATIONS

Feature	Detail
Model Number	SD5619-01
Power Source	Battery Powered
Voltage	4 Volts (DC)
Maximum Power	4 Watts
Torque	22 Inch Pounds
Speed	240 RPM
Battery Type	Lithium Ion (Integrated)
Charging Port	USB Type-C
Dimensions (L x W x H)	16 x 5 x 23.01 cm
Item Weight	372 g
Special Features	Built-In LED Working Light, Lightweight, Adjustable Mode (Pivoting Head)
Material	Plastic

## WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official SKIL website or contact their customer service department. Keep your purchase receipt as proof of purchase for any warranty claims.

**SKIL Customer Service:** Please visit [www.skil.com](http://www.skil.com) for contact information and support resources.

