



**Manuals.plus /**

› **PINDOWS /**

› PINDOWS Watch for Men, 50M Waterproof Analog Digital Watches Watch Outdoor Sports Electronic Watch Date Multi-Function LED Alarm Stopwatch. White - User Manual

## **PINDOWS PDS-603-N8**

# **PINDOWS Watch User Manual**

Model: PDS-603-N8

## **INTRODUCTION**

---

Thank you for choosing the PINDOWS Watch. This manual provides detailed instructions for setting up, operating, and maintaining your new watch. Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your device.



Image: Front view of the PINDOWS Watch in White. This watch features a clear, transparent case and strap, with a black digital and analog display. The watch face shows the time, date, and various indicators for its multi-function capabilities.

## PRODUCT FEATURES

---

- **LED Backlight:** Provides illumination for clear reading in low-light conditions.
- **50 Meters Waterproof:** Suitable for cold baths, handwashing, and light rain exposure. Not for diving or hot water.
- **12/24-Hour Format:** Time display can be switched between standard 12-hour and military 24-hour formats.
- **Calendar Week Display:** Shows the current day of the week.
- **Stopwatch Timing:** Precise 1/100 second stopwatch function.
- **Three Groups of Alarms:** Set up to three independent alarms.
- **Manual Sleep Function:** A specific function for power saving or display management.
- **Countdown Function:** A timer that counts down from a set time.
- **Dual Time Zones:** Ability to display two different time zones simultaneously.
- **Shockproof Design:** Enhanced durability for outdoor and sports activities.

# LED BACKLIGHT

## FEARLESS OF DARKNESS




Image: The PINDOWS Watch with its green LED backlight illuminated, demonstrating its visibility in darkness. The digital display is clearly visible, showing the time and date.



## 50M PRECISION WATERPROOF

Cold bath Drenched in the rain  
Swim Handwashing

Image: A PINDOWS Watch on a wrist, with water splashing around it, illustrating its 50-meter waterproof capability. The image emphasizes its suitability for activities like handwashing or being caught in the rain.

### WATCH COMPONENTS AND BUTTONS

---



Image: A detailed diagram of the PINDOWS Watch, highlighting its various buttons and display areas. Labels point to the LIGHT button, START/PAUSE button, DATE DISPLAY, WEEK DISPLAY, MODE button, TIME DISPLAY, ADJUSTMENT button, and ROTATING CROWN.

- **LIGHT Button:** Activates the LED backlight.
- **MODE Button:** Cycles through different modes (Time, Alarm, Stopwatch, Countdown).
- **START/PAUSE Button:** Used to start and pause functions like the stopwatch or countdown.
- **ADJUSTMENT Button:** Used to adjust settings within a mode.
- **ROTATING CROWN:** This crown may be used for setting the analog time or for other adjustments, depending on the watch's specific design.
- **DATE DISPLAY:** Shows the current date.
- **WEEK DISPLAY:** Shows the current day of the week.
- **TIME DISPLAY:** Shows the current time in digital format.

## SETUP AND INITIAL OPERATION

## Setting the Time and Date

1. Press the **MODE** button repeatedly until you reach the Time Setting mode (usually indicated by flashing digits).
2. Press the **ADJUSTMENT** button to select the digit you wish to change (e.g., hours, minutes, year, month, day).
3. Use the **START/PAUSE** button to increase the selected value.
4. Repeat steps 2 and 3 until all desired time and date settings are correct.
5. Press the **MODE** button again to exit the Time Setting mode.

## Activating the Backlight

To illuminate the display in dark conditions, press the **LIGHT** button located on the top left side of the watch. The backlight will remain on for a few seconds.

## OPERATING FUNCTIONS

---

### Using the Stopwatch

1. Press the **MODE** button until the stopwatch display appears (usually showing "00:00:00").
2. Press the **START/PAUSE** button to begin timing.
3. Press the **START/PAUSE** button again to pause the stopwatch.
4. To resume, press **START/PAUSE**. To reset, press the **ADJUSTMENT** button while the stopwatch is paused.

### Setting Alarms

1. Press the **MODE** button until the Alarm mode is displayed (e.g., "AL1").
2. Use the **ADJUSTMENT** button to select the alarm you wish to set (AL1, AL2, AL3).
3. Press the **ADJUSTMENT** button to select the hour or minute digits.
4. Use the **START/PAUSE** button to adjust the time.
5. Press the **MODE** button to confirm and exit.
6. To turn an alarm on or off, navigate to the alarm mode and use the **START/PAUSE** button to toggle its status.

### Using the Countdown Timer

1. Press the **MODE** button until the Countdown Timer mode is displayed.
2. Use the **ADJUSTMENT** button to set the desired countdown time (hours, minutes, seconds).
3. Press the **START/PAUSE** button to begin the countdown.
4. Press the **START/PAUSE** button again to pause the countdown.
5. To resume, press **START/PAUSE**. To reset, press the **ADJUSTMENT** button while the countdown is paused.

## MAINTENANCE AND CARE

---

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and mild soap, then dry thoroughly.
- **Water Resistance:** While the watch is 50M waterproof, avoid pressing buttons underwater. Do not expose to hot water or steam (e.g., hot showers, saunas) as this can compromise the seals.
- **Temperature:** Avoid exposing the watch to extreme temperatures, both hot and cold, for prolonged periods.
- **Chemicals:** Keep the watch away from solvents, detergents, perfumes, and other chemicals that may damage the case or strap materials.
- **Battery Replacement:** The watch uses 1 Lithium Metal battery. When the display dims or functions become erratic, it

may be time for a battery replacement. It is recommended to have this done by a professional to ensure water resistance is maintained.

## TROUBLESHOOTING


---

Problem	Possible Cause	Solution
Display is dim or blank.	Low battery.	Replace the battery.
Buttons are unresponsive.	Watch may be in a locked mode or battery is too low.	Try pressing all buttons to see if any respond. If not, replace battery. Avoid pressing buttons underwater.
Time is inaccurate.	Time not set correctly or low battery.	Reset the time and date. If problem persists, replace battery.
Water inside the watch.	Seals compromised due to impact, extreme temperature, or button pressing underwater.	Stop using the watch immediately. Seek professional repair to prevent further damage.

## SPECIFICATIONS

---

# PRODUCT PARAMETERS







Weight: 60g	Band Material: TPU
Case Material: ABS	Bottom Cover Material: Stainless Steel
 Case Diameter: 1.9inch/48mm	 Band Width: 0.86inch/22mm
 Case Thickness: 0.71inch/18mm	 Band Length: 6.9inch -8.8inch

Image: A technical diagram illustrating the key dimensions and material specifications of the PINDOWS Watch. It shows measurements for case diameter, thickness, band width, and length, along with material composition.

- **Model Number:** PDS-603-N8
- **Brand:** PINDOWS
- **Display Type:** Analog-Digital
- **Water Resistance:** 50 Meters (5 ATM)
- **Case Material:** PU (Polyurethane)
- **Band Material:** PU (Polyurethane)
- **Mirror Material:** PMMA (Acrylic)
- **Back Cover & Clasp Material:** Stainless Steel
- **Dial Case Diameter:** 2.08 inches / 5.3 cm
- **Dial Case Thickness:** 0.74 inches / 1.89 cm
- **Band Length:** 10.23 inches / 26 cm
- **Band Width:** 0.85 inches / 2.18 cm

- **Weight:** Approximately 63 Grams
- **Battery Type:** 1 Lithium Metal battery

## WARRANTY AND SUPPORT

---

PINDOWS provides a **12-month service warranty** for this product from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use.

For any questions, concerns, or support needs regarding your PINDOWS Watch, please contact our customer service.

We are committed to providing the best products and services to our customers.

Please refer to your purchase documentation or the retailer's website for specific contact information.

