



Manuals.plus /

› MIEBELY /

› MIEBELY Maserati Remote Control Car User Manual

MIEBELY 27212

MIEBELY Maserati MC20 Remote Control Car User Manual

Model: 27212

INTRODUCTION

Welcome to the MIEBELY Maserati Remote Control Car user manual. This guide provides essential information for setting up, operating, maintaining, and troubleshooting your 1:12 scale Maserati MC20 RC car. Please read this manual thoroughly before use to ensure optimal performance and safety.

IMPORTANT SAFETY INFORMATION

Please observe the following safety precautions:

- Not suitable for infants. Recommended for ages 6 years and up.
- Always operate the RC car in a safe environment, away from people, pets, and obstacles.
- Avoid operating near water or in wet conditions to prevent damage to electronic components.
- Do not touch moving parts during operation.
- Ensure batteries are charged correctly and handled with care.
- Adult supervision is recommended for younger users.
- Clean the car with a soft cloth. Avoid excessive heat or direct strong sunlight.

WHAT'S IN THE BOX

The MIEBELY Maserati MC20 Remote Control Car package includes the following components:

- 1x MIEBELY Maserati MC20 RC Car (1:12 Scale)
- 1x Remote Control Transmitter
- 1x 7.4V 900mAh Lithium-Ion Rechargeable Battery
- 1x USB Charging Cable (for battery)

- 1x User Manual



Image: The complete MIEBELY Maserati MC20 RC car package, including the car, remote control, rechargeable battery, and charging cable.

SETUP

1. Charging the Car Battery

The RC car is powered by a 7.4V 900mAh Lithium-Ion rechargeable battery. Before first use, fully charge the battery.

1. Connect the 7.4V 900mAh Lithium-Ion battery to the provided USB charging cable.
2. Plug the USB charging cable into a standard USB power adapter (not included) or a computer USB port.
3. The indicator light on the USB cable will show the charging status (e.g., red for charging, off or green for fully charged).
4. Charging typically takes approximately 2-3 hours. Do not leave unattended during charging.
5. Once fully charged, disconnect the battery from the charger.



Image: The 7.4V 900mAh Lithium-Ion battery securely placed within its compartment in the RC car.

2. Installing Batteries in the Remote Control

The remote control requires 2x AA batteries (not included).

1. Open the battery compartment cover on the back of the remote control.
2. Insert 2x AA batteries, ensuring correct polarity (+/-).
3. Close the battery compartment cover securely.

3. Installing the Car Battery

1. Locate the battery compartment on the underside of the RC car.
2. Open the battery compartment cover, usually secured by a screw.
3. Connect the fully charged 7.4V 900mAh Lithium-Ion battery to the car's power connector.
4. Carefully place the battery inside the compartment.
5. Close and secure the battery compartment cover.

OPERATING INSTRUCTIONS

1. Powering On

1. Turn on the RC car by sliding the power switch located on the underside of the car to the 'ON' position.
2. Turn on the remote control by sliding its power switch to the 'ON' position.
3. The remote control and car will automatically pair. An indicator light on the remote control will confirm successful pairing.

2. Basic Controls

The remote control features a steering wheel and a trigger for throttle control.

- **Forward/Backward:** Pull the trigger towards you to move the car forward. Push the trigger away from you to move the car backward.
- **Left/Right Steering:** Rotate the steering wheel left or right to turn the car in the corresponding direction.



Image: A hand demonstrating the use of the remote control's steering wheel for precise directional control.

3. Steering Trim Adjustment

If the car does not drive straight when the steering wheel is centered, use the steering trim adjustment dial on the remote control to fine-tune the alignment.



Image: A close-up view of the steering trim adjustment dial, labeled 'R' and 'L', used to correct the car's straight-line tracking.

4. Driving Tips

- Operate on smooth, flat surfaces for best performance.
- The 2.4Ghz frequency allows for a control range of up to 200 feet and supports multiple cars operating simultaneously without interference.
- The car features functional LED lights for a realistic driving experience.
- The doors can be opened manually for display purposes, handle with care.

Multipayer Games Without Interference



Image: Two MIEBELY Maserati RC cars, one white and one yellow, being controlled simultaneously, illustrating the 2.4Ghz anti-interference feature.

MAINTENANCE

1. Cleaning

- Clean the car with a soft, dry cloth after each use to remove dust and debris.
- Avoid using water or chemical cleaners, as these can damage electronic components.

2. Storage

- When not in use, turn off both the RC car and the remote control.
- Remove batteries from the remote control if storing for extended periods.
- Store the car and remote control in a cool, dry place, away from direct sunlight and extreme temperatures.

3. Battery Care

- Always allow the battery to cool down before recharging.
- Do not overcharge or over-discharge the battery.
- If the battery is not used for a long time, charge it periodically to maintain its health.

Make it more resistant to falling

Use ABS material



Proportional Steering



Image: The MIEBELY Maserati RC car, constructed from durable ABS material, depicted in a scenario demonstrating its impact resistance.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Cause	Solution
Car does not respond to remote control.	<ul style="list-style-type: none">◦ Car or remote control is off.◦ Low battery in car or remote control.◦ Not paired correctly.◦ Out of range.	<ul style="list-style-type: none">◦ Ensure both are switched ON.◦ Charge car battery; replace remote control batteries.◦ Turn both off and on again to re-pair.◦ Bring car closer to remote control.
Car drives slowly or inconsistently.	<ul style="list-style-type: none">◦ Low car battery.◦ Obstruction in wheels.	<ul style="list-style-type: none">◦ Recharge car battery.◦ Check and clear any debris from wheels.
Car does not drive straight.	Steering trim needs adjustment.	Use the steering trim dial on the remote control to adjust.
Doors are difficult to open/close or break easily.	Excessive force applied.	Operate doors gently. Note: The doors are designed for display and require careful handling.

SPECIFICATIONS

Product Specifications

Feature	Detail
Model	Maserati MC20 (Model 27212)
Scale	1:12
Car Battery	7.4V 900mAh Lithium-Ion (included)
Remote Control Batteries	2x AA (not included)
Frequency	2.4 GHz
Control Range	Up to 200 feet (approx. 60 meters)
Maximum Speed	12 KM/h
Product Dimensions	16.5 x 6.4 x 7 inches (41.9 x 16.3 x 17.8 cm)
Item Weight	3.52 pounds (1.6 kg)
Material	Thickened, non-toxic ABS
Recommended Age	6 years and up

Authorize Maserati



Image: The MIEBELY Maserati MC20 RC car with its approximate dimensions (length, width, height) indicated.

CUSTOMER SUPPORT

If you encounter any functional problems with your MIEBELY Maserati RC car, or if any items are missing from your package, please contact our after-sales support team for assistance. Refer to the product packaging or the retailer's website for specific contact information.