Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Gotrax /
- Gotrax GXL V2 Electric Scooter User Manual

Gotrax GXL V2

Gotrax GXL V2 Electric Scooter User Manual

Model: GXL V2 | Brand: Gotrax

Introduction

This manual provides essential information for the safe operation, maintenance, and troubleshooting of your Gotrax GXL V2 Electric Scooter. Please read this manual thoroughly before your first ride to ensure proper usage and to maximize the lifespan of your scooter.





Image: The Gotrax GXL V2 Electric Scooter in its upright, unfolded position, showcasing its sleek black and white design with red accents.

SAFETY GUIDELINES

- Always wear a helmet and appropriate safety gear.
- Do not ride in wet conditions or on slippery surfaces.
- Adhere to local traffic laws and regulations.
- Ensure the scooter is fully charged before each use.
- Regularly inspect tires, brakes, and all mechanical components.
- Do not exceed the maximum weight limit of 220 pounds.
- Recommended age for riders is 13 years and up.

SETUP

Unboxing and Initial Assembly

The Gotrax GXL V2 Electric Scooter comes mostly pre-assembled. Follow these steps for final setup:

- 1. Carefully remove the scooter from its packaging.
- 2. Unfold the scooter by releasing the folding mechanism. Ensure it clicks securely into place.
- 3. Attach the handlebars to the stem.
- 4. Ensure all screws and bolts are tightened securely.



Image: A person standing next to an unfolded Gotrax GXL V2 Electric Scooter, ready for use. This image illustrates the scooter's full size and stable stance.

Charging the Battery

Before first use, fully charge the scooter's battery. The 36V 5.2Ah battery has a 187 Wh capacity and takes approximately 4 hours to fully charge.

- Locate the charging port on the scooter.
- Connect the charger to the port, then plug it into a standard electrical outlet.
- The LED display will indicate charging status.
- Disconnect the charger once charging is complete.

OPERATING INSTRUCTIONS

Powering On/Off

- To power on: Press and hold the power button on the digital display.
- To power off: Press and hold the power button again until the display turns off.

Riding the Scooter

- 1. Place one foot firmly on the deck.
- 2. Push off with your other foot to gain initial momentum.
- 3. Press the accelerate button on the handlebar to engage the motor.
- 4. Maintain balance and steer using the handlebars.



Image: A close-up view of the Gotrax GXL V2 Electric Scooter's digital display, showing the battery level, speed, and headlight indicator. This display provides essential ride information at a glance.

Braking

- The scooter features an EABS (Electronic Anti-lock Braking System) and a rear disc brake.
- To brake: Gently squeeze the brake lever on the handlebar.
- For emergency stops: Apply firm pressure to the brake lever.



Image: An infographic highlighting key features of the Gotrax GXL V2 Electric Scooter, including its 9-12 miles travel distance, 15.5 mph max speed, rear disc brake and EABS brake, 8.5" solid tire, one-step folding system, and 250W motor.

Headlight Operation

- To turn on the headlight: Press the power button once while the scooter is on.
- To turn off the headlight: Press the power button once again.



Image: A person riding the Gotrax GXL V2 Electric Scooter at night, demonstrating the bright front headlight for improved visibility.

Folding and Carrying

- To fold: Engage the one-step folding mechanism located at the base of the stem.
- Ensure the stem locks into the folded position.
- The scooter can then be easily carried by the stem.



Image: A person carrying the folded Gotrax GXL V2 Electric Scooter onto a train, illustrating its portability and ease of transport for commuting.

MAINTENANCE

Tire Care

The GXL V2 features 8.5" solid inner honeycomb tires, which are maintenance-free and anti-piercing, eliminating the need for inflation.



Image: A detailed view of the Gotrax GXL V2 Electric Scooter's 8.5" inner honeycomb tires, highlighting their airless design, shock absorption, and maintenance-free benefits.

Cleaning and Storage

- Wipe the scooter with a damp cloth after use. Avoid using excessive water or harsh chemicals.
- Store the scooter in a cool, dry place away from direct sunlight and extreme temperatures.
- For long-term storage, ensure the battery is charged to about 50-70% and recharge it every 30-60 days to prevent deep discharge.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Scooter not turning on	Low battery; Loose connections	Charge the battery; Check all connections
Reduced range/speed	Battery degradation; Overload; Terrain	Ensure full charge; Reduce load; Ride on flat surfaces

Problem	Possible Cause	Solution
Brakes not responsive	Brake cable adjustment needed	Adjust brake cable tension (refer to detailed repair guide or contact support)

For more complex issues, please refer to the official Gotrax support resources or contact customer service.

SPECIFICATIONS

• Model Name: GXL V2

• Motor: 250W

• Max Speed: 15.5 MPH

• Max Range: Up to 12 miles (under optimum conditions)

• Battery: 36V 5.2Ah (187 Wh)

• Charging Time: Approximately 4 hours

Tires: 8.5" Solid Inner Honeycomb
 Brakes: EABS + Rear Disc Brake
 Frame Material: Aluminum Alloy

• Weight: 27 Pounds

• Weight Limit: 220 Pounds

• Product Dimensions: 42.91"L x 17.13"W x 44.49"H

• Age Range: 13 Years and Up

• Special Features: Anti-Puncture Tire, Foldable, Cruise Control, Digital Display, Front Headlight



Image: A diagram illustrating the dimensions of the Gotrax GXL V2 Electric Scooter, showing its length (42.91"), width (17.13"), and height (44.49").

WARRANTY AND SUPPORT

Warranty Information

The Gotrax GXL V2 Electric Scooter comes with a **365-day limited warranty**. This warranty covers manufacturing defects and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, technical assistance, or warranty claims, please visit the official Gotrax website or contact their customer support team. Contact information can typically be found on the product packaging or the official Gotrax website.

You can also visit the Gotrax Store on Amazon for additional product information and support.

© 2024 Gotrax. All rights reserved.

Related Documents - GXL V2

APEX XL ELECTRIC SCOOTE FORWARDS	GOTRAX APEX XL Electric Scooter User Manual - Assembly, Operation, and Safety Guide Comprehensive user manual for the GOTRAX APEX XL Electric Scooter. Learn about assembly, charging, operation, safety tips, maintenance, and troubleshooting. Includes specifications and warranty information.
♪ PET 自ちまると自むやた当ま■!	GOTRAX G4 Electric Scooter User Manual Comprehensive user manual for the GOTRAX G4 Electric Scooter, covering assembly, operation, charging, maintenance, troubleshooting, and safety guidelines.
NEBULA	GOTRAX Nebula Electric Scooter User Manual Comprehensive user manual for the GOTRAX Nebula electric scooter, covering assembly, charging, operation, maintenance, safety guidelines, and warranty information for safe and optimal use.
G Pro ELECTRIC SCOTER GREWMUN.	GOTRAX G Pro Electric Scooter User Manual Comprehensive user manual for the GOTRAX G Pro electric scooter, covering assembly, charging, operation, safety guidelines, maintenance, and troubleshooting. Learn how to safely operate and care for your GOTRAX G Pro.
	GOTRAX Eclipse Ultra Electric Scooter User Manual This user manual provides instructions for assembling, operating, and maintaining the GOTRAX Eclipse Ultra electric scooter. It covers safety precautions, specifications, charging, console functions, riding tips, folding, maintenance, battery information, and warranty details.
GO TRAX SECULT VI STATE OF THE PROPERTY OF TH	GOTRAX GXL/GXL V2 Motor Swap Guide Step-by-step instructions for swapping the motor on a GOTRAX GXL or GXL V2 electric scooter.