

[Manuals.plus](#) /

> [METEESER](#) /

> METEESER Single Din Car Stereo User Manual

## METEESER B0CJ2PCQ8V

# METEESER 6.9 Inch Single Din Car Stereo User Manual

Model: B0CJ2PCQ8V | Brand: METEESER

## 1. PRODUCT OVERVIEW

The METEESER Single Din Car Stereo is a versatile in-car entertainment and navigation system featuring a 6.9-inch IPS touchscreen. It supports wired Apple CarPlay and Android Auto, allowing seamless integration with your smartphone for navigation, communication, and media playback. Equipped with Bluetooth 5.2, FM radio, and a backup camera, this unit enhances your driving experience with convenience and safety.






Figure 1.1: METEESER Single Din Car Stereo with accessories.

## 2. WHAT'S IN THE BOX

Please verify that all components are present before beginning installation:

- Car MP5 Player (Main Unit)
- Backup Camera
- External Microphone
- Remote Control
- Power Cable
- Horn Cable
- User Manual

# Size & Package List & WIRING



- 1. Radio Antenna
- 2. Left Audio Output
- 3. Video Output 1
- 4. CVBS Input
- 5. Right Audio Output
- 6. Video Output 2
- 7. Reversing Video Input
- 8. Audio input



- A1: Back in
- A2: Brake
- A3: Key 1
- A4: Battery+
- A5: Antenna
- A6: IL L
- A7: Ignition Switch
- A8: Ground
- B1: Right Rear Speaker+
- B2: Right Rear Speaker-
- B3: Right Front Speaker+
- B4: Right Front Speaker-
- B5: Left Front Speaker+
- B6: Left Front Speaker-
- B7: Left Rear Speaker+
- B8: Left Rear Speaker-

Single - DIN touchscreen radio is 176×90×50mm (6.9×3.5×2 inches, LWH). Please confirm the size of your car's dash opening before placing an order to ensure a proper fit



Power Cable



Horn Cable



Camera



Remote Control



User Manual

Figure 2.1: Package contents and unit dimensions.

## 3. INSTALLATION GUIDE



### 3.1 Pre-Installation Check

Before installation, ensure the unit's dimensions (176mm x 90mm x 50mm or 6.9 x 3.5 x 2 inches) are compatible with your car's dash opening. Confirm your vehicle's wiring harness matches the provided cables.

### 3.2 Wiring Diagram

Refer to the wiring diagram provided in Figure 3.1 for proper connections. Incorrect wiring can damage the unit or your vehicle's electrical system. It is recommended to have installation performed by a qualified professional.

# Size & Package List & WIRING



Single - DIN touchscreen radio is 176×90×50mm (6.9×3.5×2 inches, LWH). Please confirm the size of your car's dash opening before placing an order to ensure a proper fit




Figure 3.1: Main unit wiring diagram.

## 3.3 Mounting Steps

Follow these steps to securely mount the car stereo into your vehicle's dashboard:

1. **Detach the short sleeve:** Carefully remove the metal mounting sleeve from the radio body.
2. **Insert sleeve into dash:** Slide the short sleeve into your car's radio installation aperture.
3. **Secure the sleeve:** Use the provided mounting tools to press the iron clip onto the short sleeve, fastening it to the car's dash.
4. **Insert radio body:** Gently push the radio body into the short sleeve until it clicks securely into place.



Figure 3.2: Stereo mounting steps.

### 3.4 Backup Camera Installation

The included backup camera provides a rear view when reversing. Connect the camera as shown in Figure 3.3. Ensure the red wire from the camera power cable is connected to the reversing light's positive terminal, and the black wire to ground. The yellow RCA video cable connects to the unit's 'Reversing Video Input'.




Figure 3.3: Backup camera connection diagram.

## 4. OPERATING INSTRUCTIONS

### 4.1 Wired Apple CarPlay & Android Auto

Connect your iPhone or Android smartphone to the stereo's USB port using a certified USB cable. The system will automatically launch CarPlay or Android Auto, mirroring your phone's compatible apps onto the stereo screen. This allows for safe access to navigation, calls, messages, and music while driving.

# Wired Carplay & Android Auto



Figure 4.1: Wired CarPlay and Android Auto in operation.

## 4.2 Bluetooth Connectivity

To pair your device, go to the Bluetooth settings on the stereo and enable pairing mode. On your smartphone, search for available Bluetooth devices and select 'METEESER' (or similar name). Confirm the pairing code if prompted. Once connected, you can make hands-free calls, access your phonebook, and stream audio wirelessly.

## 4.3 FM Radio

Access the FM radio function from the main menu. Use the scan feature to automatically find and save available stations. You can manually tune to frequencies or select from your saved presets (up to 18 stations).

## 4.4 Steering Wheel Control (SWC)

If your vehicle supports steering wheel controls, you can configure them to operate the stereo. Navigate to the SWC settings in the system menu and follow the on-screen instructions to map your steering wheel buttons to corresponding stereo functions (e.g., volume, track skip, call answer).

## 4.5 Mirror Link

The Mirror Link function allows you to display your smartphone's screen directly onto the car stereo. Connect your Android or iOS phone via USB and activate the Mirror Link app on the stereo. This feature supports displaying various content, including videos and maps.

#### 4.6 Media Playback (USB/TF Card)

Insert a USB drive or TF card into the designated ports. The stereo supports various audio formats including APE, FLAC, WAV, MP3, and WMA, and video formats such as RM, RMVB, AVI, MP4, MKV, and 3GP. Select the USB or TF card source from the main menu to browse and play your media files.

#### 4.7 Backup Camera Display

When the vehicle is shifted into reverse gear, the stereo automatically switches to the backup camera view, displaying the rear surroundings to assist with parking and maneuvering.

#### 4.8 Audio Equalizer (EQ)

Customize your audio experience using the built-in 10-band equalizer. Access the EQ settings to adjust frequency bands, balance, and fader. Preset EQ modes (e.g., Jazz, Classic, Pop) are also available.




Figure 4.2: Key operating features: Bluetooth, FM Radio, EQ, and USB.

## 5. MAINTENANCE

To ensure the longevity and optimal performance of your METEESER car stereo, follow these maintenance guidelines:

- **Cleaning the Screen:** Use a soft, lint-free cloth to gently wipe the touchscreen. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaner. Avoid abrasive materials or harsh chemicals.
- **General Cleaning:** Keep the unit free from dust and debris. Use a soft brush or compressed air to clean around buttons and ports.
- **Temperature Control:** Avoid exposing the unit to extreme temperatures. Prolonged exposure to direct sunlight or very cold conditions can affect performance and lifespan.
- **Software Updates:** Check the official METEESER website periodically for any available firmware updates. Follow update instructions carefully to avoid damaging the unit.

## 6. TROUBLESHOOTING

If you encounter issues with your car stereo, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not power on	Incorrect wiring; Blown fuse; Power supply issue	Check power and ground connections. Verify vehicle fuse and stereo fuse. Ensure ignition wire is connected correctly.
No sound	Speaker wires disconnected; Volume too low; Mute activated; Incorrect audio settings	Check speaker wire connections. Increase volume. Deactivate mute function. Verify audio output settings.
CarPlay/Android Auto not connecting	Faulty USB cable; Phone not compatible; Software glitch	Use a high-quality, certified USB cable. Ensure your phone's OS is up to date. Restart both phone and stereo.
Backup camera not displaying	Camera wiring issue; Incorrect video input selected	Check camera power and video signal connections. Ensure the reversing trigger wire is correctly connected.
Controls working backwards / unresponsive	Calibration issue; Software error	Perform a system reset (refer to manual for reset button location, often a small pinhole). If issue persists, contact support.
Poor radio reception	Antenna not connected; Weak signal area	Ensure the antenna is securely connected. Try scanning for stations again. Consider an antenna booster if in a weak signal area.

If the problem persists after attempting these solutions, please contact METEESER customer support for further

assistance.

## 7. SPECIFICATIONS

Detailed technical specifications for the METEESER Single Din Car Stereo:

Feature	Specification
Product Dimensions	7.4 x 4.65 x 2.28 inches (18.7 x 11.8 x 5.8 cm)
Item Weight	1.32 pounds (0.6 Kilograms)
Display Type	IPS Touchscreen
Screen Resolution	1280 x 480P
Connectivity Technology	Bluetooth 5.2, USB, 3.5mm Jack
Special Features	Wired Apple CarPlay, Wired Android Auto, FM Radio, Mirror Link, Steering Wheel Control (SWC), DVR support, EQ
Compatible Devices	Smartphone
Audio Output Mode	MP3/WMA/WAV/APE/FLAC
Video Encoding	RM/RMVB/AVI/MP4/MKV/3GP
Output Power	45 Watts

## 8. WARRANTY AND SUPPORT

### 8.1 Product Warranty

The METEESER Single Din Car Stereo comes with a 2-Year Warranty. This warranty covers manufacturing defects and ensures the product functions as intended under normal use. For specific terms and conditions, please refer to the warranty card included with your product or contact customer support.

### 8.2 Technical Support

METEESER offers lifetime technical support for this product. If you have any questions regarding installation, operation, or troubleshooting, please do not hesitate to contact our professional customer service team.

**Contact Information:**

Email: [asd85hk@163.com](mailto:asd85hk@163.com)

Online Support: Visit the METEESER store on Amazon and click 'Ask a question' to reach the seller directly.



Figure 8.1: Support and Warranty Information.