

SICOTAS DRE01

SICOTAS DRE01 4-Drawer Dresser Instruction Manual

Model: DRE01 | Brand: SICOTAS

1. INTRODUCTION

Thank you for choosing the SICOTAS DRE01 4-Drawer Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions thoroughly before beginning assembly and retain them for future reference.



Image 1.1: Front view of the assembled SICOTAS DRE01 4-Drawer Dresser.

2. SAFETY INFORMATION

To prevent serious injury, always follow these safety precautions:

- **Anti-Tipping Device:** This dresser includes an anti-tipping device. It is crucial to securely anchor the dresser to the wall using this device to prevent accidental tipping, especially in households with children.
- **Weight Distribution:** Distribute weight evenly across drawers and on the tabletop. Avoid placing heavy

items on the top edge or in a way that could cause imbalance.

- **Assembly:** Assemble the unit on a soft, clean surface to prevent scratches. Ensure all fasteners are tightened securely before use.
- **Material Safety:** The dresser is made of environmentally friendly materials. However, keep small parts away from children during assembly.

3. PACKAGE CONTENTS

Before assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

3.1. Main Frame Components

- Top Board (1)
- Side Panels (2)
- Back Panel (1)
- Support Bars (various)

3.2. Drawer Components (x4 sets)

- Drawer Fronts with Rattan Accent (1 per drawer)
- Drawer Side Panels (2 per drawer)
- Drawer Back Panel (1 per drawer)
- Drawer Bottom Panel (1 per drawer)

3.3. Hardware & Accessories

- Golden Handles (4)
- Drawer Slides (8 pieces, 2 per drawer)
- Screws, Dowels, Cam Locks (various sizes)
- Anti-Tipping Kit (wall anchor, strap)
- Anti-Slip Foot Pads (4)

4. ASSEMBLY INSTRUCTIONS

Assembly typically requires one to two individuals. A screwdriver and possibly a rubber mallet (not included) may be helpful. Follow the numbered steps carefully.

4.1. Video Guide: Installation of 4 Drawers Chest of Drawers

Video 4.1: A detailed video guide demonstrating the assembly process for the 4-drawer chest.

4.2. Step-by-Step Assembly

1. **Prepare the Base:** Attach the anti-slip foot pads to the bottom of the side panels. Secure the drawer slides to the inner sides of the main frame panels as indicated in the diagram.
2. **Construct the Frame:** Connect the side panels to the bottom and top boards using the provided dowels, screws, and cam locks. Ensure all connections are tight and stable.

3. **Install Back Panel:** Slide the back panel into the grooves on the frame. Secure it with small nails or screws as per instructions.

4. **Assemble Drawers (Repeat 4 times):**

- Attach the golden handle to the drawer front.
- Connect the drawer front, side panels, and back panel using screws and dowels.
- Slide the drawer bottom panel into the grooves.
- Attach the remaining drawer slide components to the sides of the assembled drawer box.

5. **Insert Drawers:** Carefully slide each assembled drawer into its corresponding slot in the main frame. Ensure smooth operation.

6. **Attach Anti-Tipping Device:** Following the instructions in the anti-tipping kit, securely attach the device to the back of the dresser and to a wall stud. This step is critical for safety.



Image 4.2: Various views of the dresser, illustrating its construction.

5. OPERATING INSTRUCTIONS

Your SICOTAS DRE01 dresser is designed for versatile storage and use.

- **Drawer Usage:** The 4 wider and deeper drawers are ideal for storing clothing, blankets, underwear,

socks, diapers, cosmetics, and toys. The premium metal guide rails ensure smooth opening and closing.

- **Tabletop Functionality:** The engineered wooden tabletop with raised edges is suitable for placing items such as glasses, alarm clocks, table lamps, magazines, and books. The raised edges help prevent items from sliding off.
- **Versatile Placement:** This dresser can be used in various rooms including bedrooms, living rooms, guest rooms, closets, nurseries, hallways, and entryways.



Image 5.1: The dresser integrated into various home environments.

Larger Capacity Drawers



Image 5.2: Open drawers demonstrating storage capacity.

6. MAINTENANCE AND CARE

To ensure the longevity and appearance of your dresser:

- **Cleaning:** Wipe the surface with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Clean up spills immediately to prevent staining or damage to the scratch and water-resistant veneer.
- **Sunlight Exposure:** Prolonged exposure to direct sunlight may cause color fading.
- **Hardware:** Periodically check and tighten all screws and fasteners to maintain stability.

7. TROUBLESHOOTING

If you encounter any issues with your dresser, consider the following:

- **Drawers not sliding smoothly:** Ensure the drawer slides are correctly installed and free of

obstructions. Check that all screws on the slides are tightened.

- **Wobbling:** Verify that all cam locks and screws are fully tightened. Ensure the dresser is placed on a level surface; adjust anti-slip foot pads if necessary.
- **Missing parts:** Refer to the 'Package Contents' section and contact customer support if any components were missing upon delivery.

8. SPECIFICATIONS

Feature	Detail
Brand	SICOTAS
Model Number	DRE01
Product Dimensions	15.7"D x 28.3"W x 37.8"H
Color	Reclaimed Caramel Oak/4 Drawers
Room Type	Bedroom, Dressing Room, Entryway, Hallway, Living Room
Material	FSC-Certified Engineered Wood, Rattan Accents, Metal Handles
Assembly Required	Yes
Special Features	Anti-tipping device, Raised tabletop edges, Anti-slip foot pads, Smooth metal guide rails



Image 8.1: Product dimensions.

9. CUSTOMER SUPPORT

For any questions, concerns, or assistance with your SICOTAS DRE01 dresser, please contact our professional customer service team. We are dedicated to providing satisfactory support before and after your purchase.

Please note that slight color variations may occur due to material batches, manufacturing processes, or display settings. These are normal and do not impact quality.