



Manuals.plus /

› Generico /

› Portable Air Conditioner 7000 BTU/H Dehumidifier Function - M07614 User Manual

## Generico M07614

# Portable Air Conditioner 7000 BTU/H - M07614 User Manual

Model: M07614 | Brand: Generico

## 1. INTRODUCTION

---

### 1.1 Product Overview

This manual provides essential information for the safe and efficient operation of your Generico M07614 Portable Air Conditioner. This versatile unit offers cooling, dehumidifying, and fan functions, designed to provide comfort in various environments. It features a 7000 BTU cooling capacity, a 24-hour timer, and an LED touch panel for easy control.

### 1.2 Safety Information

Please read all safety warnings and instructions carefully before using this appliance to prevent injury or damage. Keep this manual for future reference.

- Ensure the power supply matches the unit's requirements (220-240V 50Hz).
- Do not operate the unit with a damaged cord or plug.
- Do not block air inlets or outlets. Maintain at least 20 cm clearance around the unit.
- Do not insert objects into the air vents.
- Always unplug the unit before cleaning or maintenance.
- Do not use the unit in wet environments or near water.
- Keep children and pets away from the unit during operation.
- This appliance uses R290 refrigerant. Do not puncture the refrigerant circuit.

## 2. PRODUCT COMPONENTS

---

Familiarize yourself with the main parts of your portable air conditioner.



Figure 2.1: Front view of the Generico M07614 Portable Air Conditioner, showing the air outlet and control panel on top.



Figure 2.2: Top view of the air conditioner, displaying the LED touch panel, the included remote control, and the instruction manual.

- Main Unit (Portable Air Conditioner)
- Exhaust Hose
- Window Sealing Kit (Adapter, Window Slider Kit)
- Remote Control
- Drain Hose (for continuous drainage, if applicable)
- Washable Air Filter (located at the back/side)

## 3. SETUP AND INSTALLATION

---

### 3.1 Choosing a Location

Place the air conditioner on a flat, stable surface near a window or opening where the exhaust hose can be vented outdoors. Ensure there is at least 20 cm of space around the unit for proper airflow.

### 3.2 Exhaust Hose Installation

1. Attach one end of the exhaust hose to the air outlet on the back of the unit.
2. Attach the other end of the exhaust hose to the window adapter.
3. Install the window slider kit in your window opening and secure it.
4. Insert the window adapter into the opening of the window slider kit, ensuring a tight seal to prevent hot air from re-entering the room.

### 3.3 Power Connection

Plug the power cord into a grounded electrical outlet (220-240V 50Hz). Do not use extension cords or multi-plugs.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Control Panel (LED Touch Panel)

The LED touch panel on top of the unit allows you to control all functions. The display shows the current temperature or timer settings.

### 4.2 Remote Control

The included remote control provides convenient operation from a distance. Ensure batteries are correctly inserted.

- **Power Button:** Turns the unit ON/OFF.
- **Mode Button:** Cycles through operating modes: Cooling, Dehumidifying, Fan, Auto.
- **Temperature Buttons (+/-):** Adjusts the desired temperature (15-31 °C).
- **Fan Speed Button:** Selects fan speed (Low/High).
- **Timer Button:** Sets the 24-hour ON/OFF timer.
- **Sleep Button:** Activates Sleep mode for quieter operation and energy saving.
- **Swing Button:** Controls the oscillation of the air louvers (if applicable).

### 4.3 Operating Modes

- **Cooling Mode:** Provides powerful cooling. Set desired temperature.
- **Dehumidifying Mode:** Removes excess moisture from the air (capacity: 24 liters/day).
- **Fan Mode:** Circulates air without cooling.
- **Auto Mode:** Automatically selects cooling or fan mode based on room temperature.

## 5. MAINTENANCE

---

Regular maintenance ensures optimal performance and extends the lifespan of your air conditioner. Always unplug the unit before performing any maintenance.

### 5.1 Cleaning the Air Filter

The unit is equipped with a washable filter. Clean the filter every two weeks or more frequently depending on usage and air quality.

1. Turn off and unplug the air conditioner.
2. Locate and remove the air filter from the back or side of the unit.
3. Rinse the filter under running water (max 40°C) or use a vacuum cleaner to remove dust.
4. Allow the filter to air dry completely before re-installing it. Do not expose to direct sunlight.

## 5.2 Draining the Water Tank

The unit will emit an audible signal when the internal water tank is full. Drain the water to resume operation.

1. Turn off and unplug the air conditioner.
2. Place a shallow pan or container under the drain outlet (usually at the bottom rear of the unit).
3. Remove the drain plug/cap and allow the water to flow out completely.
4. Replace the drain plug/cap securely.

## 5.3 General Cleaning and Storage

- Wipe the exterior of the unit with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Before long-term storage, drain all water, clean the filter, and allow the unit to run in fan mode for a few hours to dry the internal components.
- Store the unit in a dry, cool place, covered to protect from dust.

## 6. TROUBLESHOOTING

---

Before contacting customer support, please refer to the following common issues and solutions.

Problem	Possible Cause	Solution
Unit does not turn on.	No power, power cord unplugged, circuit breaker tripped.	Check power connection, ensure outlet is working, reset circuit breaker.
Unit is running but not cooling.	Air filter clogged, exhaust hose not properly installed, room too large, doors/windows open.	Clean air filter, ensure exhaust hose is sealed, close doors/windows, check room size.
Water tank full indicator is on.	Internal water tank is full.	Drain the water tank as per Section 5.2.
Unit is noisy.	Unit not on a flat surface, foreign object in fan.	Place on a flat surface, check for obstructions (unplug first).

## 7. SPECIFICATIONS

---

Technical specifications for the Generico M07614 Portable Air Conditioner.

Feature	Specification
Model	M07614
Brand	Generico
Cooling Capacity	7000 BTU/h (2.0 kW)
Dehumidifying Capacity	24 Liters/day
Air Flow Volume	270 m <sup>3</sup> /h
Temperature Setting Range	15-31 °C
Voltage / Frequency	220-240V / 50Hz
Wattage	1960.8 watts
Timer	24-hour
Operating Modes	Cooling, Dehumidifier, Fan, Automatic
Fan Speeds	2 speeds
Refrigerant	R290
Filter Type	Washable Filter
Product Dimensions (L x W x H)	31 x 31 x 64 cm
Product Weight	19 Kg

## 8. WARRANTY AND SUPPORT

---

For warranty information and technical support, please refer to the warranty card included with your product or contact the retailer/manufacturer directly. Keep your proof of purchase for any warranty claims.

For further assistance, please visit the official website of Generico or contact their customer service department.